


View with pins facing upwards.



\* For all available feedback/ motor options, check the user manual of the drive  
 \*\* The PNP/NPN connection is configured by software  
 \*\*\* For a detailed EtherCAT bus connection diagram check the user manual or datasheet of the drive

<b>iPOS8015 MZ-CAT</b>		<b>P/N:P022.036.E122</b>	
Copyright © Technosoft 2025. All rights reserved.			
<b>iPOS8015 MZ-CAT - Electrical Connection Diagram</b>			
Size <b>A4</b>	Document Number: P091.022.8015.MZ.CAT.CDG.0825	Author: ALN	Rev <b>A</b>
Date: 0825	Sheet 1 of 1		