



T E C H N O S O F T

TML_LIB

v2.0

**Motion Control Library for
Technosoft Intelligent Drives**

User Manual

Read This First

Whilst Technosoft believes that the information and guidance given in this manual is correct, all parties must rely upon their own skill and judgment when making use of it. Technosoft does not assume any liability to anyone for any loss or damage caused by any error or omission in the work, whether such error or omission is the result of negligence or any other cause. Any and all such liability is disclaimed.

All rights reserved. No part or parts of this document may be reproduced or transmitted in any form or by any means, electrical or mechanical including photocopying, recording or by any information-retrieval system without permission in writing from Technosoft S.A.

About This Manual

This book describes the motion library **TML_LIB v2.0**. The book is common for Microsoft Windows and Linux (x86, x64 and ARM) versions of the library. The TML_LIB is a collection of functions, which can be integrated in a PC application. For Microsoft Windows version of the TML_LIB you can write the application in C#, C/C++, Delphi Pascal or Visual Basic. For Linux platforms the application for TML_LIB must be written in C/C++. With TML_LIB motion library, you can quickly program the desired motion and control the Technosoft intelligent drives and motors (with the drive integrated in the motor case) from a PC. The TML_LIB allows you to communicate with Technosoft drive/motors via serial RS-232, CAN or Ethernet channels.

Scope of This manual

This manual applies to the following Technosoft intelligent drives and motors:

- **iPOS** family of drives (all firmware revisions)
- **iGVD** (all firmware revisions)
- **iMOTIONCUBE** (all firmware revisions)
- **iMOT** family of intelligent motors (all firmware revisions)
- **previous generation of Technosoft products**

Notational Conventions

This document uses the following conventions:

- ❑ **Drive/motor** – an *intelligent drive* or an *intelligent motor* having the drive part integrated in the motor case
- ❑ **TML** – Technosoft Motion Language
- ❑ **IU** – drive/motor internal units
- ❑ **ACR.5** – bit 5 of ACR data

Related Documentation

EasyMotion Studio Quick Setup manual - summarizes the steps required to configure the drive and motor setup, using the EasyMotion Studio (ESM) software. It is also describing the drive programming with ESM and the testing and debugging tools included in the software (control panels, Logger and scope).

TML list parameters and description - describes in detail the TML variables, parameters and registers.

Help of the EasyMotion Studio software platform – describes how to use the EasyMotion Studio software. It includes: motion system setup & tuning wizard, motion sequence programming wizard, testing and debugging tools like: data logging, watch, control panels, on-line viewers of TML registers, parameters and variables, etc.

Contact information

Visit Technosoft website	www.technosoftmotion.com
Receive general information or assistance	support@technosoftmotion.com
Report issues or make suggestions	

Table of contents

Read This First.....	1
About This Manual.....	1
Scope of This manual.....	1
Notational Conventions	1
Related Documentation.....	2
Contact information.....	2
Table of contents	3
1. Introduction	8
2. Getting started.....	10
2.1. Hardware installation	10
2.2. Software installation on Microsoft Windows platforms	10
2.2.1. Installing EasySetUp	10
2.2.2. Installing TML_Lib library	10
2.3. Software installation on Linux platforms	10
2.3.1. Installing Microsoft Windows emulator.....	10
2.3.2. Installing EasySetUp	11
2.3.3. Installing TML_Lib library	11
2.4. Build the host application with TML_Lib.....	11
2.4.1. Drive/motor setup	11
2.4.2. Build you application with TML_Lib	15
3. TML description	16
3.1. Basic concept	16
3.2. Internal units and scaling factors	16
3.3. Axis Identification	17
3.4. Multithread and multiprocess applications with TML_Lib	18
3.5. Description of functions	19
3.5.1. Communication setup	20
3.5.1.1. TS_OpenChannel	20
3.5.1.2. TS_SelectChannel	23
3.5.1.3. TS_CloseChannel	24
3.5.2. Drive setup	25
3.5.2.1. TS_LoadSetup.....	25
3.5.2.2. TS_SetupAxis.....	26
3.5.2.3. TS_SetupGroup	27
3.5.2.4. TS_SetupBroadcast.....	28
3.5.2.5. TS_DriveInitialisation	29

3.5.2.6.	TS_Save	30
3.5.2.7.	TS_GetMotorPositionScalingFactor	31
3.5.2.8.	TS_GetLoadPositionScalingFactor	32
3.5.2.9.	TS_GetCurrentScalingFactor	33
3.5.2.10.	TS_GetTimeScalingFactor	34
3.5.3.	Drive administration	35
3.5.3.1.	TS_SelectAxis	35
3.5.3.2.	TS_SelectGroup	36
3.5.3.3.	TS_SelectBroadcast	37
3.5.4.	Drive/motor monitoring	38
3.5.4.1.	TS_ReadStatus	38
3.5.4.2.	TS_GetFirmwareVersion	39
3.5.4.3.	TS_GetApplicationInfo	40
3.5.4.4.	TS_GetLibraryVersion	41
3.5.4.5.	TS_SendDataToHost	42
3.5.4.6.	TS_CheckForUnrequestedDriveMessages	43
3.5.4.7.	TS_RegisterHandlerForUnrequestedDriveMessages	44
3.5.4.8.	TS_OnlineChecksum	45
3.5.5.	Error handling	46
3.5.5.1.	TS_ResetFault	46
3.5.5.2.	TS_Reset	47
3.5.5.3.	TS_GetLastErrorText	48
3.5.6.	Motion programming	49
3.5.6.1.	TS_MoveAbsolute	49
3.5.6.2.	TS_MoveRelative	51
3.5.6.3.	TS_MoveSCurveAbsolute	53
3.5.6.4.	TS_MoveSCurveRelative	54
3.5.6.5.	TS_MoveVelocity	55
3.5.6.6.	TS_SetAnalogueMoveExternal	56
3.5.6.7.	TS_SetDigitalMoveExternal	57
3.5.6.8.	TS_SetOnlineMoveExternal	58
3.5.6.9.	TS_VoltageTestMode	59
3.5.6.10.	TS_TorqueTestMode	60
3.5.6.11.	TS_PVTSetup	61
3.5.6.12.	TS_SendPVTFirstPoint	63
3.5.6.13.	TS_SendPVTPoint	64
3.5.6.14.	TS_PTSetup	65
3.5.6.15.	TS_SendPTFirstPoint	67
3.5.6.16.	TS_SendPTPoint	68

3.5.6.17.	TS_SetGearingMaster	69
3.5.6.18.	TS_SetGearingSlave	70
3.5.6.19.	TS_MotionSuperposition	72
3.5.6.20.	TS_SetCammingMaster	73
3.5.6.21.	TS_SetCammingSlaveRelative	74
3.5.6.22.	TS_SetCammingSlaveAbsolute	76
3.5.6.23.	TS_CamDownload	78
3.5.6.24.	TS_CamInitialization	79
3.5.6.25.	TS_SetMasterResolution	80
3.5.6.26.	TS_SendSynchronization	81
3.5.7.	Motor commands	82
3.5.7.1.	TS_Power	82
3.5.7.2.	TS_UpdateImmediate	83
3.5.7.3.	TS_UpdateOnEvent	84
3.5.7.4.	TS_Stop	85
3.5.7.5.	TS_SetPosition	86
3.5.7.6.	TS_SetTargetPositionToActual	87
3.5.7.7.	TS_SetCurrent	88
3.5.7.8.	TS_QuickStopDecelerationRate	89
3.5.8.	Events	90
3.5.8.1.	TS_CheckEvent	90
3.5.8.2.	TS_SetEventOnMotionComplete	91
3.5.8.3.	TS_SetEventOnMotorPosition	92
3.5.8.4.	TS_SetEventOnLoadPosition	93
3.5.8.5.	TS_SetEventOnMotorSpeed	94
3.5.8.6.	TS_SetEventOnLoadSpeed	95
3.5.8.7.	TS_SetEventOnTime	96
3.5.8.8.	TS_SetEventOnPositionRef	97
3.5.8.9.	TS_SetEventOnSpeedRef	98
3.5.8.10.	TS_SetEventOnTorqueRef	99
3.5.8.11.	TS_SetEventOnEncoderIndex	100
3.5.8.12.	TS_SetEventOnLimitSwitch	101
3.5.8.13.	TS_SetEventOnDigitalInput	102
3.5.8.14.	TS_SetEventOnHomeInput	103
3.5.9.	TML jumps and function calls	104
3.5.9.1.	TS_GOTO	104
3.5.9.2.	TS_GOTO_Label	105
3.5.9.3.	TS_CALL	106
3.5.9.4.	TS_CALL_Label	107

3.5.9.5.	TS_CancelableCALL.....	108
3.5.9.6.	TS_CancelableCALL_Label	109
3.5.9.7.	TS_Homing	110
3.5.9.8.	TS_ABORT.....	111
3.5.9.9.	TS_DownloadProgram	112
3.5.9.10.	TS_DownloadSwFile.....	113
3.5.10.	IO handling	114
3.5.10.1.	TS_SetupInput.....	114
3.5.10.2.	TS_GetInput.....	115
3.5.10.3.	TS_SetupOutput.....	116
3.5.10.4.	TS_SetOutput	117
3.5.10.5.	TS_GetHomeInput	118
3.5.10.6.	TS_GetMultipleInputs	119
3.5.10.7.	TS_SetMultipleOutputs2	120
3.5.11.	Data transfer	121
3.5.11.1.	TS_SetIntVariable	121
3.5.11.2.	TS_GetIntVariable	122
3.5.11.3.	TS_SetLongVariable	123
3.5.11.4.	TS_GetLongVariable	124
3.5.11.5.	TS_SetFixedVariable	125
3.5.11.6.	TS_GetFixedVariable	126
3.5.11.7.	TS_GetVariableAddress	127
3.5.11.8.	TS_SetBuffer	128
3.5.11.9.	TS_GetBuffer	129
3.5.12.	Miscellaneous	130
3.5.12.1.	TS_Execute.....	130
3.5.12.2.	TS_ExecuteScript	131
3.5.12.3.	TS_GetOutputOfExecute.....	132
3.5.13.	Data logger	133
3.5.13.1.	TS_SetupLogger	133
3.5.13.2.	TS_StartLogger	134
3.5.13.3.	TS_CheckLoggerStatus	135
3.5.13.4.	TS_UploadLoggerResults.....	136
1.	Examples	138
4.1.	Start Up	138
4.2.	Drive status	139
4.3.	Error handling	139
4.4.	Basic move.....	139
4.5.	Homing.....	140

4.6.	External reference	141
4.7.	Multi-axis	142
4.8.	PVT - multithreading.....	142
4.9.	Logger.....	142
4.10.	Event handling	142
4.11.	I/O handling	143
4.12.	Distributed tasks.....	143
	Appendix A – CAM files format	144
	Appendix B – Package contents of TML_LIB for Microsoft Windows.....	145
	Appendix C – Package contents of TML_LIB for Linux	147
	Appendix D – TML_Lib.h file.....	148

1. Introduction

The programming of Technosoft intelligent drives/motors involves 2 steps:

- 1) Drive/motor setup
- 2) Motion programming

For **Step 1 – drive/motor setup**, Technosoft provides **EasySetUp**. EasySetUp is an integrated development environment for the setup of Technosoft drives/motors. The output of EasySetUp is a collection of *setup data*, which can be downloaded to the drive/motor non-volatile memory (EEPROM) or saved on the PC for later use. The drive/motor copies the setup data from the EEPROM into the RAM memory at power-on and use it during runtime. The reciprocal is also possible i.e. to retrieve the complete setup data from a drive/motor non-volatile memory previously programmed. EasySetUp can be downloaded free of charge from Technosoft web page. It is also provided on the TML_LIB installation media.

For **Step 2 – motion programming**, Technosoft offers multiple options, like:

- A. Use the motion controller embedded on the drives/motors and build the motion programming in Technosoft Motion Language (TML). For this operation Technosoft provides **EasyMotion Studio**, an IDE for both drives setup and motion programming. The output of EasyMotion Studio is a collection of setup data and a TML program to download and execute on the drive/motor.
- B. Use a **.DLL** with high-level motion functions which can be integrated in a host application written in C#, C/C++, Delphi Pascal, Visual Basic or LabVIEW
- C. Use a **PLCopen** compatible library with motion function blocks which can be integrated in a PLC application based on one of the IEC 61136 standard languages
- D. Combine option A. with options B. or C. to really distribute the intelligence between the master/host and the drives/motors in complex multi-axis applications. Thus, instead of trying to command each step of an axis movement, you can program the drives/motors using TML to execute complex tasks and inform the master when these are done.

The **TML_Lib** motion library is part of option B. – a collection of functions allowing you to implement motion control applications on a PC computer. The link between the Technosoft drives/motors and the PC can be done via serial link, via CAN-bus using a PC to CAN interface or via Ethernet using an adapter/bridge between Ethernet and RS-232/CAN. Realized as a collection of high-level functions, the library allows you to focus on the main aspects related to your application specific implementation, and to simply use the drive and execute motion commands by calling appropriate functions from the library.

This manual presents how to install and use the components of the **TML_Lib** motion library.

Remarks:

- *Option D. requires using EasyMotion Studio instead of EasySetUp. With EasyMotion Studio you can create high-level motion functions in TML, to be called from the master/host software.*
- *EasyMotion Studio is also recommended for applications that require homing as it comes with 32 predefined homing procedures to select from, with the possibility to adapt them.*




Figure 1 - Using TML_LIB to control a Technosoft intelligent drive from the PC computer

2. Getting started

2.1. Hardware installation

For the hardware installation of the Technosoft drives/motors see their user manual.

For drives/motors setup, you can connect your PC to any drive/motor using an RS232 serial link. Through the serial link you can access all the drives/motors from the CAN network. Alternately, the PC can be directly connected to the CAN bus network if it is equipped with one of the CAN interfaces supported by EasySetUp.

2.2. Software installation on Microsoft Windows platforms

In order to perform successfully the following software installations, make sure that you have the “Administrator” rights.

2.2.1. Installing EasySetUp

On the TML_LIB installation CD you'll find the setup for EasyMotion Studio Demo version. This application includes a fully functional version of EasySetUp and a demo version of EasyMotion Studio. Start the setup and follow the installation instructions.

2.2.2. Installing TML_Lib library

Start the TML_LIB setup and follow the installation instructions. The package contents of the TML_LIB for Microsoft Windows is described in Appendix A.

Remark: The Delphi application and the *TML_lib.dll* file must be in the same directory at run time. Hence, you have to copy the **TML_lib.dll** file in the Delphi project's folder (by default *examples/DELPHIDemo*) before running the application.

2.3. Software installation on Linux platforms

In order to perform successfully the following software installations, make sure that you have the “root” rights and the following programs installed: **tar**, **gzip** and **sed**. Also, the TML_LIB library requires the GNU C library version 2 (**glibc-2.***) and GNU Compiler Collection release 3 (**gcc-3.***).

2.3.1. Installing Microsoft Windows emulator

EasyMotion Studio and EasySetUp are applications built for Microsoft Windows operating systems. Hence to use the applications from Linux environment an emulator for Microsoft Windows must be installed, for example **Wine**.

2.3.2. Installing EasySetUp

On the TML_LIB installation CD you'll find the setup for EasyMotion Studio Demo version. This application includes a fully functional version of EasySetUp and a demo version of EasyMotion Studio. Start the setup using the Microsoft Windows emulator and follow the installation instructions.

2.3.3. Installing TML_Lib library

From the TML_LIB installation CD copy the file **TML_lib_linux_x86.run**. Change the file's access permissions with the command **chmod ugo +x TML_lib_linux_x86.run** and launch it. After you fill the registration information the library files will be automatically saved in the appropriate directories.

2.4. Build the host application with TML_Lib

2.4.1. Drive/motor setup

Before starting to send motion commands from the PC, the drive/motor must be configured according with the application requirements. For this operation you have to use **EasySetUp**, the integrated environment for the configuration of the Technosoft drives and motors.

The output of **EasySetUp** is the setup table with all the information needed to configure and parameterize a Technosoft drive/motor. It must be downloaded to the drive/motor non-volatile memory. The setup table is copied automatically by the drive at power-on into the RAM memory of the drive/motor and is used during runtime.

Steps for commissioning a Technosoft drive/motor

Step 1. Start EasySetUp

For Microsoft Windows platforms execute: "Start | Programs | EasySetUp | EasySetUp" or "Start | Programs | EasyMotion Studio | EasySetUp" depending on which installation package you have used. On Linux platforms use the Microsoft Windows emulator to start EasySetUp.

Step 2. Establish communication

Use the **Communication | Setup** command to check/change your PC communication settings. In the Communication Setup dialog select and configure the communication channel between the PC and the drive/motor. Press the **Help** button to find detailed information on how to setup the communication channels supported. Power on the drive/motor and then press the OK button to close the **Communication | Setup** dialog.

Remarks:

1. When first time started, EasySetUp tries to communicate with the drive/motor via RS-232 and COM1 (default communication settings). If the drive/motor is powered and connected to the PC port COM1 via an RS-232 cable, the communication can be automatically established.
2. The Port list for RS232 communication is populated automatically by EasySetUp with the COM ports available on the PC




Figure 2 – Communication Setup dialogue from EasySetUp

If the communication is established, then EasySetUp will display in the status bar (the bottom line) the text “**Online**” plus the axis ID of your drive/motor, the serial number and its firmware version.



Figure 3 – Status bar of EasySetUp when communication is established

Otherwise the text displayed is “**Offline**” and a communication error message informs you the error type. In this case, return to the Communication | Setup dialog, press the Help button and check troubleshoots.

Step 3. Setup drive/motor

Press the **New** button and select your drive/motor type. Depending on the product chosen, the selection may continue with the motor technology (for example: brushless motor, brushed motor) or the control mode (for example stepper – open-loop or stepper – closed-loop) and type of feedback device (for example: incremental encoder, SSI encoder).

This opens 2 setup dialogues: for **Motor Setup** and for **Drive setup** through which you can configure and parameterize a Technosoft drive/motor, plus several predefined control panels customized for the product selected. In the **Motor setup** dialogue you can introduce the data of your motor and the associated sensors. Data introduction is accompanied by a series of tests having as goal to check the connections to the drive and/or to determine or validate a part of the motor and sensors parameters.

Brushless Motor Setup

Guideline assistant

Previous Next

Step 1. Select your motor from a database. If your motor does not exist in any database, proceed through all the next steps in order to define your motor and sensors data. In either case, use the tests from the next steps to verify/detect the motor and sensors parameters and operation.

Motor data

Nominal current: 3.52 A

Peak current: 10.6 A

Pole pairs: 4

Torque constant: 0.0355 Nm/A

Line to line resistance: 0.832736 Ohms

Line to line inductance: 1.09657 mH

Motor inertia: 48 kgm² E-7

Test Phase Connections

Detect Number of Pole Pairs

Identify Resistance and Inductance

Motor inertia is unknown

Motor sensors

Type: Incremental Encoder

Connector: Feedback 1

No. of lines/rev: 500 lines

Hall configuration: 8

Digital Halls: ☒

Temperature: ☐ Sensor type: NTC PTC

Filter encoder inputs to: 1/3 of maximum bandwidth

Reverse encoder counting: ☒

Load sensors

Type: None

Database: Siemens

Motor:

Save to User Database Delete Help Cancel

Motor brake

☐ Motor brake on output line :

OUT0

Motor brake is applied when NPN (sink) output is connected to GND.

Drive not active Drive active

Brake applied Brake released

Brake release delay : 0 ms

Brake apply delay : 0 ms

Movement direction

☐ Reverse movement direction

Transmission to load

Transmission type: ☒ Rotary to rotary

☐ Rotary to linear

☐ Linear to rotary

☐ Linear to linear

Motor displacement of: 1 rot

corresponds on load to: 1 rot

Figure 4 – Motor Setup dialogue

In the **Drive setup** dialogue you can configure and parameterize the drive for your application. Each configuration dialogue includes a **Guideline Assistant**, which will guide you through the whole process of introducing and/or checking your data. Close the Drive setup dialogue with **OK** to keep all the changes regarding the motor and the drive setup.

Drive Setup

Guideline assistant

Previous Next

Step 1. In the <<Control mode>> group box, select what do you want to control: position, speed or torque. In the <<Commutation method>> group box, choose sinusoidal or trapezoidal mode. The trapezoidal mode is possible only if your

CANbus

☒ Baud rate F/W default CANopen settings...

Current controller

Kp 4.0573 Ki 0.62688

Tune & Test

Speed controller

Kp 216.05 Integral limit 40 % Ki 7.449

Tune & Test

Position controller

Kp 0.23242 Integral limit 40 % Ki 0 Feedforward 758.87 (Acceleration) Kd 0 (Speed)

Kd filter 0 Modify Gain sched. OFF

Tune & Test

Motion complete settings

Band 0.5 rot Time 0.001 s

Filters

☒ #1 SPD LP2 400Hz Q=0.707 ☐ Filter 6 ☐ Filter 7 ☐ Filter 8 ☐ Filter 9 ☐ Filter 5 ☐ Filter 10 ☐ Current controller filter

Setup Filters

Control mode

☒ Position ☐ Speed ☐ Torque

Advanced

External reference

☐ No ☒ Yes Setup

☒ Analogue ☐ Incremental

☐ Automatically activated after Power On

Commutation method

☐ Trapezoidal ☒ Sinusoidal

Axis ID selection

☒ Set / change axis ID H/W

Drive Info

Drive operation parameters

Power supply 23.8185 V Detect

Current limit 7.06 A

Load speed limit 603.186 rad/s

Protections

☒ Over current Motor current > 8.472 A for more than 0.01 s

☒ Control error Position error > 0.6 rot for more than 3 s

☒ Control error Speed error > 600 rpm for more than 3 s

☐ Motor over temperature

☐ I2t over current 7.766 A for 15 s

External chopping resistor

☐ Connected Activate if power supply > 49.999 V

Inputs polarity

	Enable	Limit switch+	Limit switch-	Type
Active high (Connected to +Vlog)	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/> Sink (PNP)
Active low (Open/No connection)	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/> Source(NPN)

☐ Software limits - restrict movement

Negative limit -1073741.82 rot Positive limit 1073741.82 rot

☐ Position range limits

Minimum 0 rot Maximum 0.001 rot

Start mode

Move till aligned with phase A

Settings

OK Cancel Help

Motor Setup

Figure 5 – Drive Setup dialogue

Step 4. Download setup table to drive/motor

Use **Setup | Download Setup to Drive/Motor** menu command to download your setup data in the drive/motor non-volatile memory in the *setup table*. From now on, at each power-on, the setup data is copied into the drive/motor RAM memory that is used during runtime.

Step 5. Reset the drive/motor to activate the drive setup data

In order to activate the drive setup data, use the **Setup | Reset Active Drive/Motor** menu command.

Step 6. Create the setup data for TML_LIB

The TML_LIB requires the description of the drive/motor setup for the proper execution of the application. The setup description is generated with the **Setup | Export to TML_LIB...** command if you are using **EasySetup**, or the **Application | Export to TML_LIB...** command if EasyMotion Studio is used. The information is generated in the form of an archive file with the **.t.zip** extension and is saved in the **Archives** folder from EasySetUp/EasyMotion Studio installation folder (by default C:\Program Files\Technosoft\ESM).

2.4.2. Build you application with TML_Lib

TML_Lib is a collection of high level functions, grouped in several categories and provided as a dynamically loadable file (**TML_LIB.dll** for Windows version respectively **libTML_lib.so** for Linux version).

Most of the functions from TML_lib library is of Boolean type, and return a '**True**' value if the execution of the function completed without any error (at the host level). If the function returns a '**False**' value then the error description can be retrieved with the **TS_GetLastErrorText** function.

Steps to build the host application with TML_Lib

Step 1. Create the project for the host application.

Launch your development environment and create a new project. For details how to build the project read the development environment documentation.

Remark: For Borland C++ projects the user must define a **WINDOWS** or **WIN32** symbol in order to compile the C/C++ application.

Step 2. Setup the communication.

The host application is based on the communication between PC and Technosoft drives/motors thus it should begin with the communication channel setup. The communication channel is opened with the **TS_OpenChannel** function. When the host application is terminated the communication channel should be closed with the **TS_CloseChannel** function.

Step 3. Load setup configurations.

The setup description is required by the library functions in order to check the compatibility between the drive and the operation to be executed (as an example, avoiding issuing an "Output port" command to a port which is an input port on that drive).

The setup description is generated by EasySetUp/EasyMotion Studio based on the actual drive/motor configuration. The setup information is in the form of an archive file with the **t.zip** extension. The t.zip files are saved by default in the **Archives** folder from EasyMotion Studio/EasySetUp installation folder.

The setup data of the drive/motor are declared in the TML_lib application with the **TS_LoadSetup** function. The **TS_LoadSetup** requires as argument the ***.t.zip** file. The **TS_LoadSetup** function must be called for each axis controlled through TML_Lib library.

Step 4. Link setup description with the address of the drive/motor.

The setup descriptions loaded in the previous step must be linked to the drives/motors, identified by their address (axis ID). The setup description is associated to an axis with the **TS_SetupAxis** function.

Step 5. Select the active axis/group.

The messages sent from the PC address to one axis. Use function **TS_SelectAxis** to choose the destination of the messages. All further function calls, which send TML messages on the communication channel, will address the messages to this active axis.

Step 6. Program the motion for current axis.

Use the TML_Lib motion functions to implement the motion sequences required by the application.

3. TML description

3.1. Basic concept

The Technosoft intelligent drives are programmable using the Technosoft Motion Language (TML). TML consists of a high-level set of codes allowing the user to parameterize and execute specific motion operations.

TML allows to:

- Configure the motion mode (profiles, contouring, gearing in multiple axes structures, etc.)
- Detect / specifically treat external signals as limit switches, captures
- Execute homing sequences
- Setup / start specific action on pre-defined motion events
- Synchronize multiple axes structures, by sending group commands
- etc.

The **TML_Lib** library is the tool that helps you to handle the process of motion control application implementation on a PC computer, at a high level, without the need to write / compile TML code.

A central element of the library is the communication kernel, which is responsible of correct opening of the communication channel (serial RS-232, CAN-bus or Ethernet), as well as of TML messages handling. This includes handling of the specific communication protocol, for each of these channels.

Consequently, each application you'll develop starts with the opening of the communication channel, i.e. calling the **TS_OpenChannel** function. The application must end with the **TS_CloseChannel** function call.

You'll be able to handle multiple-axis applications from the PC. Besides the drive/motor setup with EasySetUp or EasyMotion Studio, you'll also need to indicate some basic drive information for correct usage of the library functions. Thus, for each drive that is installed in the system, you'll need to execute the **TS_SetupAxis** function, indicating the axis ID and configuration setup. Such information will be used for some functions of the library, in order to check if there are incompatibilities between the drive and the operation to be executed (as an example, avoiding issuing an "Output port" command to a port which is an input port on that drive).

Note that besides setting-up individual axes, it is also possible to setup groups of axes (with the **TS_SetupGroup** function). This allows you to issue commands which will be received and executed simultaneously on all the axes initialized as belonging to that group.

Once all the axes are defined, the library allows you to select the active axis or group, using the **TS_SelectAxis**, or **TS_SelectGroup** function respectively. Consequently, all future commands that you'll execute after the selection of one axis or group will be addressed to that axis or group. You can change at any time in your program the active axis/group. Also, a command can be sent to all the axes from the network, by selecting the destination with the **TS_SelectBroadcast** function.

3.2. Internal units and scaling factors

Technosoft drives/motors operate with parameters and variables represented in drive internal units (IU). The parameters and variables represent various signals: position, speed, current, voltage, etc. Each type of signal has its own internal representation in IU and a specific scaling factor. The scaling factor of each internal unit shows the correspondence with the international standard units (SI). The scaling factors are dependent on the product, motor and sensor type. Put in other words, the scaling factors depend on the drive/motor setup configuration.

To determine the internal units and the scaling factors for a specific configuration, use:

- **Help | Help Topics | Setup Data Management | Internal Units and Scaling Factors** menu command in EasySetUp

- **Help | Help Topics | Application Programming | Internal Units and Scaling Factors** menu command in EasyMotion Studio

Important: The **Internal Units and Scaling Factors** topic provides customized information, function of the application setup. If the drive, the motor technology or the feedback device is changed, the scaling factors should be checked again. It may show other relations!

3.3. Axis Identification

The data exchanged on the communication channel is done using messages. Each message contains one TML instruction to be executed by the receiver of the message. Apart from the binary code of the TML instruction attached, any message includes information about its destination: an axis (drive/motor) or a group of axes. Each drive/motor has its own 8-bit Axis ID and Group ID. This information is stored in TML variable **AAR**.

Remarks:

3. The Axis ID of a drive/motor must be **unique** and it is set during the drive/motor setup phase with **EasySetUp/EasyMotion Studio**. The possible values for Axis ID are between 1 and 255.
4. The Axis ID range for TechnoCAN communication protocol is between 1 and 31. Higher values for the Axis ID, set with EasySetUp/EasyMotion Studio, with are interpreted as modulo 32.
5. Use TS_GetIntVariable to read the value of the Axis ID and Group ID from the AAR (uint@0x030C) TML variable.

The Group ID represents a way to access a group of axes, for a multicast transmission. This feature allows sending a command simultaneously to several axes, for example to start or stop the axes motion in the same time. When a function block sends a command to a group, all the axes members of this group will receive the command. For example, if the axis is member of group 1 and group 3, it will receive all the messages that in the group ID include group 1 and group 3.

Each axis can be programmed to be member of one or several of the 8 possible groups.

Table 1. Definition of the groups

Group No.	Group ID value
1	1 (0000 0001b)
2	2 (0000 0010b)
3	4 (0000 0100b)
4	8 (0000 1000b)
5	16 (0001 0000b)
6	32 (0010 0000b)
7	64 (0100 0000b)
8	128 (1000 0000b)

Remarks:

1. A drive/motor belongs, by default, to the group 1 (group ID = 1).
2. The TechnoCAN protocol supports up to 5 groups, possible Group ID values: 1 to 5

3.4. Multithread and multiprocess applications with TML_Lib

The TML_LIB library supports multithread applications developed under C/C++ and Delphi. Each thread created in your application has to setup the communication, the axes and program the motion commands. For details about threads see the documentation of your programming language.

Remarks:

1. For multithread applications created for Microsoft Windows, under Visual C++, the communication module of TML_LIB library, the **tmlcomm.dll**, must be dynamically linked at **load-time**.
2. The examples included in the package use the single thread variant of the library with the exception of Ex08_PVT. The example Ex08_PVT is available only for C/C++ and Delphi.
3. Applications developed under Visual Basic **must** use the single thread variant of the TML_lib.

The following example presents the basic steps for creating a multithread application using C run-time library and the Win32 API:

1. Include the header **<windows.h>** for all the Win32 specific thread information
2. Define an array of handles and an array of thread id's.
3. Declare structures for passing to the controlling functions of each thread (define here the parameters you might be interested on).
4. Define global pointers to the structures required.
5. Declare the control functions for each thread. In Win32, thread functions **MUST** be declared like this:
DWORD WINAPI <name>(LPVOID)
6. In the main body of your application call the function to create and start thread (in our example **CreateThread** function that actually creates and begins the execution of the thread). See the documentation of your development environment for more details.
7. Wait until all threads are done. Use **WaitForMultipleObjects** function. Read the help associated to the API call "WaitForMultipleObjects".
8. Close the handles of the threads with the function: **CloseHandle**.

These steps were followed to create **Ex08_PVT** example. The example commands two Technosoft drives/motors to execute a 2-D motion profile described by a sequence of linear and circular segments. The application uses separated threads for each axis, in which computes the necessary commands for the associated drive. The application requires the multithread variant of the TML_lib, installed by default in the "C:\Program Files\Technosoft\TML_LIB\lib-multithread" folder.

Depending on the communication channel used, the TML_LIB can share the communication resources enabling you to build multiprocess application. The communication devices suited for multiprocess applications are the RS232 and the CAN interfaces:

- from the Electronic System Design (ESD) – under Linux and Microsoft Windows
- from Peak System – under Linux

3.5. Description of functions

The section presents the functions implemented in the **TML_LIB** library. The functions are classified as follows:

- **Communication setup** – functions that manage the PC communication channel
- **Drive setup** – functions for axis setup in the PC application
- **Drive administration** – functions that control the destination axis of the messages sent from the host
- **Drive/motor monitoring** – functions for monitoring the drive/motor status
- **Error handling** – functions for FAULT state reset and drive reset
- **Motion programming** – functions for motion programming on the selected axis.
- **Motor commands** – functions to enable/disable the motor power stage, start/stop the motion, change the value of the motor position and current
- **Events** – functions for events programming and test
- **TML jumps and function calls** – functions which allows you to execute code downloaded in the drive/motor memory
- **I/O handling** – functions for read/write operations with drive/motor I/O ports
- **Data transfer** – functions for read/write operations from/to the drive/motor memory
- **Miscellaneous** – functions to send individual TML commands and to view the binary code of a TML command
- **Data logger** – functions for logger setup and data upload

For each function you will find the following information:

- The C prototype
- Description of the arguments
- A functional description
- Name of related functions
- Examples references. The examples are listed in **chapter 4**.

3.5.1. Communication setup

3.5.1.1. TS_OpenChannel

Prototype:

```
INT TML_EXPORT TS_OpenChannel(LPCSTR pszDevName, BYTE btType, BYTE nHostID, DWORD baudrate);
```

Arguments:

Name	I/O	Description
pszDevName	Input	The communication channel to be opened
btType		The type of the communication channel and the CAN-bus communication protocol
nHostID		Axis ID for the PC
baudrate		Communication baud rate
Return	Output	The file descriptor of the or -1 if error

Description: The function opens the communication channel specified with parameter **pszDevName**.

The **btType** parameter specifies the communication channel type and the CAN-bus communication protocol used by the application. **btType = ChannelType | ProtocolType**.

The TML_LIB supports the following types of communication channels:

- serial RS-232
 - **ChannelType = CHANNEL_RS232** for PC serial port
 - **ChannelType = CHANNEL_VIRTUAL_SERIAL** for communication through a user implemented serial driver. To properly interface the serial driver with the tmlcomm.dll, the user must follow the next steps:
 - a. initialize the communication channel with the serial settings implemented on the Technosoft drives/motors: 8 data bits, 2 stop bits, no parity, no flow control and one of the following baud rates: 9600 (default after reset), 19200, 38400, 56600 and 115200.
 - b. Implement the functions for interfacing the custom communication driver with the tmlcomm.dll. See the virtRS232.cpp file from the **VCvirtRS232** example project.
 - c. Export the functions from the communication driver using a module-definition (.DEF) file. See the virtRS232.def file from the **VCvirtRS232** example project.
- CAN-bus devices supported by TML_LIB for Microsoft Windows
 - **ChannelType = CHANNEL_IXXAT_CAN** for **IXXAT** PC to CAN interface
 - **ChannelType = CHANNEL_SYS_TEC_USBCAN** for **Sys Tec** USB to CAN interface
 - **ChannelType = CHANNEL_ESD_CAN** for **ESD** CAN interfaces
 - **ChannelType = CHANNEL_LAWICEL_USBCAN** for **Lawicel** CAN interface
 - **ChannelType = CHANNEL_PEAk_SYS_PCAN_PCI** for **PEAK System** PC-PCI to CAN interface
 - **ChannelType = CHANNEL_PEAk_SYS_PCAN_ISA** for **PEAK System** PCAN-ISA
 - **ChannelType = CHANNEL_PEAk_SYS_PCAN_PC104** for **PEAK System** PC/104

- **ChannelType** = **CHANNEL_PEAk_SYS_PcAN_USB** for **PEAK System** USB to CAN interface
 - **ChannelType** = **CHANNEL_PEAk_SYS_PcAN_DONGLE** for **PEAK System** Dongle interfaces
 - **ChannelType** = **CHANNEL_KVASER_USBCAN** for **KVASER** USB to CAN interface
- CAN-bus devices supported by TML_LIB for Linux
 - **ChannelType** = **CHANNEL_IXXAT_CAN** for IXXAT CAN interfaces supported by the Basic CAN interface from IXXAT
 - **ChannelType** = **CHANNEL_ESD_CAN** for ESD CAN interfaces
 - **ChannelType** = **CHANNEL_PEAk_SYS_PcAN_ISA** for **PEAK System** PCAN-ISA
 - **ChannelType** = **CHANNEL_PEAk_SYS_PcAN_PC104** for **PEAK System** PC/104
 - **ChannelType** = **CHANNEL_PEAk_SYS_USB** for **PEAK System** USB interface
 - **ChannelType** = **CHANNEL_PEAk_SYS_PCI** for **PEAK System** PCI interface
 - **ChannelType** = **CHANNEL_SOCKET_CAN** for SocketCAN compatible interfaces

Remarks:

1. The drivers for Peak System interface must be installed with **NO_NDEV_SUPPORT** option. The **cat /proc/pcan** command can be used to check if the NDEV support is disabled.

```
root@eg-blujdea-Ubuntu:~/Desktop/Ex01_StartUp# cat /proc/pcan
*----- PEAK-System CAN interfaces (www.peak-system.com) -----
*----- Release 20150729 n (7.15.2) Oct 31 2016 13:35:34 -----
*----- [mod] [isa] [pci] [pec] [dng] [par] [usb] [pcc] -----
*----- 1 interfaces @ major 245 found -----
*n -type- -ndev- --base-- irq --btr- --read-- --write- --irqs-- -errors- status
0      pci  -NA- fdcfe000 020 0x0014 00000007 00000007 00000033 00000007 0x0000
```

- Ethernet¹
 - **ChannelType** = **CHANNEL_XPORT_IP** for Technosoft Ethernet to RS232 adapter
 - **ChannelType** = **CHANNEL_ETHERNET_CAN** for Technosoft Ethernet to CAN adapter

The CAN-bus communication protocols supported by the TML_LIB are:

- **ProtocolType** = **PROTOCOL_TMLCAN** – 29-bit CAN identifier
- **ProtocolType** = **PROTOCOL_TECHNOCAN** – 11-bit CAN identifier

Remarks:

1. By default, the TML_LIB uses the TMLCAN communication protocol, thus if the drive/ motor supports only TMLCAN protocol then the **btType** = **ChannelType**.
2. The specification of CAN-bus protocol is required when the PC is connected directly to the CAN-bus through a PC to CAN interface or in the cases when the drive/motor connected to the PC via RS232/Ethernet acts as a retransmission relay between the PC and the CAN-bus network. More details about the retransmission relay concept can be found in EasyMotion Studio on line help.

Depending on the communication channel type, the parameter **pszDevName** can be:

- For serial communication:
 - 'COM1', 'COM2', 'COM3'.... for Microsoft Windows version
 - '/dev/ttyS0', '/dev/ttyS1', '/dev/ttyUSB0' for Linux version
- For virtual serial interface is the name of the dll file that implements the serial interface
- For CAN-bus communication:
 - '1', '2', '3'... for Microsoft Windows version
 - '/dev/pcan0', '/dev/pcan8' for Linux version
- For Ethernet communication is the IP address of the Ethernet to RS232/CAN bridge: '192.168.19.52', ...

The **nHostID** parameter represents the Axis ID of the PC in the system. The value of **nHostId** is set as follows:

¹ Supported only in the TML_LIB for Microsoft Windows

- For serial RS-232 the **nHostID** is equal with the axis ID of the drive connected to the PC serial port
- For Ethernet to RS232 adapter the **nHostID** is equal with the axis ID of the drive connected to the serial port of the Ethernet adapter.
- For Ethernet to CAN adapter the **nHostID** is equal with the axis ID assigned to the Ethernet to CAN adapter via the Ethernet-CAN Adapter Configurator tool included in EasyMotion Studio package.

The communication speed is set with the **BaudRate** parameter. The accepted values are:

- For serial communication and Ethernet to RS232: 9600, 19200, 38400, 56000 or 115200 bps.
- For CAN-bus and Ethernet to CAN: 125000, 250000, 500000, 1000000 bps

Remark: *You can open several communication channels but only one can be active in an application at one moment. You can switch between the communication channels with function `TS_SelectChannel`.*

Related functions: `TS_CloseChannel`, `TS_SelectChannel`

Associated examples: all

3.5.1.2. TS_SelectChannel

Prototype:

BOOL TML_EXPORT TS_SelectChannel(INT fd);

Arguments:

Name	I/O	Description
fd	Input	The communication channel file descriptor
Return	Output	TRUE if no error, FALSE if error

Description: The function selects as active the communication channel described by parameter **fd**. All commands send towards the drives/motors will use the selected communication channel.

Remarks:

1. Use function *TS_OpenChannel* to open the communication channels
2. The function *TS_SelectChannel* is not required in applications with only one communication channel

Related functions: TS_OpenChannel, TS_CloseChannel

Associated examples: –

3.5.1.3. TS_CloseChannel

Prototype:

void TML_EXPORT TS_CloseChannel(INT fd);

Arguments:

Name	I/O	Description
fd	Input	The communication channel file descriptor
-	Output	-

Description: The function closes the communication channel described by parameter **fd**. With **fd = -1** the function closes the channel previously selected with function **TS_SelectChannel**. This function must be called at the end of the application. It will release the communication channel resources, as it was allocated to the program when the **TS_OpenChannel** function was called.

Related functions: TS_OpenChannel, TS_SelectChannel

Associated examples: all

3.5.2. Drive setup

3.5.2.1. TS_LoadSetup

Prototype:

INT TML_EXPORT TS_LoadSetup(LPCSTR setupDirectory);

Arguments:

Name	I/O	Description
setupDirectory	Input	The setup description file (t.zip) to be loaded in the TML_lib application
Return	Output	The index associated to the setup

Description: The function loads the description of the drive/motor that will be controlled from the PC application. The description of the drive/motor configuration is generated from EasyMotion Studio (Application | Export to TML_lib...) or EasySetUp (Setup | Export to TML_lib...) and stored in a zip file with **t.zip** extension.

The **setupDirectory** string specifies the absolute or relative path of the t.zip file. The function returns an index associated to the configuration setup. The value returned by TS_LoadSetup must be used to associate the configuration setup with the corresponding axis.

Remark: *The function must be called for each drive/motor only once in your program, in the initialization part.*

Related functions: TS_SetupAxis, TS_SetupGroup, TS_SetupBroadcast

Associated examples: all

3.5.2.2. TS_SetupAxis

Prototype:

BOOL TML_EXPORT TS_SetupAxis(BYTE axisID, INT idxSetup);

Arguments:

Name	I/O	Description
axisID	Input	AxisID of the drive/motor
idxSetup		Configuration description index generated by TS_LoadSetup
Return	Output	TRUE if no error, FALSE if error

Description: The function links a configuration description (t.zip file) to an **axisID** address. The configuration description is identified through **idxSetup**.

The function must be called for each axis of the motion system, only once in your program, in the initialization part, before any attempt to send messages to that axis.

Remarks:

1. The **axisID** address must be identical with the value set for the drive/motor in Drive Setup dialog from EasySetUp or EasyMotion Studio.
2. Use function TS_LoadSetup to load the configuration description files (t.zip) for each axis and generate the index.

Related functions: TS_LoadSetup, TS_SetupGroup, TS_SetupBroadcast

Associated examples: all

3.5.2.3. TS_SetupGroup

Prototype:

BOOL TML_EXPORT TS_SetupGroup(BYTE groupID, INT idxSetup);

Arguments:

Name	I/O	Description
groupID	Input	Group ID number. It must be a value between 1 and 8
idxSetup		Name of the data file storing the setup axis information
Return	Output	TRUE if no error, FALSE if error

Description: The function links a configuration description (t.zip file) to an **axisID** address. The configuration description is identified through **idxSetup**.

The function must be called for each axis of the motion system, only once in your program, in the initialization part, before any attempt to send messages to that axis.

Remarks:

1. The **axisID** address must be identical with the value set for the drive/motor in Drive Setup dialog from EasySetUp or EasyMotion Studio.
2. Use function *TS_LoadSetup* to load the configuration description files (t.zip) for each axis and generate the index.

Related functions: TS_LoadSetup, TS_SetupGroup, TS_SetupBroadcast

Associated examples: all

3.5.2.4. TS_SetupBroadcast

Prototype:

BOOL TML_EXPORT TS_SetupBroadcast(INT idxSetup);

Arguments:

Name	I/O	Description
idxSetup	Input	Name of the data file storing the setup axis information
Return	Output	TRUE if no error, FALSE if error

Description: The function sets the configuration description file to be used by TML_LIB when it sends broadcast commands. The configuration setup is identified through **idxSetup**.

Remarks: Use function *TS_LoadSetup* to generate the identifier of the configuration description file.

Related functions: TS_LoadSetup, TS_SetupAxis, TS_SetupGroup

Associated examples: Ex07_MultiAxes

3.5.2.5. TS_DriveInitialisation

Prototype:

BOOL TML_EXPORT TS_DriveInitialisation(void);

Arguments:

Name	I/O	Description
-	Input	-
Return	Output	TRUE if no error, FALSE if error

Description: The function initializes the active axis. It must be executed when the drive/motor is powered or after a reset with function TS_Reset. The function call should be placed after the functions TS_SetupAxis and TS_SelectAxis and before any functions that send messages to the axis.

If the setup table from the active axis is invalid the function will fail and a valid setup table must be downloaded from EasySetUp or EasyMotion Studio. The new setup table becomes active once the drive is reset or power cycled.

Related functions: TS_LoadSetup, TS_SetupAxis, TS_SelectAxis

Associated examples: all

3.5.2.6. TS_Save

Prototype:

BOOL TML_EXPORT TS_Save(void);

Arguments:

Name	I/O	Description
-	Input	-
Return	Output	TRUE if no error, FALSE if error

Description: The function saves the actual values of all the TML parameters with setup data from the active data RAM memory into the non-volatile memory, in the setup table. Through this command, you can save the parameters modifications done after the power on initialization.

Related functions: TS_Reset, TS_Save

Associated examples: –

3.5.2.7. TS_GetMotorPositionScalingFactor

Prototype:

BOOL TML_EXPORT TS_GetMotorPositionScalingFactor (double& scalingFactor);

Arguments:

Name	I/O	Description
scalingFactor		Pointer to the parameter where the scaling factor will be stored
Return	Output	TRUE if no error, FALSE if error

Description: The function returns the load position scaling factor from **motor position internal units** to **rotations**, respectively **mm** in case of linear motors, for the active axis. The scaling factor is stored in the t.zip file generated by EasyMotion Studio.

Related functions:

Associated examples: –

3.5.2.8. TS_GetLoadPositionScalingFactor

Prototype:

BOOL TML_EXPORT TS_GetLoadPositionScalingFactor (double& scalingFactor);

Arguments:

Name	I/O	Description
scalingFactor		Pointer to the parameter where the scaling factor will be stored
Return	Output	TRUE if no error, FALSE if error

Description: The function returns the load position scaling factor from **load position internal units** to **rotations**, respectively **mm** in case of linear loads, for the active axis. The scaling factor is stored in the t.zip file generated by EasyMotion Studio.

Related functions:

Associated examples: –

3.5.2.9. TS_GetCurrentScalingFactor

Prototype:

BOOL TML_EXPORT TS_GetCurrentScalingFactor (double& scalingFactor);

Arguments:

Name	I/O	Description
scalingFactor		Pointer to the parameter where the scaling factor will be stored
Return	Output	TRUE if no error, FALSE if error

Description: The function returns the current scaling factor from drive **current internal units** to **A** for the active axis. The scaling factor is stored in the t.zip file generated by EasyMotion Studio.

Related functions:

Associated examples: –

3.5.2.10. TS_GetTimeScalingFactor

Prototype:

BOOL TML_EXPORT TS_GetTimeScalingFactor (double& scalingFactor);

Arguments:

Name	I/O	Description
scalingFactor		Pointer to the parameter where the scaling factor will be stored
Return	Output	TRUE if no error, FALSE if error

Description: The function returns the current scaling factor from drive **time internal units** to **ms** for the active axis. The scaling factor is stored in the t.zip file generated by EasyMotion Studio.

Related functions:

Associated examples: –

3.5.3. Drive administration

3.5.3.1. TS_SelectAxis

Prototype:

BOOL TML_EXPORT TS_SelectAxis(BYTE axisID);

Arguments:

Name	I/O	Description
axisID	Input	The axis ID where the commands are sent
Return	Output	TRUE if no error, FALSE if error

Description: The function selects the currently active axis. All further function calls, which send TML messages over the communication channel, will address the messages to the active axis.

The function can be called once the configuration of the axis is completed (after calling the **TS_SetupAxis** function to link a configuration description file with the **axisID**).

For single axis motion system, the function must be called only once. In case of a multiple axis application, the **TS_SelectAxis** must be called each time you want to redirect the communication to another axis of the system.

Related functions: TS_SelectGroup, TS_SelectBroadcast

Associated examples: all

3.5.3.2. TS_SelectGroup

Prototype:

BOOL TML_EXPORT TS_SelectGroup(BYTE groupID);

Arguments:

Name	I/O	Description
groupID	Input	The group ID where the commands are sent
Return	Output	TRUE if no error, FALSE if error

Description: The function selects the currently active group. All further function calls, which send TML messages over the communication channel, will address these messages to this active group. The active group is set with parameter **groupID**. It must be a value between 1 and 8.

Remark: The function must be called after the group setup i.e. after calling the **TS_SetupGroup** function.

Related functions: TS_SelectAxis, TS_SelectBroadcast

Associated examples: Ex08_PVT

3.5.3.3. TS_SelectBroadcast

Prototype:

BOOL TML_EXPORT TS_SelectBroadcast(void);

Arguments:

Name	I/O	Description
-	Input	-
Return	Output	TRUE if no error, FALSE if error

Description: The function enables TML_LIB to issue the broadcast messages, i.e. all further function calls, which send TML messages on the communication channel, will address these messages to all the axes.

Remark: The function must be called after the broadcast setup i.e. after calling the **TS_SetupBroadcast** function.

Related functions: TS_SelectAxis, TS_SelectGroup

Associated examples: Ex07_MultiAxes

3.5.4. Drive/motor monitoring

3.5.4.1. TS_ReadStatus

Prototype:

BOOL TML_EXPORT TS_ReadStatus(SHORT SelIndex, WORD& Status);

Arguments:

Name	I/O	Description
SelIndex	Input	Registers selection index
Status		Pointer of the variable where the status is saved
Return	Output	TRUE if no error, FALSE if error

Description: The function returns drive/motor status information. Depending on the value of **SelIndex** parameter, you can examine the contents of the Motion Control Register (**SelIndex = REG_MCR**), Motion Status Register (**SelIndex = REG_MSR**), Interrupt Status Register (**SelIndex = REG_ISR**), Status Register Low (**SelIndex = REG_SRL**), Status Register High (**SelIndex = REG_SRH**) or Motion Error Register (**SelIndex = REG_MER**) of the drive/motor.

Related functions: –

Associated examples: Ex02_DriveStatus, Ex03_ErrorHandling, Ex05_Homing

3.5.4.2. TS_GetFirmwareVersion

Prototype:

BOOL TML_EXPORT TS_GetFirmwareVersion (LPSTR szFWVersion);

Arguments:

Name	I/O	Description
szFWVersion	Input	Specifies the char array where the firmware version will be stored
Return	Output	TRUE if no error, FALSE if error

Description: The function requests the firmware version from the active axis. The firmware version is codified with 5 characters. The ASCII code of the characters will be stored in the **szFWVersion** array.

Related functions: –

Associated examples: Ex02_DriveStatus

3.5.4.3. TS_GetApplicationInfo

Prototype:

BOOL TML_EXPORT TS_GetApplicationInfo(LPSTR pszOutput);

Arguments:

Name	I/O	Description
pszOutput	Input	Pointer to a string where Application ID will be saved
Return	Output	TRUE if no error, FALSE if error

Description: The function returns the Application ID string from the configuration description file (*.t.zip) generated with EasyMotion Studio/EasySetUp.

The Application ID string can be set via the Drive Info dialog from Drive Setup. The Application ID string can have up to 30 characters and it can be used to identify the setup/application stored in the non-volatile memory of the drive.

Drive info

Intelligent drive name: iPOS4808 MY-CAN Product ID: P027.414.E101 E2ROM size: 16 Kwords Firmware ID: F514I OK Cancel

Drive data

Power supply (motor) min. value: 11 V max. value: 52 V

Logic supply min. value: 8 V max. value: 40 V

Nominal current: 8 A

Peak current: 20 A

Maximum measurable current: 20 A

Maximum measurable DC voltage: 102.3 V

Analogue inputs range: 5 V

Temperature sensor: ☒ Sensor gain: 0.01 V/°C Output at 0°C: 0.5 V

Protections

☒ Over voltage: Trigger if power supply > 53 V

☒ Under voltage: Trigger if power supply < 8.9997 V

☒ I2t: Support over current: 10 A for 15 s

☒ Drive temperature: Trigger if T > T2max: 105.002 °C

Application ID: A01

Remark:

The Application ID stored in the non-volatile memory of the drive can be retrieved with the TS_GetBuffer function

The "Application ID" is saved in the non-volatile memory of the drive starting with the address 0x7FCF until the address 7FDDh. The address range is automatically adjusted by the firmware if the non-volatile memory is smaller, i.e. the non-volatile memory of the iPOS360x starts at 0x4000 up to 0x4FFF.

Related functions: –

Associated examples: Ex02_DriveStatus

3.5.4.4. TS_GetLibraryVersion

Prototype:

BOOL TML_EXPORT TS_GetLibraryVersion(LPSTR szLibVersion);

Arguments:

Name	I/O	Description
szLibVersion	Input	Specifies the char array where the library version will be stored
Return	Output	TRUE if no error, FALSE if error

Description: The function returns the version number of the TML_lib library. The ASCII codes of the version will be stored in the **szLibVersion** array.

Related functions: –

Associated examples: –

3.5.4.5. TS_SendDataToHost

Prototype:

```
BOOL TML_EXPORT TS_SendDataToHost(BYTE HostAddress, DWORD StatusRegMask WORD ErrorRegMask);
```

Arguments:

Name	I/O	Description
HostAddress	Input	The Axis ID of the host where the messages are sent
StatusRegMask		Specifies the bits from status register that trigger the message
ErrorRegMask		Specifies the bits from error register that trigger the message
Return	Output	TRUE if no error, FALSE if error

Description: The function enables the active axis to send messages automatically to the host. The messages are triggered by the conditions that change the status registers of the drive/motor. The conditions are set through **StatusRegMask** and **ErrorRegMask** arguments. The host Axis ID is set with parameter **HostAddress**.

Table 1 – Description of StatusRegMask

Status Register Low	Bit 7	Homing/CALLS warning
	Bit 8	Homing/CALLS active
	Bit 10	Motion is completed
	Bit 14	Event set has occurred
	Bit 15	Axis is ON
Status Register High	Bit 16	ENDINIT executed
	Bit 17	Over position trigger 1
	Bit 18	Over position trigger 2
	Bit 19	Over position trigger 3
	Bit 20	Over position trigger 4
	Bit 22	LSP event/interrupt
	Bit 23	LSN event/interrupt
	Bit 24	Capture event/interrupt
	Bit 26	I2t warning - Motor
	Bit 27	I2t warning - Drive
	Bit 28	In Gear
	Bit 30	In Cam
	Bit 31	Fault

Table 2 – Description of ErrorRegMask

Motion Error Register	Bit 0	CANbus error
	Bit 1	Short-circuit
	Bit 2	Invalid setup data
	Bit 3	Control error
	Bit 4	Serial comm. Error
	Bit 5	Position wraparound
	Bit 6	LSP (limit +) active
	Bit 7	LSN (limit -) active
	Bit 8	Over current
	Bit 9	I2t
	Bit 10	Over temperature - Motor
	Bit 11	Over temperature - Drive
	Bit 12	Over voltage
	Bit 13	Under voltage
	Bit 14	Command error
	Bit 15	Enable input is valid

Related functions: TS_RegisterHandlerForUnrequestedDriveMessages, TS_CheckForUnrequestedDriveMessages

Associated examples: Ex02_DriveStatus

3.5.4.6. TS_CheckForUnrequestedDriveMessages

Prototype:

BOOL TML_EXPORT TS_CheckForUnrequestedDriveMessages(void);

Arguments:

Name	I/O	Description
-	Input	-
Return	Output	TRUE if no error, FALSE if error

Description: The function checks if there are new unrequested messages received from the drive/motor. If the communication buffer contains an unrequested message, then it calls the user callback function that handles this type of messages. The TS_CheckForUnrequestedDriveMessages function should be called periodically to ensure that the latest information is used in the application.

Related functions: TS_RegisterHandlerForUnrequestedDriveMessages, TS_SendDataToHost

Associated examples: Ex02_DriveStatus

3.5.4.7. TS_RegisterHandlerForUnrequestedDriveMessages

Prototype:

```
void TML_EXPORT TS_RegisterHandlerForUnrequestedDriveMessages(pfnCallbackRecvDriveMsg handler);
```

Arguments:

Name	I/O	Description
pfnCallbackRecvDriveMsg	Input	Pointer to the user callback function
Return	Output	TRUE if no error, FALSE if error

Description: The function registers the callback function defined by the user which will handle the unrequested messages sent by the drive/motor to the host.

Related functions: TS_CheckForUnrequestedDriveMessages, TS_SendDataToHost

Associated examples: Ex02_DriveStatus

3.5.4.8. TS_OnlineChecksum

Prototype:

BOOL TML_EXPORT TS_OnlineChecksum(WORD startAddress, WORD endAddress WORD &checksum);

Arguments:

Name	I/O	Description
startAddress	Input	The memory range start address
endAddress		The memory range end address
checksum		Pointer to the variable where the checksum is stored
Return	Output	TRUE if no error, FALSE if error

Description: The function requests from the active axis the checksum of a memory range. The memory range is defined with parameters **startAddress** and **endAddress**. The function stores the checksum received from the drive in the **checksum** variable.

The TS_OnlineChecksum function can be used to check the integrity of the data saved in the non-volatile or RAM memory of a drive/motor. The memory type is selected automatically function of the **startAddress** and the **endAddress**.

Related functions: TS_SetBuffer

Associated examples: –

3.5.5. Error handling

3.5.5.1. TS_ResetFault

Prototype:

BOOL TML_EXPORT TS_ResetFault(void);

Arguments:

Name	I/O	Description
-	Input	-
Return	Output	TRUE if no error, FALSE if error

Description: The function resets the FAULT state on the active axis. A drive/motor enters in fault state when detects an error. Following the TS_ResetFault execution, most of the errors bits from **Motion Error Register** are cleared (set to 0), the Ready output (if present) is set to the ready level, the Error output (if present) is set to the no error level and the drive/motor is ready to return to normal operation. The power stage of the drive/motor must be re-enabled with the TS_Power function.

Remarks:

- The TS_ResetFault execution does not change the status of:
 - MER.15 (enable input on disabled level),
 - MER.7 (negative limit switch input active),
 - MER.6 (positive limit switch input active) and
 - MER.2 (invalid setup table)
- The drive/motor will return to FAULT status if there are errors when the function is executed

Related functions: TS_Power, TS_ReadStatus

Associated examples: Ex03_ErrorHandling

3.5.5.2. TS_Reset

Prototype:

BOOL TML_EXPORT TS_Reset(void);

Arguments:

Name	I/O	Description
-	Input	-
Return	Output	TRUE if no error, FALSE if error

Description: The function resets the active axis. After reset the drive/motor will load the values of the TML parameters stored in the non-volatile memory downloaded during setup phase. If the AUTORUN mode is enabled on the drive/motor then, after the reset, the TML program stored in the non-volatile memory will be automatically executed (if there is such a program).

Remark: *If during drive/motor operation you have changed the setup parameters and want to use them after the reset, call function TS_Save prior to TS_Reset. The function TS_Save stores the actual values of all TML parameters in the drive's/motor's non-volatile memory.*

Related functions: TS_DriveInitialization, TS_Power, TS_DownloadProgram, TS_GOTO, TS_Save

Associated examples: Ex03_ErrorHandling.

3.5.5.3. TS_GetLastErrorText

Prototype:

LPCSTR TML_EXPORT TS_GetLastErrorText(void);

Arguments:

Name	I/O	Description
-	Input	-
Return	Output	A text related to the last occurred error

Description: The function returns the description of the last error occurred during the execution of a TML_LIB function.

Related functions: –

Associated examples: all

3.5.6. Motion programming

3.5.6.1. TS_MoveAbsolute

Prototype:

BOOL TML_EXPORT TS_MoveAbsolute(LONG AbsPosition, DOUBLE Speed, double Acceleration, SHORT MoveMoment, SHORT ReferenceBase);

Arguments:

Name	I/O	Description
AbsPosition	Input	Position to reached expressed in TML position units
Speed		Slew speed expressed in TML speed units. If the value is zero the drive/motor will use the previously value set for speed
Acceleration		Acceleration/deceleration rate expressed in TML acceleration units. If its value is zero the drive/motor will use the previously value set for acceleration
MoveMoment		Defines the moment when the motion is started
ReferenceBase		Specifies how the motion reference is computed: from actual values of position and speed reference or from actual values of load/motor position and speed
Return	Output	TRUE if no error, FALSE if error

Description: The function programs an absolute positioning with trapezoidal speed profile. The motion is described through **AbsPosition** parameter for position to reach, **Speed** for slew speed and **Acceleration** for acceleration/deceleration rate. The position to reach can be positive or negative. The **Speed** and **Acceleration** can be **only** positive.

Once set, the motion parameters are memorized on the drive/motor. If you intend to use values previously defined for the acceleration rate and/or the velocity you don't need to send their values again in the following trapezoidal profiles. Set to zero the value of speed and/or acceleration and the drive/motor will use the values previously defined (this option reduces the TML code generated by this function).

The motion is executed:

- Immediately when **MoveMoment = UPDATE_IMMEDIATE**
- When a programmed event occurs if **MoveMoment = UPDATE_ON_EVENT**
- If you select **MoveMoment = UPDATE_NONE**, the movement is parameterized, but does not execute. You'll need to issue an update command to determine the execution of the movement. Use the **TS_UpdateImmediate** or the **TS_UpdateOnEvent** functions in order to activate the movement.

Set **ReferenceBase = FROM_REFERENCE** if you want the reference generator to compute the motion profile starting from the actual values of the position and speed reference. Set **ReferenceBase = FROM_MEASURE** if you want the reference generator to compute the motion profile starting from the actual values of the load/motor position and speed. When this option is used, at the beginning of each new motion profile, the position and speed reference are updated with the actual values of the load/motor position and speed.

Remark: *For stepper open loop configurations the ReferenceBase option is ignored because there is no position feedback.*

Related functions: TS_MoveRelative, TS_MoveSCurveAbsolute, TS_MoveSCurveRelative, TS_MoveVelocity.

Associated examples: Ex05_Homing, Ex07_MultiAxes, Ex11_IOHandling

3.5.6.2. TS_MoveRelative

Prototype:

BOOL TML_EXPORT TS_MoveRelative(LONG RelPosition, DOUBLE Speed, DOUBLE Acceleration, BOOL IsAdditive, SHORT MoveMoment, SHORT ReferenceBase);

Arguments:

Name	I/O	Description
RelPosition	Input	Position increment expressed in TML position units
Speed		Slew speed expressed in TML speed units. If the value is zero the drive/motor will use the previously value set for speed
Acceleration		Acceleration/deceleration rate expressed in the TML acceleration units. If its value is zero the drive/motor will use the previously value set for acceleration
IsAdditive		Specifies how is computed the position to reach
MoveMoment		Defines the moment when the motion is started
ReferenceBase		Specifies how the motion reference is computed: from actual values of position and speed reference or from actual values of load/motor position and speed
Return	Output	TRUE if no error, FALSE if error

Description: The function programs a relative positioning with trapezoidal speed profile. The motion is described through **RelPosition** for position increment, **Acceleration** for acceleration/deceleration rate and **Speed** for slew speed. The position increment can be positive or negative; the sign gives the motion direction. The speed and acceleration can be **only** positive.

Once set, the motion parameters are memorized on the drive/motor. If you intend to use values previously defined for the acceleration rate and/or the velocity you don't need to send their values again in the following trapezoidal profiles. Set to zero the value of speed and/or acceleration if you want the drive/motor to use the values previously defined with other commands (this option reduces the TML code generated by this function).

The position to reach can be computed in 2 ways: standard (default) or additive. In standard mode, the position to reach is computed by adding the position increment to the instantaneous position in the moment when the command is executed. In the additive mode, the position to reach is computed by adding the position increment to the previous position to reach, independently of the moment when the command was issued. The additive mode is activated with **IsAdditive = TRUE**.

The motion is executed:

- Immediately when **MoveMoment = UPDATE_IMMEDIATE**
- When a programmed event occurs if **MoveMoment = UPDATE_ON_EVENT**
- If you select **MoveMoment = UPDATE_NONE**, the movement is parameterized, but does not execute. You'll need to issue an update command to determine the execution of the movement. Use the **TS_UpdateImmediate** or the **TS_UpdateOnEvent** functions in order to activate the movement.

Set **ReferenceBase = FROM_REFERENCE** if you want the reference generator to compute the motion profile starting from the actual values of the position and speed reference. Use this option for example if successive

standard relative moves must be executed and the final target position should represent exactly the sum of the individual commands. Set **ReferenceBase = FROM_MEASURE** if you want the reference generator to compute the motion profile starting from the actual values of the load/motor position and speed. When this option is used, at the beginning of each new motion profile, the position and speed reference are updated with the actual values of the load/motor position and speed.

Remark: *For stepper open loop configurations the ReferenceBase option is ignored because there is no position feedback.*

Related functions: TS_MoveAbsolute, TS_MoveSCurveAbsolute, TS_MoveSCurveRelative, TS_MoveVelocity

Associated examples: Ex02_DriveStatus, Ex04_BasicMove, Ex05_Homing, Ex09_Logger,
Ex10_EventHandling, Ex11_IOHandling

3.5.6.3. TS_MoveSCurveAbsolute

Prototype:

BOOL TML_EXPORT TS_MoveSCurveAbsolute(LONG AbsPosition, DOUBLE Speed, DOUBLE Acceleration, LONG JerkTime, SHORT MoveMoment, SHORT DecelerationType);

Arguments:

Name	I/O	Description
AbsPosition	Input	Position to reach expressed in TML position units
Speed		The slew speed expressed in TML speed units.
Acceleration		Acceleration/deceleration rate expressed in TML acceleration units.
JerkTime		Represents the time interval for acceleration to reach the programmed value. It is expressed in TML time units.
MoveMoment		Defines the moment when the motion is started
DecelerationType		Specifies the speed profile used when the motion is stopped with TS_Stop
Return	Output	TRUE if no error, FALSE if error

Description: The function block programs an absolute positioning with an S-curve shape of the speed. This shape is due to the jerk limitation, leading to a trapezoidal or triangular profile for the acceleration and an S-curve profile for the speed. The motion is described through **AbsPosition** parameter for position to reach, **Speed** for slew speed, **Acceleration** for acceleration/deceleration rate and **JerkTime**. The position to reach can be positive or negative. The **Speed**, **Acceleration** and **JerkTime** can be **only** positive.

An S-curve profile must begin when load/motor is not moving. During motion the parameters should not be changed. Therefore, when executing successive S-curve commands, you should wait for the previous motion to end before setting the new motion parameters and starting next motion.

When the motion is stopped with function TS_Stop, the deceleration phase can be done in 2 ways:

- Smooth, using an S-curve speed profile, when **DecelerationType = S_CURVE_SPEED_PROFILE**
- Fast, using a trapezoidal speed profile, when **DecelerationType = TRAPEZOIDAL_SPEED_PROFILE**

The motion can be executed:

- Immediately when **MoveMoment = UPDATE_IMMEDIATE**
- When a programmed event occurs if **MoveMoment = UPDATE_ON_EVENT**
- If you select **MoveMoment = UPDATE_NONE**, the movement is parameterized, but does not execute. You'll need to issue an update command to determine the execution of the movement. Use the **TS_UpdateImmediate** or the **TS_UpdateOnEvent** functions in order to activate the movement.

Related functions: TS_MoveAbsolute, TS_MoveRelative, TS_MoveSCurveRelative TS_MoveVelocity, TS_QuickStopDecelerationRate

Associated examples: Ex04_BasicMove

3.5.6.4. TS_MoveSCurveRelative

Prototype:

BOOL TML_EXPORT TS_MoveSCurveRelative (LONG AbsPosition, DOUBLE Speed, DOUBLE Acceleration, LONG JerkTime, SHORT MoveMoment, SHORT DecelerationType);

Arguments:

Name	I/O	Description
RelPosition	Input	Position increment expressed in TML position units
Speed		The slow speed expressed in TML speed units.
Acceleration		Acceleration/deceleration rate expressed in TML acceleration units.
JerkTime		Represents the time interval for acceleration to reach the programmed value. It is expressed in TML time units.
MoveMoment		Defines the moment when the motion is started
DecelerationType		Specifies the speed profile used when the motion is stopped with TS_Stop
Return	Output	TRUE if no error, FALSE if error

Description: The function block programs a relative positioning with an S-curve shape of the speed. This shape is due to the jerk limitation, leading to a trapezoidal or triangular profile for the acceleration and an S-curve profile for the speed. The motion is described through **RelPosition** parameter for position increment, **Speed** for slow speed, **Acceleration** for acceleration/deceleration rate and **JerkTime**. The position to reach can be positive or negative. The **Speed**, **Acceleration** and **JerkTime** can be **only** positive.

An S-curve profile must begin when load/motor is not moving. During motion the parameters should not be changed. Therefore, when executing successive S-curve commands, you should wait for the previous motion to end before setting the new motion parameters and starting next motion.

When the motion is stopped with function TS_Stop, the deceleration phase can be done in 2 ways:

- Smooth, using an S-curve speed profile, when **DecelerationType = S_CURVE_SPEED_PROFILE**
- Fast, using a trapezoidal speed profile, when **DecelerationType = TRAPEZOIDAL_SPEED_PROFILE**

The motion can be executed:

- Immediately when **MoveMoment = UPDATE_IMMEDIATE**
- When a programmed event occurs if **MoveMoment = UPDATE_ON_EVENT**
- If you select **MoveMoment = UPDATE_NONE**, the movement is parameterized, but does not execute. You'll need to issue an update command to determine the execution of the movement. Use the **TS_UpdateImmediate** or the **TS_UpdateOnEvent** functions in order to activate the movement.

Related functions: TS_MoveAbsolute, TS_MoveRelative, TS_MoveSCurveAbsolute TS_MoveVelocity

Associated examples: Ex04_BasicMove

3.5.6.5. TS_MoveVelocity

Prototype:

BOOL TML_EXPORT TS_MoveVelocity(DOUBLE Speed, DOUBLE Acceleration, SHORT MoveMoment, SHORT ReferenceBase);

Arguments:

Name	I/O	Description
Speed	Input	Jog speed expressed in TML speed units
Acceleration		Acceleration rate expressed in TML acceleration units. If the value is zero the drive/motor will use the previously value set for acceleration.
MoveMoment		Defines the moment when the motion is started
ReferenceBase		Specifies how the motion reference is computed: from actual values of position and speed reference or from actual values of load/motor position and speed
Return	Output	TRUE if no error, FALSE if error

Description: The function programs a trapezoidal speed profile. You specify the jog **Speed**. The load/motor accelerates until the jog speed is reached. The jog speed can be positive or negative; the sign gives the direction. The **Acceleration** can be **only** positive.

Once set, the motion parameters are memorized on the drive/motor. If you intend to use values previously defined for the acceleration rate you don't need to send its value again in the following speed profiles. Set to zero the value of acceleration if you want the drive/motor to use the value previously defined with other commands (this option reduces the TML code generated by this function).

The motion is executed:

- Immediately when **MoveMoment = UPDATE_IMMEDIATE**
- When a programmed event occurs if **MoveMoment = UPDATE_ON_EVENT**
- If you select **MoveMoment = UPDATE_NONE**, the movement is parameterized, but does not execute. You'll need to issue an update command to determine the execution of the movement. Use the **TS_UpdateImmediate** or the **TS_UpdateOnEvent** functions in order to activate the movement.

Set **ReferenceBase = FROM_REFERENCE** if you want the reference generator to compute the motion profile starting from the actual values of the position and speed reference. Use this option for example if successive standard relative moves must be executed and the final target position should represent exactly the sum of the individual commands. Set **ReferenceBase = FROM_MEASURE** if you want the reference generator to compute the motion profile starting from the actual values of the load/motor position and speed. When this option is used, at the beginning of each new motion profile, the position and speed reference are updated with the actual values of the load/motor position and speed.

Related functions: TS_MoveRelative, TS_MoveAbsolute, TS_MoveSCurveAbsolute, TS_MoveSCurveRelative

Associated examples: Ex04_BasicMove, Ex06_ExternalReference, Ex07_MultiAxes, Ex10_EventHandling, Ex11_IOHandling

3.5.6.6. TS_SetAnalogueMoveExternal

Prototype:

BOOL TML_EXPORT TS_SetAnalogueMoveExternal(SHORT ReferenceType, BOOL UpdateFast, DOUBLE LimitVariation, SHORT MoveMoment);

Arguments:

Name	I/O	Description
ReferenceType	Input	Specifies how the analogue signal is interpreted
UpdateFast		Specifies how often the analogue reference is read when torque control is performed
LimitVariation		Speed/acceleration limit value for position/speed control expressed in TML internal units
MoveMoment		Defines the moment when the motion is started
Return	Output	TRUE if no error, FALSE if error

Description: The function block programs the drive/motor to work with an external analogue reference read via a dedicated analogue input (10-bit resolution). The analogue signal can be interpreted as a position, speed or torque analogue reference. Through parameter **ReferenceType** you specify how the analogue signal is interpreted:

- Position reference when **ReferenceType = REFERENCE_POSITION**. The drive/motor performs position control.
- Speed reference when **ReferenceType = REFERENCE_SPEED**. The drive/motor performs speed control.
- Torque reference when **ReferenceType = REFERENCE_TORQUE**. The drive/motor performs torque control.

Remark: During the drive/motor setup, in the **Drive setup** dialogue, you have to:

1. Select the appropriate control type for your application at Control Mode.
2. Perform the tuning of controllers associated with the selected control mode.
3. Setup the analogue reference. You specify the reference values corresponding to the upper and lower limits of the analogue input. In addition, a dead-band symmetrical interval and its center point inside the analogue input range may be defined.

In position control you can limit the maximum speed at sudden changes of the position reference and thus to reduce the mechanical shocks. In speed control you can limit the maximum acceleration at sudden changes of the speed reference and thus to get a smoother transition. These features are activated by setting the **LimitVariation** parameter to a positive value and disabled when the **LimitVariation** is zero.

In torque control you can choose how often to read the analogue input: at each slow loop sampling period (**UpdateFast = TRUE**) or at each fast loop sampling period (**UpdateFast = FALSE**).

The motion is executed:

- Immediately when **MoveMoment = UPDATE_IMMEDIATE**
- When a programmed event occurs if **MoveMoment = UPDATE_ON_EVENT**
- If you select **MoveMoment = UPDATE_NONE**, the motion parameters are set, but does not execute. You'll need to issue an update command to determine the execution of the movement. Use the **TS_UpdateImmediate** or the **TS_UpdateOnEvent** functions in order to activate the movement.

Related functions: TS_SetDigitalMoveExternal, TS_SetOnlineMoveExternal

Associated examples: Ex06_ExternalReference

3.5.6.7. TS_SetDigitalMoveExternal

Prototype:

BOOL TML_EXPORT TS_SetDigitalMoveExternal(BOOL SetGearRatio, SHORT Denominator, SHORT Numerator, DOUBLE LimitVariation, SHORT MoveMoment);

Arguments:

Name	I/O	Description
SetGearRatio	Input	Specifies if the digital reference is followed by the drive with a gear ratio
Denominator		Gear ratio denominator
Numerator		Gear ratio numerator
LimitVariation		Acceleration limit value
MoveMoment		Defines the moment when the motion is started
Return	Output	TRUE if no error, FALSE if error

Description: The function block programs the drive/motor to work with an external digital reference provided as pulse & direction or quadrature encoder signals. In either case, the drive/motor performs a position control with the reference computed from the external signals.

Remarks: *The option for the input signals: pulse & direction or quadrature encoder is established during the drive/motor setup.*

The drive/motor follows the external reference with a gear ratio different than 1:1 when **SetGearRatio = TRUE**. The gear ratio is specified as a ratio of 2 integer values: **Numerator** / **Denominator**. The **Numerator** value is signed, while the **Denominator** is unsigned. The sign indicates the direction of movement: positive – same as the external reference, negative – reversed to the external reference.

You can limit the maximum acceleration at sudden changes of the external reference and thus to get a smoother transition. This feature is activated when the parameter **LimitValue** has a positive value and disabled when its value is zero.

The motion is executed:

- Immediately when **MoveMoment = UPDATE_IMMEDIATE**
- When a programmed event occurs if **MoveMoment = UPDATE_ON_EVENT**
- If you select **MoveMoment = UPDATE_NONE**, the motion parameters are set, but the motion is not activated. You'll need to issue an update command to determine the execution of the movement. Use the **TS_UpdateImmediate** or the **TS_UpdateOnEvent** functions in order to activate the movement.

Related functions: TS_SetAnalogueMoveExternal, TS_SetOnlineMoveExternal

Associated examples: Ex06_ExternalReference

3.5.6.8. TS_SetOnlineMoveExternal

Prototype:

BOOL TML_EXPORT TS_SetOnlineMoveExternal(SHORT ReferenceType, DOUBLE LimitVariation, DOUBLE InitialValue, SHORT MoveMoment);

Arguments:

Name	I/O	Description
ReferenceType	Input	Specifies how the analogue signal is interpreted
LimitVariation		Speed/acceleration limit value for position/speed control expressed in TML internal units
InitialValue		The initial value of the reference received on-line
MoveMoment		Defines the moment when the motion is started
Return	Output	TRUE if no error, FALSE if error

Description: The function programs the drive/motor to work with a reference received via a communication channel from an external device. Depending on the control mode chosen, the external reference is saved in one of the TML variables:

- **EREFP**, which becomes the position reference if the **ReferenceType = REFERENCE_POSITION**
- **EREFS**, which becomes the speed reference if the **ReferenceType = REFERENCE_SPEED**
- **EREFT**, which becomes the torque reference if the **ReferenceType = REFERENCE_TORQUE**
- **EREFV**, which becomes voltage reference if the **ReferenceType = REFERENCE_VOLTAGE**

Remark: During the drive/motor setup, in the **Drive setup** dialogue, you have to:

1. Select the appropriate control type for your application in **Drive Setup** dialogue.
2. Perform the tuning of controllers associated with the selected control mode.

In position control you can limit the maximum speed at sudden changes of the position reference and thus to reduce the mechanical shocks. In speed control you can limit the maximum acceleration at sudden changes of the speed reference and thus to get a smoother transition. These features are activated by setting the **LimitVariation** parameter to a positive value and disabled when the **LimitVariation** is zero.

The motion is executed:

- Immediately when **MoveMoment = UPDATE_IMMEDIATE**
- When a programmed event occurs if **MoveMoment = UPDATE_ON_EVENT**
- If you select **MoveMoment = UPDATE_NONE**, the movement is parameterized, but does not execute. You'll need to issue an update command to determine the execution of the movement. Use the **TS_UpdateImmediate** or the **TS_UpdateOnEvent** functions in order to activate the movement.

If the external device starts sending the reference AFTER the motion mode is activated, it may be necessary to initialize EREFP, EREFS, EREFT or EREFV. The desired starting value is set through **InitialValue** parameter.

Related functions: TS_SetAnalogueMoveExternal, TS_SetDigitalMoveExternal

Associated examples: Ex06_ExternalReference

3.5.6.9. TS_VoltageTestMode

Prototype:

BOOL TML_EXPORT TS_VoltageTestMode(SHORT MaxVoltage, SHORT IncrVoltage, SHORT Theta0, SHORT Dtheta, SHORT MoveMoment);

Arguments:

Name	I/O	Description
MaxVoltage	Input	Maximum test voltage expressed in TML voltage command units
IncrVoltage		Voltage increment expressed in TML internal units
Theta0		Initial value of electrical angle expressed in TML electrical angle units
Dtheta		Electric angle increment expressed in TML electrical angle increment units
MoveMoment		Defines the moment when the motion is started
Return	Output	TRUE if no error, FALSE if error

Description: The function allows you to set the drives/motors in voltage test mode. In the test mode a saturated ramp voltage is applied to the motor, i.e. the voltage will increase with the **IncrVoltage** increment at each slow sampling period up to the **MaxVoltage** value.

Remark: *This is a test mode to be used only in some special cases for drives setup. The test mode is not supposed to be used during normal operation*

For AC motors (like for example the brushless motors), you have the possibility to rotate a voltage reference vector with a programmable speed. As a result, these motors can be moved in an “open-loop” mode without using the position sensor. The main advantage of this test mode is the possibility to conduct in a safe way a series of tests, which can offer important information about the motor parameters, drive status and the integrity of the its connections.

The voltage reference vector initial position is set through parameter **Theta0** and its speed through **Dtheta**. For DC motors set these parameters to zero.

The motion is executed:

- Immediately when **MoveMoment** = **UPDATE_IMMEDIATE**
- When a programmed event occurs if **MoveMoment** = **UPDATE_ON_EVENT**
- If you select **MoveMoment** = **UPDATE_NONE**, the movement is parameterized, but does not execute. You'll need to issue an update command to determine the execution of the movement. Use the **TS_UpdateImmediate** or the **TS_UpdateOnEvent** functions in order to activate the movement.

Related functions: TS_TorqueTestMode

Associated examples: –

3.5.6.10. TS_TorqueTestMode

Prototype:

BOOL TML_EXPORT TS_TorqueTestMode(SHORT MaxTorque, SHORT IncrTorque, SHORT Theta0, SHORT Dtheta, SHORT MoveMoment);

Arguments:

Name	I/O	Description
MaxTorque	Input	Maximum test torque expressed in TML current units
IncrTorque		Torque increment expressed in TML internal units
Theta0		Initial value of electrical angle expressed in TML electrical angle units
Dtheta		Electric angle increment expressed in TML electrical angle increment units
MoveMoment		Defines the moment when the motion is started
Return	Output	TRUE if no error, FALSE if error

Description: The function allows you to set the drives/motors in torque test mode. In the test mode a saturated ramp current is applied to the motor, i.e. the current will increase with the **IncrTorque** increment at each slow sampling period up to the **MaxTorque** value.

Remark: *This is a test mode to be used only in some special cases for drives setup. The test mode is not supposed to be used during normal operation*

For AC motors (like for example the brushless motors), you have the possibility to rotate a current reference vector with a programmable speed. As a result, these motors can be moved in an “open-loop” mode without using the position sensor. The main advantage of this test mode is the possibility to conduct in a safe way a series of tests, which can offer important information about the motor parameters, drive status and the integrity of the its connections.

The current reference vector initial position is set through parameter **Theta0** and its speed through **Dtheta**. For DC motors set these parameters to zero.

The motion is executed:

- Immediately when **MoveMoment = UPDATE_IMMEDIATE**
- When a programmed event occurs if **MoveMoment = UPDATE_ON_EVENT**
- If you select **MoveMoment = UPDATE_NONE**, the movement is parameterized, but does not execute. You'll need to issue an update command to determine the execution of the movement. Use the **TS_UpdateImmediate** or the **TS_UpdateOnEvent** functions in order to activate the movement.

Related functions: TS_VoltageTestMode

Associated examples: –

3.5.6.11. TS_PVTSetup

Prototype:

BOOL TML_EXPORT TS_PVTSetup(SHORT ClearBuffer, SHORT IntegrityChecking, SHORT ChangePVTCounter, SHORT AbsolutePositionSource, SHORT ChangeLowLevel, SHORT PVTCounterValue, SHORT LowLevelValue);

Arguments:

Name	I/O	Description
ClearBuffer	Input	Specifies if the PVT buffer is cleared
IntegrityChecking		Enable/disable PVT counter integrity checking
ChangePVTCounter		Specifies if the integrity counter is updated with the value of PVTCounterValue parameter
AbsolutePositionSource		Selects the source for initial position for absolute PVT mode
ChangeLowLevel		Specifies if the level for BufferLow signaling is updated with the value of LowLevelValue parameter
PVTCounterValue		The new value for the drive/motor PVT integrity counter
LowLevelValue		The new value for the level of the BufferLow signal
Return	Output	TRUE if no error, FALSE if error

Description: The function programs a drive/motor to work in PVT motion mode. In PVT motion mode the drive/motor performs a positioning path described through a series of points. Each point specifies the desired **Position**, **Velocity** and **Time**, i.e. contains a PVT data. Between the points the built-in reference generator performs a 3rd order interpolation.

Remark: The function block just programs the drive/motor for PVT mode. The motion mode is activated with function *TS_SendPVTFirstPoint* and the PVT points are sent to the drive with function *TS_SendPVTPoint*.

A key factor for getting a correct positioning path in PVT mode is to set correctly the distance in time between the points. Typically, this is 10-20ms, the shorter the better. If the distance in time between the PVT points is too big, the 3rd order interpolation may lead to important variations compared with the desired path.

The PVT motion mode can be started only when the previous motion is complete. However, you can switch at any moment to another motion mode.

The PVT mode can be relative or absolute. In the absolute mode, each PVT point specifies the position to reach. The initial position may be either the current position reference TML variable TPOS (**AbsolutePositionSource = TRUE**) or a preset value read from the TML parameter PVTPOS0 (**AbsolutePositionSource = FALSE**). In the relative mode, each PVT point specifies the position increment relative to the previous point. In both cases, the time is relative to the previous point i.e. represents the duration of a PVT segment. For the first PVT point, the time is measured from the starting of the PVT mode.

Remark: The PVT mode, absolute or relative, is set with function *TS_SendPVTFirstPoint*.

Each time when the drive receives a new PVT point, it is saved into the PVT buffer. The reference generator empties the buffer as the PVT points are executed. The PVT buffer is of type FIFO (first in, first out). The default length of the PVT buffer is 7 PVT points. Each entry in the buffer is made up of 9 words, so the default length of the PVT buffer in terms of how much memory space is reserved is 63 (3Fh) words. The drive/motor automatically sends messages to the host when the buffer is full, low or empty. The messages contain the PVT status (TML variable **PVTSTS**). The buffer full condition occurs when the number of PVT points in the buffer is equal with the buffer size. The buffer low condition occurs when the number of PVT points in the buffer is less or equal with a programmable value. The level for BufferLow signaling is updated when **ChangeLowLevel = TRUE** with the value of parameter **LowLevelValue**. The buffer empty condition occurs when the buffer is empty and the execution of the last PVT point is over.

When the PVT buffer becomes empty the drive/motor:

- Remains in PVT mode if the velocity of last PVT point executed is zero and waits for new points to receive
- Enters in quick stop mode if the velocity of last PVT point executed is not zero

Therefore, a correct PVT sequence must always end with a last PVT point having velocity zero.

Remarks:

1. *The PVT and PT modes share the same buffer. Therefore, the TML parameters and variables associated with the buffer management are the same.*
2. *Both the PVT buffer size and its start address are programmable via TML parameters **PVTBUFBEGIN**(int@0x0864) and **PVTBUFLen** (int@0x0865). Therefore, if needed, the PVT buffer size can be substantially increased. Use **TS_SetIntegerVariable** to change the PVT buffer parameters.*

Each PVT point includes a 7-bit integrity counter. The integrity counter value must be incremented by the host by one, each time a new PVT point is sent to the drive/motor. If the integrity counter error checking is activated (**IntegrityChecking = TRUE**), the drive compares its integrity counter value with the one sent with the PVT point. This comparison is done every time a PVT point is received. If the values of the two integrity counters do not match, the integrity check error is triggered, the drive/motor sends messages with **PVTSTS** to the host and the received PVT point is discarded. Each time a PVT point is accepted (the integrity counters match or the integrity counter error checking is disabled), the drive automatically increments its internal integrity counter.

The default value of the internal integrity counter after power up is 0. Set **ChangePVTCounter = TRUE** to change its value with **PVTCounterValue** parameter. The integrity counter checking is disabled when parameter **IntegrityChecking = FALSE**.

Related functions: **TS_SendPVTFirstPoint**, **TS_SendPVTPoint**

Associated examples: **Ex08_PVT**

3.5.6.12. TS_SendPVTFirstPoint

Prototype:

BOOL TML_EXPORT TS_SendPVTFirstPoint(LONG Position, DOUBLE Velocity, WORD Time, SHORT PVTCounter, SHORT PositionType, LONG InitialPosition, SHORT MoveMoment SHORT ReferenceBase);

Arguments:

Name	I/O	Description
Position	Input	Position value for first PVT point expressed in TML position units
Velocity		Speed at the end of the first PVT segment expressed in TML speed units
Time		Represents the time interval of the PVT segment expressed in TML time units. The maximum time interval is 511 IU.
PVTCounter		Integrity counter for first PVT point.
PositionType		Specifies the type of PVT mode
InitialPosition		The initial position at the start of an absolute PVT movement
MoveMoment		Defines the moment when the motion is started
ReferenceBase		Specifies how the motion reference is computed: from actual values of position and speed reference or from actual values of load/motor position and speed
Return	Output	TRUE if no error, FALSE if error

Description: The function sends the first PVT point and activates the PVT motion mode.

Parameter **PositionType** sets the PVT mode: absolute or relative. In the absolute mode (**PositionType = ABSOLUTE_POSITION**), each PVT point specifies the position to reach. The initial position may be either the current position reference TML variable TPOS or a preset value read from the TML parameter PVTPOS0. In the relative mode (**PositionType = RELATIVE_POSITION**), each PVT point specifies the position increment relative to the previous point.

Remark: The source for initial position, TPOS or PVTPOS0, is set with function TS_PVTSetup.

The motion is executed:

- Immediately when **MoveMoment = UPDATE_IMMEDIATE**
- When a programmed event occurs if **MoveMoment = UPDATE_ON_EVENT**
- If you select **MoveMoment = UPDATE_NONE**, the movement is parameterized, but does not execute. You'll need to issue an update command to determine the execution of the movement. Use the **TS_UpdateImmediate** or the **TS_UpdateOnEvent** functions in order to activate the movement.

Related functions: TS_PVTSetup, TS_SendPVTPoint

Associated examples: Ex08_PVT

3.5.6.13. TS_SendPVTPoint

Prototype:

BOOL TML_EXPORT TS_SendPVTPoint(LONG Position, DOUBLE Velocity, WORD Time, SHORT PVTCounter);

Arguments:

Name	I/O	Description
Position	Input	Position at the end of the PVT segment expressed in TML position units
Velocity		Velocity at the end of the PVT segment expressed in TML speed units
Time		Time interval for the current PVT segment expressed in TML time units
PVTCounter		The integrity counter for the current PVT point
Return	Output	TRUE if no error, FALSE if error

Description: The function sends a PVT point to the drive/motor. Each point specifies the desired **Position**, **Velocity** and **Time**, i.e. contains a **PVT** data. Between the PVT points the reference generator performs a 3rd order interpolation. The PVT point also includes a 7-bit integrity counter. The integrity counter value must be incremented by the host by one, each time a new PVT point is sent to the drive/motor.

Related functions: TS_PVTSetup, TS_SendPVTFirstPoint

Associated examples: Ex08_PVT

3.5.6.14. TS_PTSetup

Prototype:

```
BOOL TML_EXPORT TS_PTSetup(SHORT ClearBuffer, SHORT IntegrityChecking, SHORT
ChangePTCounter, SHORT AbsolutePositionSource, SHORT ChangeLowLevel, SHORT PTCounterValue,
SHORT LowLevelValue);
```

Arguments:

Name	I/O	Description
ClearBuffer	Input	When TRUE the PT buffer is cleared
IntegrityChecking		Enable/disable PT counter integrity checking
ChangePTCounter		Specifies if the integrity counter is updated with the value of PTCounterValue parameter
AbsolutePositionSource		Selects the source for initial position for absolute PT mode
ChangeLowLevel		Specifies if the level for BufferLow signaling is updated with the value of LowLevelValue parameter
PTCounterValue		The new value for the drive/motor PT integrity counter
LowLevelValue	Output	The new value for the level of the BufferLow signal
Return		TRUE if no error, FALSE if error

Description: The function programs a drive/motor to work in PT motion mode. In PT motion mode the drive/motor performs a positioning path described through a series of points. Each point specifies the desired **Position** and **Time**, i.e. contains a PT data. Between the points the built-in reference generator performs a linear interpolation.

Remark: The function block just programs the drive/motor for PT mode. The motion mode is activated with function *TS_SendPTFirstPoint* and the PT points are sent to the drive with function *TS_SendPTPoint*.

The PT motion mode can be started only when the previous motion is complete. However, you can switch at any moment to another motion mode.

The PT mode can be relative or absolute. In the absolute mode, each PT point specifies the position to reach. The initial position may be either the current position reference TML variable TPOS (**AbsolutePositionSource = TRUE**) or a preset value read from the TML parameter PVTPOS0 (**AbsolutePositionSource = FALSE**). In the relative mode, each PT point specifies the position increment relative to the previous point. In both cases, the time is relative to the previous point i.e. represents the duration of a PT segment. For the first PT point, the time is measured from the starting of the PT mode.

Remark: The PT mode, absolute or relative, is set with function *TS_SendPTFirstPoint*.

Each time when the drive receives a new PT point, it is saved into the PT buffer. The reference generator empties the buffer as the PT points are executed. The PT buffer is of type FIFO (first in, first out). The default length of the PT buffer is 7 PT points. The drive/motor automatically sends messages to the host when the buffer is full, low or empty. The messages contain the PT status (TML variable **PVTSTS**). The buffer full condition occurs when the

number of PT points in the buffer is equal with the buffer size. The buffer low condition occurs when the number of PT points in the buffer is less or equal with a programmable value. Set **ChangeLowLevel = TRUE** to change the level for BufferLow signaling with the value of parameter **LowLevelValue**. The buffer empty condition occurs when the buffer is empty and the execution of the last PT point is over. When the PT buffer becomes empty the drive/motor keeps the position reference unchanged.

Remarks:

1. *The PT and PVT modes share the same buffer. Therefore, the TML parameters and variables associated with the buffer management are the same.*
2. *Both the PT buffer size and its start address are programmable via TML parameters **PVTBUFBEGIN**(int@0x0864) and **PVTBUFLen** (int @0x0865). Therefore, if needed, the PT buffer size can be substantially increased. Use **TS_SetIntegerVariable** to change the PT buffer parameters.*

Each PT point also includes a 7-bit integrity counter. The integrity counter value must be incremented by the host by one, each time a new PT point is sent to the drive/motor. If the integrity counter error checking is activated (**IntegrityChecking = FALSE**), the drive compares its integrity counter value with the one sent with the PT point. This comparison is done every time a PT point is received. If the values of the two integrity counters do not match, the integrity check error is triggered, the drive/motor sends messages with PVTSTS to the host and the received PT point is discarded. Each time a PT point is accepted (the integrity counters match or the integrity counter error checking is disabled), the drive automatically increments its internal integrity counter.

The default value of the internal integrity counter after power up is 0. Set **ChangePTCounter = TRUE** to change the value of integrity counter with **PTCounterValue** parameter. The integrity counter checking is disabled when parameter **IntegrityChecking = TRUE**.

Related functions: TS_SendPTFirstPoint, TS_SendPTPoint

Associated examples: –

3.5.6.15. TS_SendPTFirstPoint

Prototype:

BOOL TML_EXPORT TS_SendPTFirstPoint(LONG Position, WORD Time, SHORT PTCounter, SHORT PositionType, LONG InitialPosition, SHORT MoveMoment SHORT ReferenceBase);

Arguments:

Name	I/O	Description
Position	Input	Position value for first PT point expressed in TML position units
Time		Time interval of the PT segment expressed in TML time units.
PTCounter		Integrity counter for first PT point.
PositionType		Specifies the type of PT mode
InitialPosition		The initial position at the start of an absolute PT movement
MoveMoment		Defines the moment when the motion is started
ReferenceBase		Specifies how the motion reference is computed: from actual values of position and speed reference or from actual values of load/motor position and speed
Return	Output	TRUE if no error, FALSE if error

Description: The function sends the first PT point and activates the PT motion mode.

Parameter **PositionType** sets the PT mode: absolute or relative. In the absolute mode (**PositionType = ABSOLUTE_POSITION**), each PT point specifies the position to reach. The initial position may be either the current position reference TML variable TPOS or a preset value read from the TML parameter PVTPOS0. In the relative mode (**PositionType = RELATIVE_POSITION**), each PT point specifies the position increment relative to the previous point.

Remark: The initial position source, TPOS or PVTPOS0, is set with function TS_PTSetup.

The motion is executed:

- Immediately when **MoveMoment = UPDATE_IMMEDIATE**
- When a programmed event occurs if **MoveMoment = UPDATE_ON_EVENT**
- If you select **MoveMoment = UPDATE_NONE**, the movement is parameterized, but does not execute. You'll need to issue an update command to determine the execution of the movement. Use the **TS_UpdateImmediate** or the **TS_UpdateOnEvent** functions in order to activate the movement.

Related functions: TS_PTSetup, TS_SendPTPoint

Associated examples: –

3.5.6.16. TS_SendPTPoint

Prototype:

BOOL TML_EXPORT TS_SendPTPoint(LONG Position, WORD Time, SHORT PTCounter);

Arguments:

Name	I/O	Description
Position	Input	Position at the end of the PT segment expressed in TML position units
Time		Time interval for the current PT segment expressed in TML time units
PTCounter		The integrity counter for the current PT point
Return	Output	TRUE if no error, FALSE if error

Description: The function sends a PT point to the drive/motor. Each point specifies the desired **Position**, and **Time**. Between the PT points the reference generator performs a linear interpolation. The PT point also includes a 7-bit integrity counter. The integrity counter value must be incremented by the host by one, each time a new PT point is sent to the drive/motor.

Related functions: TS_PTSetup, TS_SendPTFirstPoint

Associated examples: –

3.5.6.17. TS_SetGearingMaster

Prototype:

BOOL TML_EXPORT TS_SetGearingMaster(BOOL Group, BYTE SlaveID, SHORT ReferenceBase, BOOL Enable, BOOL SetSlavePos, SHORT MoveMoment);

Arguments:

Name	I/O	Description
Group	Input	Specifies if the master sends its position to one slave or a group of slaves
SlaveID		The axis ID of the slave or group ID of group of slaves
ReferenceBase		Specifies if the master sends its load position or its position reference
Enable		Enable/disables the master in electronic gearing
SetSlavePos		Specify if the master is initializing the slave(s)
MoveMoment		Defines the moment when the settings are activated
Return	Output	TRUE if no error, FALSE if error

Description: The function programs the active axis as master in electronic gearing. Once at each slow loop sampling time interval, the master sends either its load position APOS (**ReferenceBase = FROM_MEASURE**) or its position reference TPOS (**ReferenceBase = FROM_REFERENCE**) to the axis or the group of axes specified in the parameter **SlaveID**.

Remark: The *ReferenceBase = FROM_MEASURE* option is not valid if the master operates in open loop. It is meaningless if the master drive has no position sensor.

The **SlaveID** is interpreted either as the Axis ID of one slave (**Group = FALSE**) or the value of a Group ID i.e. the group of slaves to which the master should send its data (**Group = TRUE**).

The master operation is enabled with **Enable = TRUE** and is disabled when **Enable = FALSE**. In both cases, these operations have no effect on the motion executed by the master.

If the master activation is done AFTER the slaves are set in electronic gearing mode, set **SetSlavePos = TRUE** to determine the master to send an initialization message to the slaves.

The commands are executed:

- Immediately when **MoveMoment = UPDATE_IMMEDIATE**
- When a programmed event occurs if **MoveMoment = UPDATE_ON_EVENT**
- If you select **MoveMoment = UPDATE_NONE**, the movement is parameterized, but does not execute. You'll need to issue an update command to determine the execution of the movement. Use the **TS_UpdateImmediate** or the **TS_UpdateOnEvent** functions in order to activate the movement.

Related functions: TS_SetGearingSlave, TS_SendSynchronization

Associated examples: Ex07_MultiAxes

3.5.6.18. TS_SetGearingSlave

Prototype:

BOOL TML_EXPORT TS_SetGearingSlave(SHORT Denominator, SHORT Numerator, SHORT ReferenceBase, SHORT EnableSlave, DOUBLE LimitVariation, SHORT MoveMoment);

Arguments:

Name	I/O	Description
Denominator	Input	Gear ratio denominator (always positive)
Numerator		Gear ratio numerator (positive or negative)
ReferenceBase		Specifies how the motion reference is computed: from actual values of position and speed reference or from actual values of load/motor position and speed
EnableSlave		Enables the electronic gearing slave mode
EnableSuperposition		Enables/disables motion superposition
LimitVariation		Acceleration limit when the slave is coupling
MoveMoment		Defines the moment when the settings are activated
Return	Output	TRUE if no error, FALSE if error

Description: The function programs the active axis to operate as slave in electronic gearing. In electronic gearing slave mode, the drive/motor performs a position control. At each slow loop sampling period, the slave computes the master's position increment and multiplies it with its programmed gear ratio. The result is the slave's position reference increment, which added to the previous slave position reference gives the new slave position reference.

The gear ratio is the result of the division **Numerator / Denominator**. **Numerator** is a signed integer, while the **Denominator** is unsigned integer. The **Numerator** sign indicates the direction of movement: positive – same as the master, negative – reversed to the master. **Numerator** and **Denominator** are used by an automatic compensation procedure that eliminates the round off errors, which occur when the gear ratio is an irrational number like: 1/3 (Slave = 1, Master = 3).

The slave can get the master position in two ways:

1. Via a communication channel (**EnableSlave = SLAVE_COMMUNICATION_CHANNEL**), from a drive/motor set as master with function block TS_SetGearingMaster
2. Via an external digital reference of type pulse & direction or quadrature encoder (**EnableSlave = SLAVE_2ND_ENCODER**)

Remark: Set **EnableSlave = SLAVE_NONE** if you want to program the motion mode parameters without enabling it.

When master position is provided via the external digital interface, the slave computes the master position by counting the pulse & direction or quadrature encoder signals. The initial value of the master position is set by default to 0. Use function TS_SetLongVariable to change its value by writing the desired value in the TML variable APOS2.

You can smooth the slave coupling with the master, by limiting the maximum acceleration on the slave. This is particularly useful when the slave must couple with a master running at high speed. This feature is activated when the parameter **LimitVariation** has a positive value and disabled when its value is zero.

Set **ReferenceBase = FROM_REFERENCE** if you want the reference generator to compute the slave position starting from the actual values of the position and speed reference. Set **ReferenceBase = FROM_MEASURE** if you want the reference generator to compute the slave position starting from the actual values of the load/motor position and speed. When this option is used, at the beginning of each new motion profile, the position and speed reference are updated with the actual values of the load/motor position and speed.

Remarks:

1. *The function requires drive/motor position loop to be closed. During the drive/motor setup select **Position** at Control Mode and perform the position controller tuning.*
2. *Use function block **TS_SetGearingMaster** to program a drive/motor as master in electronic gearing*
3. *When the reference is read from second encoder or pulse & direction inputs you don't need to program a drive/motor as master in electronic gearing*

Related functions: TS_SetGearingMaster, TS_SetMasterResolution

Associated examples: Ex07_MultiAxes

3.5.6.19. TS_MotionSuperposition

Prototype:

BOOL TML_EXPORT TS_MotionSuperposition(short Enable, short Update);

Arguments:

Name	I/O	Description	
Enable	Input	0	Disable the Superposition mode
		1	Enable the Superposition mode
Update		0	Doesn't send UPD command to the drive, in order to take into account, the Superposition mode
		1	Sends UPD command to the drive, in order to take into account, the Superposition mode
Return	Output	TRUE if no error, FALSE if error	

Description: Enable or disable the superposition of the electronic gearing mode with a second motion mode.

When this *superposed mode* activated, the position reference is computed as the sum of the position references for each of the 2 superposed motions.

You may enable the *superposed mode* at any moment, independently of the activation/deactivation of the electronic gearing slave.

If the *superposed mode* is activated during an electronic gearing motion, any subsequent motion mode change is treated as a second move to be superposed over the basic electronic gearing move, instead of replacing it.

If the *superposed mode* is activated during another motion mode, a second electronic gearing mode will start using the motion parameters previously set. This move is superposed over the first one. After the first move ends, any other subsequent motion will be added to the electronic gearing.

When you disable the *superposed mode*, the electronic gearing slave move is stopped and the drive/motor executes only the other motion. If you want to remain in the electronic gearing slave mode, set first the electronic gearing slave move and then disable the *superposed mode*.

Related functions: -

Associated examples: -

3.5.6.20. TS_SetCammingMaster

Prototype:

BOOL TML_EXPORT TS_SetCammingMaster(BOOL Group, BYTE SlaveID, SHORT ReferenceBase, BOOL Enable, SHORT MoveMoment);

Arguments:

Name	I/O	Description
Group	Input	Specifies if the master sends its position to one slave or a group of slaves
SlaveID		The axis ID of the slave or group ID of group of slaves
ReferenceBase		Specifies if the master sends its load position or its position reference
Enable		Enable/disables the master in electronic camming
MoveMoment		Defines the moment when the settings are activated
Return	Output	TRUE if no error, FALSE if error

Description: The function programs the active axis as master in electronic camming. Once at each slow loop sampling time interval, the master sends either its load position APOS (**ReferenceBase = FROM_MEASURE**) or its position reference TPOS (**ReferenceBase = FROM_REFERENCE**) to the axis or the group of axes specified in the parameter **SlaveID**.

Remark: The *ReferenceBase = FROM_MEASURE* option is not valid if the master operates in open loop. It is meaningless if the master drive has no position sensor.

The **SlaveID** is interpreted either as the Axis ID of one slave (**Group = FALSE**) or the value of a Group ID i.e. the group of slaves to which the master should send its data (**Group = TRUE**).

The master operation is enabled with **Enable = TRUE** and is disabled when **Enable = FALSE**. In both cases, these operations have no effect on the motion executed by the master.

The commands are executed:

- Immediately when **MoveMoment = UPDATE_IMMEDIATE**
- When a programmed event occurs if **MoveMoment = UPDATE_ON_EVENT**
- If you select **MoveMoment = UPDATE_NONE**, the movement is parameterized, but does not execute. You'll need to issue an update command to determine the execution of the movement. Use the **TS_UpdateImmediate** or the **TS_UpdateOnEvent** functions in order to activate the movement.

Related functions: TS_CamDownload, TS_CamInitialization TS_SetCammingSlaveRelative, TS_SetCammingSlaveAbsolute, TS_SendSynchronization

Associated examples: Ex07_MultiAxes

3.5.6.21. TS_SetCammingSlaveRelative

Prototype:

BOOL TML_EXPORT TS_SetCammingSlaveRelative(WORD RunAddress, SHORT ReferenceBase, SHORT EnableSlave, SHORT MoveMoment, LONG OffsetFromMaster, DOUBLE MultInputFactor, DOUBLE MultOutputFactor);

Arguments:

Name	I/O	Description
RunAddress	Input	Drive/motor RAM address where the cam table is copied with function TS_CamInitialization
ReferenceBase		Specifies how the motion reference is computed: from actual values of position and speed reference or from actual values of load/motor position and speed
EnableSlave		Enable the electronic camming slave mode
MoveMoment		Defines the moment when the settings are activated
OffsetFromMaster		Cam table offset expressed in TML position units
MultInputFactor		CAM table input scaling factor
MultOutputFactor		CAM table output scaling factor
Return	Output	TRUE if no error, FALSE if error

Description: The function block programs the active axis to operate as slave in electronic camming relative mode. The slave drive/motor executes a cam profile function of the master drive/motor position. The cam profile is defined by a cam table – a set of (X, Y) points, where X is cam table input i.e. the master position and Y is the cam table output i.e. the corresponding slave position. Between the points the drive/motor performs a linear interpolation. In electronic camming relative mode, the output of the cam table is added to the slave actual position.

The cam tables are previously stored in drive/motor non-volatile memory with function **TS_CamDownload**. After download, previously starting the camming slave, you have to initialize the cam table, i.e. to copy it from non-volatile memory to RAM memory. Use function **TS_CamInitialization** to initialize a cam table. The active cam table is selected through parameter **RunAddress**. The **RunAddress** must contain the drive/motor RAM address where the cam table was copied.

The slave can get the master position in two ways:

1. Via a communication channel (**EnableSlave = SLAVE_COMMUNICATION_CHANNEL**), from a drive/motor set as master with function block TS_SetGearingMaster
2. Via an external digital reference of type pulse & direction or quadrature encoder (**EnableSlave = SLAVE_2ND_ENCODER**)

Remark:

1. Set **EnableSlave = SLAVE_NONE** to program the motion mode parameters without enabling it.

2. Use function block **TS_SetCammingMaster** to program a drive/motor as master in electronic camming. When the reference is read from second encoder or pulse & direction inputs you don't need to program a drive/motor as master in electronic camming

When master position is provided via the external digital interface, the slave computes the master position by counting the pulse & direction or quadrature encoder signals. The initial value of the master position is set by default to 0. Use function block TS_SetLongVariable to change its value by writing the desired value in the TML variable APOS2.

With parameter **OffsetFromMaster** you can shift the cam profile versus the master position, by setting an offset for the slave. The cam table input is computed as the master position minus the cam offset. For example, if a cam table is defined between angles 100 to 250 degrees, a cam offset of 50 degrees will make the cam table to execute between master angles 150 and 300 degrees.

You can compress/extend the cam table input. Set the parameter **MultInputFactor** with the correction factor by which the cam table input is multiplied. For example, an input correction factor of 2, combined with a cam offset of 180 degrees, will make possible to execute a cam table defined for 360 degrees of the master in the last 180 degrees.

You can also compress/extend the cam table output. Specify through input **MultOutputFactor** the correction factor by which the cam table output is multiplied. This feature addresses the applications where the slaves must execute different position commands at each master cycle, all having the same profile defined through a cam table. In this case, the drive/motor is programmed with a unique normalized cam profile and the cam table output is multiplied with the relative position command updated at each master cycle.

Remark: If the *OffsetFromMaster*, *MultInputFactor* and/or *MultOutputFactor* are set to zero the drive/motor will use the value previously set for the parameter or the default value. With this option the TML code generated by this function is reduced.

Related functions: TS_CamDownload, TS_CamInitialization, TS_SetCammingSlaveAbsolute,
TS_SetCammingMaster, TS_SetMasterResolution

Associated examples: Ex07_MultiAxes

3.5.6.22. TS_SetCammingSlaveAbsolute

Prototype:

BOOL TML_EXPORT TS_SetCammingSlaveAbsolute(WORD RunAddress, DOUBLE LimitVariation, SHORT ReferenceBase, SHORT EnableSlave, SHORT MoveMoment, LONG OffsetFromMaster, DOUBLE MultInputFactor, DOUBLE MultOutputFactor);

Arguments:

Name	I/O	Description
RunAddress	Input	Drive/motor RAM address where the cam table is copied with function TS_CamInitialization
LimitVariation		Slave speed limit value expressed in TML speed units
ReferenceBase		Specifies how the motion reference is computed: from actual values of position and speed reference or from actual values of load/motor position and speed
EnableSlave		Enable the electronic camming slave mode
MoveMoment		Defines the moment when the settings are activated
OffsetFromMaster		Cam table offset expressed in TML position units
MultInputFactor		CAM table input scaling factor
Return	Output	TRUE if no error, FALSE if error

Description: The function block programs the active axis to operate as slave in electronic camming absolute mode. The slave drive/motor executes a cam profile function of the master drive/motor position. The cam profile is defined by a cam table – a set of (X, Y) points, where X is cam table input i.e. the master position and Y is the cam table output i.e. the corresponding slave position. Between the points the drive/motor performs a linear interpolation. In electronic camming absolute mode, the output of the cam table represents the position to reach.

The electronic camming absolute mode may generate abrupt variations on the slave position reference, mainly at entry in the camming mode. Set parameter **LimitVariation** to limit the speed of the slave during travel towards the position to reach. The limitation is disabled if the **LimitVariation** is set to zero.

The cam tables are previously stored in drive/motor non-volatile memory with function TS_CamDownload. After download, previously starting the camming slave, you have to initialize the cam table, i.e. to copy it from non-volatile memory to RAM memory. Use function TS_CamInitialization to initialize a cam table. The active cam table is selected through parameter **RunAddress**. The **RunAddress** must contain the drive/motor RAM address where the cam table was copied.

The slave can get the master position in two ways:

1. Via a communication channel (**EnableSlave = SLAVE_COMMUNICATION_CHANNEL**), from a drive/motor set as master with function block TS_SetGearingMaster
2. Via an external digital reference of type pulse & direction or quadrature encoder (**EnableSlave = SLAVE_2ND_ENCODER**)

Remark:

1. Set **EnableSlave = SLAVE_NONE** if you want to program the motion mode parameters without enabling it.
2. Use function block **TS_SetCammingMaster** to program a drive/motor as master in electronic camming. When the reference is read from second encoder or pulse & direction inputs you don't need to program a drive/motor as master in electronic camming

When master position is provided via the external digital interface, the slave computes the master position by counting the pulse & direction or quadrature encoder signals. The initial value of the master position is set by default to 0. Use function block TS_SetLongVariable to change its value by writing the desired value in the TML variable APOS2.

Set the parameter **OffsetFromMaster** to shift the cam profile versus the master position, by setting an offset for the slave. The cam table input is computed as the master position minus the cam offset. For example, if a cam table is defined between angles 100 to 250 degrees, a cam offset of 50 degrees will make the cam table to execute between master angles 150 and 300 degrees.

You can compress/extend the cam table input. Set the parameter **MultInputFactor** with the correction factor by which the cam table input is multiplied. For example, an input correction factor of 2, combined with a cam offset of 180 degrees, will make possible to execute a cam table defined for 360 degrees of the master in the last 180 degrees.

You can also compress/extend the cam table output. Specify through input **MultOutputFactor** the correction factor by which the cam table output is multiplied. This feature addresses the applications where the slaves must execute different position commands at each master cycle, all having the same profile defined through a cam table. In this case, the drive/motor is programmed with a unique normalized cam profile and the cam table output is multiplied with the relative position command updated at each master cycle.

Remark: If the *OffsetFromMaster*, *MultInputFactor* and/or *MultOutputFactor* are set to zero the drive/motor will use the value previously set for the parameter or the default value. With this option the TML code generated by this function is reduced.

Related functions: TS_CamDownload, TS_CamInitialization, TS_SetCammingSlaveRelative,
TS_SetCammingMaster, TS_SetMasterResolution

Associated examples: –

3.5.6.23. TS_CamDownload

Prototype:

BOOL TML_EXPORT TS_CamDownload(LPCSTR pszCamFile, WORD LoadAddress, WORD RunAddress, WORD& wNextLoadAddr, WORD& wNexLoadAddr);

Arguments:

Name	I/O	Description
pszCamFile	Input	The name of the file containing the cam table description
LoadAddress		The non-volatile memory (EEPROM) address where the cam table is downloaded
RunAddress		The RAM address where the cam table is copied at initialization
wNextLoadAddr	Output	Next available EEPROM address from where a cam table can be downloaded
wNextRunAddr		Next available RAM address where a cam table can be copied
Return		TRUE if no error, FALSE if error

Description: The function downloads a cam table in the drive/motor non-volatile memory (EEPROM) starting with address **LoadAddress**. The **RunAddress** parameter is required to compute the **wNextRunAddr**. The function returns the next valid memory addresses for cam tables trough output parameters **wNextLoadAddr** respectively **wNextRunAddr**. If the values returned by the function are 0 then there is no memory available.

The **LoadAddress** and **RunAddress** for the **first** cam table downloaded are computed by **EasyMotion Studio** and displayed in the dialogue **Memory Settings**. To open the dialogue **Memory Settings**, select the appropriate TML application and in **Application General Information** press the button **Memory Settings**. For the next cam tables, if available, the **LoadAddress** and **RunAddress** are the values returned by the previous call of function **TS_CamDownload** (parameters **wNextLoadAddr** and **wNextRunAddr**).

The cam table description is read from the file **pszCamFile**. The file is generated from **EasyMotion Studio** and has the extension ***.cam**.

Steps to follow when using cam tables:

1. Create or import a cam table in **EasyMotion Studio**. The cam table is saved by EasyMotion Studio as a *.cam file in the application directory.
2. Download the cam table in the drive/motor non-volatile memory with **TS_CamDownload**
3. Initialize the cam table with **TS_CamInitialization** function
4. Program the drive/motor to operate as slave in electronic camming mode with **TS_SetCammingSlaveAbsolute** or **TS_SetCammingSlaveRelative**. Select the cam table used with the parameter **RunAddress**.

Related functions: TS_SetCammingSlaveRelative, TS_SetCammingSlaveAbsolute, TS_CamInitialization

Associated examples: Ex07_Multiaxes

3.5.6.24. TS_CamInitialization

Prototype:

BOOL TML_EXPORT TS_CamInitialization(WORD LoadAddress, WORD RunAddress);

Arguments:

Name	I/O	Description
LoadAddress	Input	Non-volatile memory (EEPROM) address where the cam table is downloaded
RunAddress		RAM address where the cam table is copied at run time
Return	Output	TRUE if no error, FALSE if error

Description: The function copies a cam table from drive/motor non-volatile memory in the RAM memory at address **RunAddress**. The cam table was previously downloaded with function **TS_CamDownload** at non-volatile memory address **LoadAddress**.

The function must be called for each cam table used by the application.

Related functions: TS_SetCammingSlaveRelative, TS_SetCammingSlaveAbsolute, TS_CamDownload

Associated examples: Ex07_MultiAxes

3.5.6.25. TS_SetMasterResolution

Prototype:

BOOL TML_EXPORT TS_SetMasterResolution(LONG MasterResolution);

Arguments:

Name	I/O	Description
MasterResolution	Input	Number of encoder counts per one revolution of the master position sensor.
Return	Output	TRUE if no error, FALSE if error

Description: The function sets the TML parameter **MASTERRES** with the value **MasterResolution**.

The master resolution is needed by the electronic gearing or camming slaves to compute correctly the master position and speed (i.e. the position increment). If master position is not cyclic (i.e. the resolution is equal with the whole 32-bit range of position), set master resolution to 0x80000001.

Remark: Call function **TS_SetMasterResolution** before activating the electronic gearing or camming slave mode with function **TS_SetGearingSlave** respectively **TS_SetCammingSlaveAbsolute/Relative**.

Related functions: TS_SetGearingSlave, TS_SetCammingSlaveAbsolute, TS_SetCammingSlaveRelative

Associated examples: Ex07_MultiAxes

3.5.6.26. TS_SendSynchronization

Prototype:

BOOL TML_EXPORT TS_SendSynchronization(LONG Period);

Arguments:

Name	I/O	Description
Period	Input	Time period between two synchronization messages. It is expressed in TML time units
Return	Output	TRUE if no error, FALSE if error

Description: The function enables/disables the synchronization procedure between axes. The synchronization process is activated when the parameter **Period** has a non-zero value. The active axis is set as the synchronization master and the other axes become synchronization slaves. To disable the synchronization procedure set the **Period** to zero.

The synchronization process is performed in two steps. First, the master sends a synchronization message to all axes, including to itself. When this message is received, all the axes read their own internal time. Next, the master sends its internal time to all the slaves, which compare it with their own internal time. If there are differences, the slaves correct slightly their sampling periods in order to keep them synchronized with those of the master. As effect, when synchronization procedure is active, the execution of the control loops on the slaves is synchronized with those of the master within a 10µs time interval. Due to this powerful feature, drifts between master and slave axes are eliminated. The **Period** represents the time interval in internal units between the synchronization messages sent by the master. Recommended value is 20ms.

Related functions: TS_SetGearingMaster, TS_SetGearingSlave TS_SetCammingMaster, TS_SetCammingSlave

Associated examples: –

3.5.7. Motor commands

3.5.7.1. TS_Power

Prototype:

BOOL TML_EXPORT TS_Power(BOOL Enable);

Arguments:

Name	I/O	Description
Enable	Input	Enables/disables the power stage of the active axis
Return	Output	TRUE if no error, FALSE if error

Description: The function enables/disables the power stage of the active axis. If **Enable = TRUE**, the power stage is enabled (executes the TML command **AxisON**). The power stage is disabled (executes the TML command **AxisOFF**) when **Enable = FALSE**.

Related functions: TS_ResetFault, TS_Reset

Associated examples: All

3.5.7.2. TS_UpdateImmediate

Prototype:

BOOL TML_EXPORT TS_UpdateImmediate(void);

Arguments:

Name	I/O	Description
-	Input	-
Return	Output	TRUE if no error, FALSE if error

Description: The function updates the motion mode immediately. It allows you to start a motion previously programmed. This can be useful for example if you already defined a motion and you want to start it in a specific context (after testing a condition, event, input port, etc.). The command can also be useful to repeat the last motion that was already defined and eventually executed (as for example a relative move).

Related functions: TS_UpdateOnEvent

Associated examples: Ex08_PVT

3.5.7.3. TS_UpdateOnEvent

Prototype:

BOOL TML_EXPORT TS_UpdateOnEvent(void);

Arguments:

Name	I/O	Description
-	Input	-
Return	Output	TRUE if no error, FALSE if error

Description: The function updates the motion mode on next event occurrence. It allows you to start a motion that was previously programmed at the occurrence of the active event. This can be useful for example if you already defined a motion and you want to start it when an event occurs. The command can also be used to repeat the last motion that was already defined and eventually executed (as for example a relative move), when the event will occur.

Related functions: TS_UpdateImmediate

Associated examples: -

3.5.7.4. TS_Stop

Prototype:

BOOL TML_EXPORT TS_Stop(void);

Arguments:

Name	I/O	Description
-	Input	-
Return	Output	TRUE if no error, FALSE if error

Description: The function stops the motor with the deceleration rate set in CACC TML parameter. The drive/motor decelerates following a trapezoidal speed profile. If the function is called during the execution of an S-curve profile, the deceleration profile may be chosen between a trapezoidal or an S-curve profile. You can detect when the motor has stopped by setting a motion complete event with function **TS_SetEventOnMotionComplete** and waiting until the event occurs (**WaitEvent = TRUE**). When the drive performs torque control the drive is set in torque external mode with current reference = 0.

Remarks:

- *In order to restart after a TS_Stop call you need to set the motion mode again. This operation disables the stop mode and allows the motor to move*
- *When TS_Stop is executed the drive/motor will stop the execution of the TML program (if present), to avoid overwriting the stop command from the TML program*
- *During abrupt stops an important energy may be generated. If the power supply can't absorb the energy generated by the motor, it is necessary to foresee an adequate surge capacitor in parallel with the drive supply to limit the over voltage.*

Related functions: TS_QuickStopDecelerationRate

Associated examples: Ex02_DriveStatus, Ex04_BasicMove, Ex05_Homing, Ex06_ExternalReference

3.5.7.5. TS_SetPosition

Prototype:

BOOL TML_EXPORT TS_SetPosition(long PosValue);

Arguments:

Name	I/O	Description
PosValue	Input	The value used to set the position, expressed in TML position units
Return	Output	TRUE if no error, FALSE if error

Description: The function sets/changes the referential for position measurement by changing simultaneously the load position (TML variable APOS) and the target position values (TML variable APOS), while keeping the position error (difference between the TPOS and APOS). Future motion commands will be related to the absolute value, as updated at this point to **PosValue**.

Related functions: –

Associated examples: Ex04_BasicMove, Ex05_Homing, Ex07_MultiAxes, Ex09_Logger, Ex11_IOHandling

3.5.7.6. TS_SetTargetPositionToActual

Prototype:

BOOL TML_EXPORT TS_SetTargetPositionToActual(void);

Arguments:

Name	I/O	Description
-	Input	-
Return	Output	TRUE if no error, FALSE if error

Description: The function sets the value of the target position (the position reference) to the value of the actual load position i.e. TPOS = APOS_LD. The command may be used in closed loop systems when the load/motor is still following a hard stop, to reposition the target position to the actual load position.

Remark: *The command is automatically executed by the drive if the next motion mode is set with ReferenceBase = FROM_MEASURE. In this case the target position and speed are both updated with the actual values of the load position and respectively load speed: TPOS = APOS_LD and TSPD = ASPD_LD.*

Related functions: –

Associated examples: –

3.5.7.7. TS_SetCurrent

Prototype:

BOOL TML_EXPORT TS_SetCurrent(short CrtValue);

Arguments:

Name	I/O	Description
CrtValue	Input	Value at which the motor current reference is set expressed in TML current units
Return	Output	TRUE if no error, FALSE if error

Description: The function sets the motor run current with **CrtValue**. The run current is used by the drive to control the step motor in open loop.

Remark: *The command is valid only for configurations with step motor operating in open loop.*

Related functions: –

Associated examples: –

3.5.7.8. TS_QuickStopDecelerationRate

Prototype:

BOOL TML_EXPORT TS_QuickStopDecelerationRate(DOUBLE Deceleration);

Arguments:

Name	I/O	Description
Deceleration	Input	The value written in TML parameter CDEC
Return	Output	TRUE if no error, FALSE if error

Description: The function sets on the active axis the TML parameter **CDEC** with the value **Deceleration**. The drive/motor uses the deceleration rate when:

- The function TS_Stop is executed during a positioning set with TS_MoveSCurveRelative/Absolute and option **DecelerationType = TRAPEZOIDAL_SPEED_PROFILE**
- Enters in **quick stop mode**. The drive enters in quick stop mode if an error requiring the immediate stop of the motion occurs (like triggering a limit switch or following a command error), the drive/motor enters automatically

Related functions: TS_Stop, TS_MoveSCurveRelative, TS_MoveSCurveAbsolute

Associated examples: Ex05_Homing, Ex11_IOHandling

3.5.8. Events

3.5.8.1. TS_CheckEvent

Prototype:

BOOL TML_EXPORT TS_CheckEvent(BOOL &event);

Arguments:

Name	I/O	Description
-	Input	-
Event		Signal if event occurred
Return	Output	TRUE if no error, FALSE if error

Description: The function checks if the actually active event occurred. If an event was defined using one of the **SetEvent...** functions with **WaitEvent = FALSE**, then you can check if the event occurred using the **TS_CheckEvent** function.

This is an interesting alternative to the case when **WaitEvent** parameter was set to TRUE in one of the **SetEvent...** functions. In that case, if the event will not occur, due to some unexpected problems, the program will hang-up in an internal loop of the **SetEvent...** function, waiting for the event to occur.

Thus, in order to avoid such a problem, set the **WaitEvent** parameter to FALSE, in the **SetEvent...** function, and then call the **TS_CheckEvent** function from your application. In this way, you can detect if the event does not occur and eventually exit from the test loop after a given time period.

Related functions: all SetEvent... functions

Associated examples: Ex10_EventHandling

3.5.8.2. TS_SetEventOnMotionComplete

Prototype:

BOOL TML_EXPORT TS_SetEventOnMotionComplete(BOOL WaitEvent, BOOL EnableStop);

Arguments:

Name	I/O	Description
WaitEvent	Input	–
EnableStop		On motion complete stop the motion
Return	Output	TRUE if no error, FALSE if error

Description: The function sets an event when the motion is completed. You can use, for example, this event to start your next move only after the actual move is finalized.

The motion complete condition is set in the following conditions:

- During position control:
 - If UPGRADE.11=1, when the position reference arrives at the position to reach (commanded position) and the position error remains inside a settle band for a preset stabilize time interval. The settle band is set with TML parameter POSOKLIM and the stabilize time with TML parameter TONPOSOK. This is the default condition.
 - If UPGRADE.11=0, when the position reference arrives at the position to reach (commanded position)
- During speed control, when the speed reference arrives at the commanded speed

The motion complete condition is reset when a new motion is started i.e. when the update command – UPD is executed.

Remark:

1. Use function TS_SetIntVariable to change the settle band and/or the stabilize time.
2. In case of steppers controlled open-loop, the motion complete condition for positioning is always set when the position reference arrives at the position to reach independently of the UPGRADE.11 statuses.

If the **WaitEvent = TRUE**, the function will continuously test the status of the drive event, and will wait until the event occurs. There is a drawback of this situation, if the event will not occur, due to some unexpected problems. In such a case, the program hangs-up in an internal loop of the **TS_SetEventOnMotionComplete** waiting for the event to occur.

If the parameter **WaitEvent = FALSE**, you can check if the event occurred using the **TS_CheckEvent** function. In this way, you can detect if the event does not occur and eventually exit from the test loop after a given time period.

At event occurrence the motion is stopped if the parameter **EnableStop = TRUE**. Set **EnableStop = FALSE** if you do not want to stop the motion at event occurrence.

Related functions: TS_CheckEvent, and all other SetEvent... functions

Associated examples : Ex04_BasicMove, Ex05_Homing, Ex07_MultiAxes, Ex09_Logger, Ex11_IOHandling

3.5.8.3. TS_SetEventOnMotorPosition

Prototype:

```
BOOL TML_EXPORT TS_SetEventOnMotorPosition(SHORT PositionType, LONG Position, BOOL Over,
BOOL WaitEvent, BOOL EnableStop);
```

Arguments:

Name	I/O	Description
PositionType	Input	Specifies the motor position type: absolute or relative
Position		The position value that triggers the event expressed in TML position units.
Over		Specifies the condition tested
WaitEvent		Specifies if the function waits the event occurrence
EnableStop		Stop the motion when at event occurrence
Return	Output	TRUE if no error, FALSE if error

Description: It allows you to program an event function of motor position. The events can be: when the absolute (**PositionType = ABSOLUTE_POSITION**) or relative (**PositionType = ABSOLUTE_RELATIVE**) motor position is equal or over/under **Position**.

The absolute motor position is the measured position of the motor. The relative position is the load displacement from the beginning of the actual movement. For example, if a position profile was started with the absolute load position 50 revolutions, when the absolute load position reaches 60 revolutions, the relative motor position is 10 revolutions.

The condition monitored for the event is set with parameter **Over**. For **Over = TRUE** the event is set when the motor position is equal or over the **Position**. When **Over = FALSE** the event is set if the motor position becomes equal or under **Position**.

If the **WaitEvent = TRUE**, the function tests continuously the event status, and waits until the event occurs. There is a drawback of this situation, if the event will not occur, due to some unexpected problems. In such a case, the program hangs-up in an internal loop of the **TS_SetEventOnMotorPosition** waiting for the event to occur.

If the parameter **WaitEvent = FALSE**, you can check if the event occurred using the **TS_CheckEvent** function. In this way, you can detect if the event does not occur and eventually exit from the test loop after a given time period.

At event occurrence the motion is stopped if the parameter **EnableStop = TRUE**. Set **EnableStop = FALSE** if you do not want to stop the motion at event occurrence.

Related functions: TS_CheckEvent, and all other SetEvent... functions

Associated examples: Ex10_EventHandling

3.5.8.4. TS_SetEventOnLoadPosition

Prototype:

BOOL TML_EXPORT TS_SetEventOnLoadPosition(LONG Position, BOOL Over, BOOL WaitEvent, SHORT EnableStop);

Arguments:

Name	I/O	Description
PositionType	Input	Specifies the load position type: absolute or relative
Position		The position value that triggers the event expressed in TML position units.
Over		Specifies the condition tested
WaitEvent		Specifies if the function waits the event occurrence
EnableStop		Stop the motion when at event occurrence
Return	Output	TRUE if no error, FALSE if error

Description: It allows you to program an event function of load position. The events can be: when the absolute (**PositionType = ABSOLUTE_POSITION**) or relative (**PositionType = ABSOLUTE_RELATIVE**) load position is equal or over/under **Position**.

The absolute load position is the measured position of the load. The relative position is the load displacement from the beginning of the actual movement.

The condition monitored for the event is set with parameter **Over**. For **Over = TRUE** the event is set when the load position is equal or over the **Position**. When **Over = FALSE** the event is set if the load position becomes equal or under **Position**.

If the **WaitEvent = TRUE**, the function tests continuously the event status, and waits until the event occurs. There is a drawback of this situation, if the event will not occur, due to some unexpected problems. In such a case, the program hangs-up in an internal loop of the **TS_SetEventOnLoadPosition** waiting for the event to occur.

If the parameter **WaitEvent = FALSE**, you can check if the event occurred using the **TS_CheckEvent** function. In this way, you can detect if the event does not occur and eventually exit from the test loop after a given time period.

At event occurrence the motion is stopped if the parameter **EnableStop = TRUE**. Set **EnableStop = FALSE** if you do not want to stop the motion at event occurrence.

Related functions: TS_CheckEvent, and all other SetEvent... functions

Associated examples: -

3.5.8.5. TS_SetEventOnMotorSpeed

Prototype:

BOOL TML_EXPORT TS_SetEventOnMotorSpeed(DOUBLE Speed, BOOL Over, BOOL WaitEvent, BOOL EnableStop);

Arguments:

Name	I/O	Description
Speed	Input	The speed value that triggers the event expressed in TML speed units.
Over		Specifies the condition tested
WaitEvent		Specifies if the function waits the event occurrence
EnableStop		Stop the motion when at event occurrence
Return	Output	TRUE if no error, FALSE if error

Description: It allows you to program an event function of motor speed. The events can be: when the motor speed is over (**Over = TRUE**) or under (**Over = FALSE**) the **Speed** parameter.

If the **WaitEvent = TRUE**, the function tests continuously the event status, and waits until the event occurs. There is a drawback of this situation, if the event will not occur, due to some unexpected problems. In such a case, the program hangs-up in an internal loop of the **TS_SetEventOnMotionComplete** waiting for the event to occur.

If the parameter **WaitEvent = FALSE**, you can check if the event occurred using the **TS_CheckEvent** function. In this way, you can detect if the event does not occur and eventually exit from the test loop after a given time period.

At event occurrence the motion is stopped if the parameter **EnableStop = TRUE**. Set **EnableStop = FALSE** if you do not want to stop the motion at event occurrence.

Related functions: TS_CheckEvent, and all other SetEvent... functions

Associated examples: Ex04_BasicMove, Ex10_EventHandling

3.5.8.6. TS_SetEventOnLoadSpeed

Prototype:

BOOL TML_EXPORT TS_SetEventOnLoadSpeed(DOUBLE Speed, BOOL Over, BOOL WaitEvent, BOOL EnableStop);

Arguments:

Name	I/O	Description
Speed	Input	The speed value that triggers the event expressed in TML speed units.
Over		Specifies the condition tested
WaitEvent		Specifies if the function waits the event occurrence
EnableStop		Stop the motion when at event occurrence
Return	Output	TRUE if no error, FALSE if error

Description: It allows you to program an event function of load speed. The events can be: when the load speed is over (**Over = TRUE**) or under (**Over = FALSE**) the **Speed** parameter.

If the **WaitEvent = TRUE**, the function tests continuously the event status, and waits until the event occurs. There is a drawback of this situation, if the event will not occur, due to some unexpected problems. In such a case, the program hangs-up in an internal loop of the **TS_SetEventOnLoadSpeed** waiting for the event to occur.

If the parameter **WaitEvent = FALSE**, you can check if the event occurred using the **TS_CheckEvent** function. In this way, you can detect if the event does not occur and eventually exit from the test loop after a given time period.

At event occurrence the motion is stopped if the parameter **EnableStop = TRUE**. Set **EnableStop = FALSE** if you do not want to stop the motion at event occurrence.

Related functions: TS_CheckEvent, and all other SetEvent... functions

Associated examples: -

3.5.8.7. TS_SetEventOnTime

Prototype:

BOOL TML_EXPORT TS_SetEventOnTime(WORD Time, BOOL WaitEvent, BOOL EnableStop);

Arguments:

Name	I/O	Description
Time	Input	Time delay expressed in TML time units
WaitEvent		Specifies if the function waits the event occurrence
EnableStop		On event stop the motion
Return	Output	TRUE if no error, FALSE if error

Description: The function programs an event after a time period equal to the value of the **Time** parameter.

If the parameter **WaitEvent** = **TRUE** the function tests continuously the event status, and waits until the event occurs. There is a drawback of this situation, if the event will not occur, due to some unexpected problems. In such a case, the program hangs-up in an internal loop of the **TS_SetEventOnTime** function, waiting for the event to occur.

If the parameter **WaitEvent** = **FALSE**, you can check if the event occurred using the **TS_CheckEvent** function. In this way, you can detect if the event does not occur and eventually exit from the test loop after a given time period.

At the event occurrence the motion is stopped if the parameter **EnableStop** = **TRUE**. Set **EnableStop** = **FALSE** if you do not want to stop the motion at event occurrence.

Remark: The timers start *ONLY* after the execution of the *ENDINIT* (end of initialization) command. Therefore, you should not set wait events before calling the *TS_DriveInitialisation* function.

Related functions: TS_CheckEvent, and all other SetEvent... functions

Associated examples: Ex04_BasicMove, Ex06_ExternalReference

3.5.8.8. TS_SetEventOnPositionRef

Prototype:

BOOL TML_EXPORT TS_SetEventOnPositionRef(LONG Position, BOOL Over, BOOL WaitEvent, BOOL EnableStop);

Arguments:

Name	I/O	Description
Position	Input	The position reference value that triggers the event expressed in TML position units.
Over		Specifies the condition tested
WaitEvent		Specifies if the function waits the event occurrence
EnableStop		Stop the motion when at event occurrence
Return	Output	TRUE if no error, FALSE if error

Description: It allows you to program an event function of position reference. Setting this event, you can detect when the position reference is over (**Over = TRUE**) or under (**Over = FALSE**) the value of parameter **Position**.

If the parameter **WaitEvent = TRUE** the function tests continuously the event status, and waits until the event occurs. There is a drawback of this situation, if the event will not occur, due to some unexpected problems. In such a case, the program hangs-up in an internal loop of the **TS_SetEventOnPositionRef** function, waiting for the event to occur.

If the parameter **WaitEvent = FALSE**, you can check if the event occurred using the **TS_CheckEvent** function. In this way, you can detect if the event does not occur and eventually exit from the test loop after a given time period.

At the event occurrence the motion is stopped if the parameter **EnableStop = TRUE**. Set **EnableStop = FALSE** if you do not want to stop the motion at event occurrence.

Related functions: TS_CheckEvent, and all other SetEvent... functions

Associated examples: Ex07_MultiAxes

3.5.8.9. TS_SetEventOnSpeedRef

Prototype:

BOOL TML_EXPORT TS_SetEventOnSpeedRef(DOUBLE Speed, BOOL Over, BOOL WaitEvent, BOOL EnableStop);

Arguments:

Name	I/O	Description
Speed	Input	The speed reference value that triggers the event expressed in TML speed units.
Over		Specifies the condition tested
WaitEvent		Specifies if the function waits the event occurrence
EnableStop		Stop the motion when at event occurrence
Return	Output	TRUE if no error, FALSE if error

Description: It allows you to program an event function of speed reference. Setting this event, you can detect when the speed reference is over (**Over = TRUE**) or under (**Over = FALSE**) the value of parameter **Speed**.

If the parameter **WaitEvent = TRUE** the function tests continuously the event status, and waits until the event occurs. There is a drawback of this situation, if the event will not occur, due to some unexpected problems. In such a case, the program hangs-up in an internal loop of the **TS_SetEventOnSpeedRef** function, waiting for the event to occur.

If the parameter **WaitEvent = FALSE**, you can check if the event occurred using the **TS_CheckEvent** function. In this way, you can detect if the event does not occur and eventually exit from the test loop after a given time period.

At the event occurrence the motion is stopped if the parameter **EnableStop = TRUE**. Set **EnableStop = FALSE** if you do not want to stop the motion at event occurrence.

Related functions: TS_CheckEvent, and all other SetEvent... functions

Associated examples: -

3.5.8.10. TS_SetEventOnTorqueRef

Prototype:

BOOL TML_EXPORT TS_SetEventOnTorqueRef(DOUBLE Torque, BOOL Over, BOOL WaitEvent, BOOL EnableStop);

Arguments:

Name	I/O	Description
Torque	Input	The torque reference value that triggers the event expressed in TML current units.
Over		Specifies the condition tested
WaitEvent		Specifies if the function waits the event occurrence
EnableStop		Stop the motion when at event occurrence
Return	Output	TRUE if no error, FALSE if error

Description: It allows you to program an event function of torque reference. Setting this event, you can detect when the torque reference is over (**Over = TRUE**) or under (**Over = FALSE**) the value of parameter **Torque**.

If the parameter **WaitEvent = TRUE** the function tests continuously the event status, and waits until the event occurs. There is a drawback of this situation, if the event will not occur, due to some unexpected problems. In such a case, the program hangs-up in an internal loop of the **TS_SetEventOnTorqueRef** function, waiting for the event to occur.

If the parameter **WaitEvent = FALSE**, you can check if the event occurred using the **TS_CheckEvent** function. In this way, you can detect if the event does not occur and eventually exit from the test loop after a given time period.

At the event occurrence the motion is stopped if the parameter **EnableStop = TRUE**. Set **EnableStop = FALSE** if you do not want to stop the motion at event occurrence.

Related functions: TS_CheckEvent, and all other SetEvent... functions

Associated examples: -

3.5.8.11. TS_SetEventOnEncoderIndex

Prototype:

BOOL TML_EXPORT TS_SetEventOnEncoderIndex(SHORT IndexType, SHORT TransitionType, BOOL WaitEvent, BOOL EnableStop);

Arguments:

Name	I/O	Description
IndexType	Input	Specifies the index monitored for transition
TransitionType		Specifies the input transition monitored
WaitEvent		Specifies if the function waits the event occurrence
EnableStop		Stop the motion when at event occurrence
Return	Output	TRUE if no error, FALSE if error

Description: It allows you to program an event function of drive/motor encoder index inputs. You can monitor the first encoder index (**IndexType = Index_1**) or the second encoder index (**IndexType = Index_2**). The event is trigger by encoder index transition low to high when **TransitionType = TRANSITION_LOW_TO_HIGH** or by the transition high to low when **TransitionType = TRANSITION_HIGH_TO_LOW**.

If the parameter **WaitEvent = TRUE** the function tests continuously the event status, and waits until the event occurs. There is a drawback of this situation, if the event will not occur, due to some unexpected problems. In such a case, the program hangs-up in an internal loop of the **TS_SetEventOnEncoderIndex** function, waiting for the event to occur.

If the parameter **WaitEvent = FALSE**, you can check if the event occurred using the **TS_CheckEvent** function. In this way, you can detect if the event does not occur and eventually exit from the test loop after a given time period.

At the event occurrence the motion is stopped if the parameter **EnableStop = TRUE**. Set **EnableStop = FALSE** if you do not want to stop the motion at event occurrence.

Related functions: TS_CheckEvent, and all other SetEvent... functions

Associated examples: -

3.5.8.12. TS_SetEventOnLimitSwitch

Prototype:

BOOL TML_EXPORT TS_SetEventOnLimitSwitch(SHORT LSWType, SHORT TransitionType, BOOL WaitEvent, BOOL EnableStop);

Arguments:

Name	I/O	Description
LSWType	Input	Specifies the limit switch monitored for transition
TransitionType		Specifies the input transition monitored
WaitEvent		Specifies if the function waits the event occurrence
EnableStop		Stop the motion when at event occurrence
Return	Output	TRUE if no error, FALSE if error

Description: It allows you to program an event function of drive/motor limit switch inputs. The event is set:

- when a transition occurs on limit switch negative if parameter **LSWType = LSW_NEGATIVE**
- when a transition occurs on limit switch positive if parameter **LSWType = LSW_POSITIVE**

You can monitor the limit switch transition low to high when **TransitionType = TRANSITION_LOW_TO_HIGH** or the transition high to low when **TransitionType = TRANSITION_HIGH_TO_LOW**.

If the parameter **WaitEvent = TRUE** the function tests continuously the event status, and waits until the event occurs. There is a drawback of this situation, if the event will not occur, due to some unexpected problems. In such a case, the program hangs-up in an internal loop of the **TS_SetEventOnLimitSwitch** function, waiting for the event to occur.

If the parameter **WaitEvent = FALSE**, you can check if the event occurred using the **TS_CheckEvent** function. In this way, you can detect if the event does not occur and eventually exit from the test loop after a given time period.

At the event occurrence the motion is stopped if the parameter **EnableStop = TRUE**. Set **EnableStop = FALSE** if you do not want to stop the motion at event occurrence.

Related functions: TS_CheckEvent and all other SetEvent... functions

Associated examples: Ex05_Homing

3.5.8.13. TS_SetEventOnDigitalInput

Prototype:

BOOL TML_EXPORT TS_SetEventOnDigitalInput(BYTE InputPort, SHORT IOState BOOL WaitEvent, BOOL EnableStop);

Arguments:

Name	I/O	Description
InputPort	Input	Specifies the digital input monitored
IOState		The input state that trigger the event
WaitEvent		Specifies if the function waits the event occurrence
EnableStop		Stop the motion when at event occurrence
Return	Output	TRUE if no error, FALSE if error

Description: It allows you to program an event function of drive/motor general purpose digital inputs. The event is set when a transition occurs on digital input **InputPort**.

You can monitor when the digital input goes high (**IOState = IO_HIGH**) or the digital input goes low (**IOState = IO_LOW**).

If the parameter **WaitEvent = TRUE** the function tests continuously the event status, and waits until the event occurs. There is a drawback of this situation, if the event will not occur, due to some unexpected problems. In such a case, the program hangs-up in an internal loop of the **TS_SetEventOnDigitalInput** function, waiting for the event to occur.

If the parameter **WaitEvent = FALSE**, you can check if the event occurred using the **TS_CheckEvent** function. In this way, you can detect if the event does not occur and eventually exit from the test loop after a given time period.

At the event occurrence the motion is stopped if the parameter **EnableStop = TRUE**. Set **EnableStop = FALSE** if you do not want to stop the motion at event occurrence.

Related functions: TS_CheckEvent and all other SetEvent... functions

Associated examples: -

3.5.8.14. TS_SetEventOnHomeInput

Prototype:

BOOL TML_EXPORT TS_SetEventOnHomeInput(SHORT IOState BOOL WaitEvent, BOOL EnableStop);

Arguments:

Name	I/O	Description
IOState	Input	Input port state (High/low)
WaitEvent		Specifies if the function waits the event occurrence
EnableStop		Stop the motion when at event occurrence
Return	Output	TRUE if no error, FALSE if error

Description: It allows you to program an event function of drive/motor general purpose digital input assigned as home input. The home input is specific for each product and based on the setup data. The event is set when a transition occurs on home input.

You can monitor when the home input goes high (**IOState = IO_HIGH**) or the home input goes low (**IOState = IO_LOW**).

If the parameter **WaitEvent = TRUE** the function tests continuously the event status, and waits until the event occurs. There is a drawback of this situation, if the event will not occur, due to some unexpected problems. In such a case, the program hangs-up in an internal loop of the **TS_SetEventOnHomeInput** function, waiting for the event to occur.

If the parameter **WaitEvent = FALSE**, you can check if the event occurred using the **TS_CheckEvent** function. In this way, you can detect if the event does not occur and eventually exit from the test loop after a given time period.

At the event occurrence the motion is stopped if the parameter **EnableStop = TRUE**. Set **EnableStop = FALSE** if you do not want to stop the motion at event occurrence.

Related functions: TS_CheckEvent and all other SetEvent... functions

Associated examples: -

3.5.9. TML jumps and function calls

3.5.9.1. TS_GOTO

Prototype:

BOOL TML_EXPORT TS_GOTO(WORD address);

Arguments:

Name	I/O	Description
address	Input	The memory address where the jump is made
Return	Output	TRUE if no error, FALSE if error

Description: The function commands the active axis to execute the TML code beginning from the **address** until TML instruction **END** is encountered. The TML code can be stored in the drive/motor non-volatile memory (EEPROM) or in the TML program memory.

Prior calling the **TS_GOTO** function you have to:

- Create a TML sequence using **EasyMotion Studio**.
- Build the TML program with the **Application | Motion | Build** menu command
- Download the TML program in the drive/motor memory with EasyMotion Studio with the **Application | Motion | Download Program**. The TML program can be downloaded with the TS_DownloadProgram function too using the out file generated by EasyMotion Studio when the TML program is built.
- Make sure that a valid instruction is found at **address**. Otherwise, unpredictable effects can occur, which can affect to correct operation of the drive/motor.

Remark:

- For more details about drive/motor memory structure see the “Memory Map” topic from EasyMotion Studio help.*
- During the execution of a local TML program on the drive, any TML command sent on-line from the PC is treated with higher priority, and will be executed before executing the local TML code.*

Related functions: TS_DownloadProgram, TS_GOTO_Label, TS_CALL, TS_CALL_Label

Associated examples: Ex08_PVT, Ex12_DistributedTasks

3.5.9.2. TS_GOTO_Label

Prototype:

BOOL TML_EXPORT TS_GOTO_Label(LPCSTR pszLabel);

Arguments:

Name	I/O	Description
pszLabel	Input	TML program label where the jump is made
Return	Output	TRUE if no error, FALSE if error

Description: The function commands the active axis to execute the TML code beginning from label **pszLabel** until TML instruction **END** is encountered. The TML code can be stored in the drive/motor non-volatile memory (EEPROM) or in the TML program memory.

The string **pszLabel** must be a valid TML label, defined in EasyMotion Studio prior generating the setup information.

Prior calling the **TS_GOTO_Label** function you have to:

- Create a TML motion sequence using **EasyMotion Studio**. The commands sequence must start with **pszLabel** label declaration.
- Build the TML program with the **Application | Motion | Build** menu command
- Download the TML program in the drive/motor memory with EasyMotion Studio with the **Application | Motion | Download Program**. The TML program can be downloaded with the **TS_DownloadProgram** function too using the out file generated by EasyMotion Studio when the TML program is built.
- Generate the setup data (*.t.zip) for TML_lib using the menu command **Application | Export to TML_lib...** to include the new **pszLabel** label

Remarks:

- For more details about drive/motor memory structure see the “Memory Map” topic from EasyMotion Studio help.*
- During the execution of a local TML program on the drive, any TML command sent on-line from the PC is treated with higher priority, and will be executed before executing the local TML code.*

Related functions: TS_DownloadProgram, TS_GOTO, TS_CALL, TS_CALL_Label, TS_CancelableCALL, TS_CancelableCALL_Label

Associated examples: -

3.5.9.3. TS_CALL

Prototype:

BOOL TML_EXPORT TS_CALL (WORD address);

Arguments:

Name	I/O	Description
address	Input	The memory address where the jump is made
Return	Output	TRUE if no error, FALSE if error

Description: The function commands the active axis to execute the TML function stored at **address**. The TML functions can be stored in the drive/motor non-volatile memory or in the TML program memory. The function execution ends when the TML instruction **RET** is encountered.

Prior calling the **TS_CALL** function you have to:

- Create at least one TML function using **EasyMotion Studio**
- Select, in the **Memory Setting** dialogue, from where you want to run the TML program: TML program or non-volatile memory.
- Build the TML program with the **Application | Motion | Build** menu command
- Download the TML program in the drive/motor memory with EasyMotion Studio with the **Application | Motion | Download Program**. The TML program can be downloaded with the **TS_DownloadProgram** function too using the out file generated by EasyMotion Studio when the TML program is built.
- Use the **Command Interpreter** to retrieve the address of the TML functions by typing “**?Function_name**”, where the **Function_name** is the function names. Repeat the above procedure for all the functions defined in EasyMotion Studio application.
- Make sure that a valid TML code subroutine begins at **address**. Otherwise, unpredictable effects can occur, which can affect to correct operation of the drive/motor.

Remarks:

- For more details about drive/motor memory structure see the “Memory Map” topic from EasyMotion Studio help.*
- During the execution of a local TML program on the drive, any TML command sent on-line from the PC is treated with higher priority, and will be executed before executing the local TML code.*

Related functions: TS_DownloadProgram, TS_CALL_Label, TS_CancelableCALL,
TS_CancelableCALL_Label, TS_GOTO, TS_GOTO_Label

Associated examples: -

3.5.9.4. TS_CALL_Label

Prototype:

BOOL TML_EXPORT TS_CALL_Label (LPCSTR pszFunctionName);

Arguments:

Name	I/O	Description
pszFunctionName	Input	Name of the TML function
Return	Output	TRUE if no error, FALSE if error

Description: The function commands the active axis to execute the TML function **pszFunctionName**. The TML functions can be stored in the drive/motor non-volatile memory or in the TML program memory. The function execution ends when the TML instruction **RET** is encountered.

The string **pszFunctionName** must be a valid TML function name, defined in EasyMotion Studio prior generating the setup information.

Prior calling the **TS_CALL_Label** function you have to:

- Create a TML function having the **pszFunctionName** name using **EasyMotion Studio**
- Build the TML program with the **Application | Motion | Build** menu command
- Download the TML program in the drive/motor memory with EasyMotion Studio with the **Application | Motion | Download Program**. The TML program can be downloaded with the **TS_DownloadProgram** function too using the out file generated by EasyMotion Studio when the TML program is built.
- Generate the setup data (*.t.zip) for TML_lib using the menu command **Application | Export to TML_lib...** to include the new **pszFunctionName**

Remark:

- For more details about drive/motor memory structure see the “Memory Map” topic from EasyMotion Studio help.*
- During the execution of a local TML program on the drive, any TML command sent on-line from the PC is treated with higher priority, and will be executed before executing the local TML code.*

Related functions: TS_DownloadProgram, TS_CALL, TS_GOTO, TS_GOTO_Label, TS_CancelableCALL, TS_CancelableCALL_Label

Associated examples: -

3.5.9.5. TS_CancelableCALL

Prototype:

BOOL TML_EXPORT TS_CancelableCALL(WORD address);

Arguments:

Name	I/O	Description
address	Input	The TML program memory address from where the TML function is stored
Return	Output	TRUE if no error, FALSE if error

Description: The function commands the active axis to execute the TML function stored at **address**. Use this command if the exit from the called TML function depends on conditions that may not be reached. In this case, using function **TS_Abort** you can terminate the function execution and return to the next instruction after the call. The TML functions can be stored in the drive/motor non-volatile memory or in the TML program memory. The execution of a function called with TS_CancelableCALL is signaled with bit SRL.8, when the function execution ends the bit is reset.

Prior calling the **TS_CancelableCALL** function you have to:

- Create at least one TML function using **EasyMotion Studio**
- Build the TML program with the **Application | Motion | Build** menu command
- Download the TML program in the drive/motor memory with EasyMotion Studio with the **Application | Motion | Download Program**. The TML program can be downloaded with the TS_DownloadProgram function too using the out file generated by EasyMotion Studio when the TML program is built.
- In the **Command Interpreter** type the command “**?Function_name**” to retrieve the memory address where the **Function_name** is stored. Repeat the procedure above for all the functions defined in EasyMotion Studio.
- Make sure that a valid TML code subroutine begins at **address**. Otherwise, unpredictable effects can occur, which can affect to correct operation of the drive/motor.

Remarks:

- Only one function at a time can be called with the TS_CancelableCALL_Label or TS_CancelableCALL functions. A cancelable call issued during the execution of a function called with TS_CancelableCALL_Label or TS_CancelableCALL is ignored. This situation is signaled with SRL.7 bit.*
- For more details about drive/motor memory structure see the “Memory Map” topic from EasyMotion Studio help.*
- During the execution of a local TML program on the drive, any TML command sent on-line from the PC is treated with higher priority, and will be executed before executing the local TML code.*

Related functions: TS_DownloadProgram, TS_CALL, TS_CALL_Label, TS_CancelableCALL_Label

Associated examples: -

3.5.9.6. TS_CancelableCALL_Label

Prototype:

BOOL TML_EXPORT TS_CancelableCALL_Label (LPCSTR pszFunctionName);

Arguments:

Name	I/O	Description
pszFunctionName	Input	Name of the TML function
Return	Output	TRUE if no error, FALSE if error

Description: The function commands the active axis to execute the TML function stored at **pszFunctionName**. Use this command if the exit from the called TML function depends on conditions that may not be reached. In this case, using function **TS_Abort** you can terminate the TML function execution and return to the next instruction after the call. The execution of a function called with **TS_CancelableCALL_Label** is signaled with bit SRL.8, when the function execution ends the bit is reset.

Prior calling the **TS_CancelableCALL_Label** function you have to:

- Create a TML function having the name **pszFunctionName** using **EasyMotion Studio**
- Build the TML program with the **Application | Motion | Build** menu command
- Download the TML program in the drive/motor memory with EasyMotion Studio with the **Application | Motion | Download Program**. The TML program can be downloaded with the **TS_DownloadProgram** function too using the out file generated by EasyMotion Studio when the TML program is built.
- Generate the setup data (*.t.zip) for TML_lib using the menu command **Application | Export to TML_lib...** to include the new **pszFunctionName**

Remarks:

- Only one function at a time can be called with the **TS_CancelableCALL_Label** or **TS_CancelableCALL** functions. A cancelable call issued during the execution of a function called with **TS_CancelableCALL_Label** or **TS_CancelableCALL** is ignored. This situation is signaled with SRL.7 bit.*
- For more details about drive/motor memory structure see the “Memory Map” topic from EasyMotion Studio help.*
- During the execution of a local TML program on the drive, any TML command sent on-line from the PC is treated with higher priority, and will be executed before executing the local TML code.*

Related functions: TS_DownloadProgram, TS_CALL, TS_CALL_Label, TS_CancelableCALL

Associated examples: Ex05_Homing, Ex12_DistributedTasks

3.5.9.7. TS_Homing

Prototype:

BOOL TML_EXPORT TS_Homing(BYTE homingNumber);

Arguments:

Name	I/O	Description
homingNumber	Input	The number of homing routine to be executed.
Return	Output	TRUE if no error, FALSE if error

Description: The function triggers the execution of a homing routine embedded in the firmware of the drive/motor. The execution of the homing routine can be aborted with the **TS_Abort** function.

The parameters of the homing routine (acceleration, velocity and home position) must be set previously with the TS_SetFixedVariable respectively TS_SetLongVariable functions. The execution of the homing routine is signaled with bit SRL.8, when the homing is completed the bit is reset.

Remark

The TS_Homing routine can be called while no TML function is triggered with the TS_CancelableCALL_Label or TS_CancelableCALL functions. A homing routine triggered during the execution of a function called with TS_CancelableCALL_Label or TS_CancelableCALL is ignored. This situation is signaled with SRL.7 bit.

Related functions: TS_CancelableCALL, TS_CancelableCALL_Label, TS_Abort

Associated examples: Ex05_Homing

3.5.9.8. TS_ABORT

Prototype:

BOOL TML_EXPORT TS_ABORT(void);

Arguments:

Name	I/O	Description
-	Input	-
Return	Output	TRUE if no error, FALSE if error

Description: The function aborts the execution of a TML function started with TS_CancelableCALL or TS_CancelableCALL_Label functions.

Related functions: TS_DownloadProgram, TS_CancelableCALL, TS_CancelableCALL_Label

Associated examples: Ex05_Homing, Ex12_DistributedTasks

3.5.9.9. TS_DownloadProgram

Prototype:

BOOL TML_EXPORT TS_DownloadProgram(LPCSTR pszOutFile, WORD& wEntryPoint);

Arguments:

Name	I/O	Description
pszOutFile	Input	The name of the COFF (*.out) file generated with EasyMotion Studio
wEntryPoint		Start address of downloaded file
Return	Output	TRUE if no error, FALSE if error

Description: The function downloads a COFF formatted file to the drive/motor, and returns the entry point of the file. Parameter **pszOutFile** specifies the name of the file to be downloaded. If the operation is successful, the function will return the entry point (start address) of the downloaded code in the **wEntryPoint** parameter. The downloaded code can be launched with **TS_GOTO** function, the argument of the TS_GOTO being the wEntryPoint address.

The COFF file (*.out) is generated from EasyMotion Studio with the **Application | Motion | Build** menu command and is saved in the application directory. You can download several such applications in different locations of the drive internal memory, and execute them according to your application status, with the **TS_GOTO** function.

Related functions: TS_GOTO

Associated examples: Ex12_DistributedTasks

3.5.9.10. TS_DownloadSwFile

Prototype:

BOOL TML_EXPORT TS_DownloadSwFile(LPCSTR pszSwFile);

Arguments:

Name	I/O	Description
pszSwFile	Input	The path to the SW file generated with EasyMotion Studio
Return	Output	TRUE if no error, FALSE if error

Description: The function downloads a software file (*.sw) to the non-volatile memory of drive/motor.

The software file (*.sw) contains the TML program and/or setup table and it is generated from EasyMotion Studio with the **Application | Create EEPROM Programmer File** menu command. You can download several TML programs in different locations of the drive internal memory, and execute them according to your application structure, with the **TS_GOTO** or **TS_CALL** functions.

Remark: *If a setup table is downloaded through a software file, it will become active once the drive is reset with TS_Reset or the power supply is cycled.*

Related functions: TS_GOTO, TS_CALL

Associated examples: –

3.5.10. IO handling

3.5.10.1. TS_SetupInput

Prototype:

BOOL TML_EXPORT TS_SetupInput(BYTE nIO);

Arguments:

Name	I/O	Description
nIO	Input	Port number to be set as input
Return	Output	TRUE if no error, FALSE if error

Description: The function sets the I/O port with number **nIO** of the drive/motor as an input port.

Use the function only if the input may also be used as an output. **Check the drive/motor user manual to find what inputs are available.** The input setup must be done only once before the first use of the input. If inputs of the drive/motor are separated from the outputs (i.e. none of the input line can be used as output) then there is no need to use the function.

Remark: *Each intelligent drive/motor has a specific number of inputs and outputs, therefore only a part of the maximum number of I/Os is used.*

Related functions: TS_GetInput, TS_SetupOutput, TS_SetOutput

Associated examples: Ex06_ExternalReference, Ex11_IOHandling, Ex12_DistributedTasks

3.5.10.2. TS_GetInput

Prototype:

BOOL TML_EXPORT TS_GetInput(BYTE nIO, BYTE& InValue);

Arguments:

Name	I/O	Description
nIO	Input	Input port number read
InValue		Pointer to the variable where the port status is stored
Return	Output	TRUE if no error, FALSE if error

Description: The function returns the status of digital input port **nIO**. When the function is executed, the variable **InValue**, where the input line status is saved, becomes:

- Zero if the input line was low
- Non-zero if the input line was high

If the IO port selected can be used as input or an output, then prior calling **TS_GetInput** you need to call **TS_SetupInput** and configure IO port as input. **Check the drive/motor user manual to find what inputs are available.**

Remark: *Each intelligent drive/motor has a specific number of inputs and outputs, therefore only a part of the maximum number of I/Os is used.*

Related functions: TS_SetupInput, TS_SetupOutput, TS_SetOutput

Associated examples: Ex06_ExternalReference, Ex11_IOHandling, Ex12_DistributedTasks

3.5.10.3. TS_SetupOutput

Prototype:

BOOL TML_EXPORT TS_SetupOutput(BYTE nIO);

Arguments:

Name	I/O	Description
nIO	Input	Port number to be set as output
Return	Output	TRUE if no error, FALSE if error

Description: The function configures the digital I/O port with number **nIO** of the drive/motor as an output port.

Use the function only if the output selected may also be used as an input. **Check the drive/motor user manual to find what outputs are available.** Do this operation only once, first time when you use the output. If the drive/motor has the outputs separated from the inputs (i.e. none of the output line can be used as an input) you don't have to use the function.

Remark: *Each intelligent drive/motor has a specific number of inputs and outputs, therefore only a part of the maximum number of I/Os is used.*

Related functions: TS_GetInput, TS_SetupOutput, TS_SetOutput

Associated examples: -

3.5.10.4. TS_SetOutput

Prototype:

BOOL TML_EXPORT TS_SetOutput(BYTE nIO, BYTE OutValue);

Arguments:

Name	I/O	Description
nIO	Input	Output port number to be written
OutValue		Output status value to be set
Return	Output	TRUE if no error, FALSE if error

Description: The function set/resets the status of digital output port **nIO** of the drive/motor.

The port status **IO_LOW** or **IO_HIGH** is set corresponding to the value of the **OutValue** parameter.

If the IO port selected may also be used as input or an output, then prior calling **TS_SetOutput** you need to call **TS_SetupOutput** and configure IO port as output.

Remark: *Each intelligent drive/motor has a specific number of inputs and outputs, therefore only a part of the maximum number of I/Os is used.*

Related functions: **TS_SetupOutput**, **TS_SetupInput**, **TS_GetInput**

Associated examples: **Ex11_IOHandling**

3.5.10.5. TS_GetHomeInput

Prototype:

BOOL TML_EXPORT TS_GetHomeInput(BYTE& InValue);

Arguments:

Name	I/O	Description
InValue	Input	Pointer to the variable where the port status is stored
Return	Output	TRUE if no error, FALSE if error

Description: The function returns the status of the general purpose digital input assigned as home input. **Check the drive/motor user manual to find the IO configuration.**

When the function is executed, the variable **InValue** where the input line status is saved becomes:

- Zero if the input line was low
- Non-zero if the input line was high

If the input port may also be used as output, then prior calling **TS_GetHomeInput** you need to call **TS_SetupInput** and configure it as input.

Related functions: TS_SetupInput, TS_GetInput

Associated examples: Ex07_MultipleAxes

3.5.10.6. TS_GetMultipleInputs

Prototype:

BOOL TML_EXPORT TS_GetMultipleInputs(PCSTR pszVarName, SHORT& Status);

Arguments:

Name	I/O	Description
pszVarName	Input	TML variable where the inputs status is saved
Status		Pointer to variable where the value of pszVarName is stored
Return	Output	TRUE if no error, FALSE if error

Description: The function reads simultaneously the status of more inputs and save their status in TML variable **pszVarName** on the drive/motor. The value of **pszVarName** is then uploaded from the drive and stored in **Status** variable.

The digital inputs are numbered from 0 to 15. The input's number represents also the position of the corresponding bit from the **pszVarName**, i.e. input number **x** has associated bit **x** from the **pszVarName**.

The **Status** bits corresponding to these inputs are set as follows: 0 if the input is low and 1 if the input is high. The other bits of the variable are set to 0.

Remark: *If one of these inputs is inverted inside the drive/motor, the corresponding bit from the variable is inverted too. Hence, these bits always show the inputs status at connectors level (0 if input is low and 1 if input is high) even when the inputs are inverted.*

The variable **pszVarName** is of type integer and must be defined with EasyMotion Studio before generating the setup data for TML_lib.

Related functions: TS_SetInput, TS_GetInput

Associated examples: Ex11_IOHandling

3.5.10.7. TS_SetMultipleOutputs2

Prototype:

BOOL TML_EXPORT TS_SetMultipleOutputs2(SHORT SelectedPorts, SHORT &Status);

Arguments:

Name	I/O	Description
SelectedPorts	Input	Mask for selecting the outputs controlled. Each bit of the parameter represents an output port.
Status		Parameter containing the outputs status to be set
Return	Output	TRUE if no error, FALSE if error

Description: The function sets simultaneously the digital outputs selected with the **SelectedPorts** mask using the value of the **Status** parameter.

Remark: *The function is designed for iPOS and iMOT families therefore the TS_SetMultipleOutputs function should be used for previous generation of Technosoft products.*

The digital outputs are numbered from 0 to 15 and they form an ordered list, for example, a product with 3 outputs will have 0, 1 and 2. The input's number represents also the position of the corresponding bit from the **SelectedPorts** mask, i.e. input number **x** has associated bit **x** from the **SelectedPorts**.

The outputs are set as follows:

- **low** if the corresponding bit from the **SelectedPorts** is 1 and the corresponding bit from **Status** variable is 0.
- **high** if it's the corresponding bit from **SelectedPorts** is 1 and the corresponding bit from SelectedPorts is 1.

Remarks: *If one of these outputs is inverted inside the drive/motor, its command is inverted. Hence, the outputs are always set at connectors level according with the bits values (low if bit is 0 and high if bit is 1) even when the outputs are inverted.*

Related functions: TS_SetupOutput, TS_SetOutput

Associated examples: –

3.5.11. Data transfer

3.5.11.1. TS_SetIntVariable

Prototype:

BOOL TML_EXPORT TS_SetIntVariable(LPCSTR pszName, SHORT value);

Arguments:

Name	I/O	Description
pszName	Input	Parameter name
value		Parameter value
Return	Output	TRUE if no error, FALSE if error

Description: The function writes the **value** in the **pszName** TML data on the active axis. The TML data (parameter, variable or user defined variable) is of type integer (16-bit).

Remarks:

1. The TML data available is configuration dependent and it is listed in the variables.cfg file from *.t.zip configuration description file.
2. The user defined variables are set with EasyMotion Studio prior generating the configuration description file (*.t.zip).

Related functions: TS_GetIntVariable, TS_SetLongVariable, TS_GetLongVariable, TS_SetFixedVariable, TS_GetFixedVariable

Associated examples: Ex03_ErrorHandling, Ex06_ExternalReference, Ex12DistributedTasks

3.5.11.2. TS_GetIntVariable

Prototype:

BOOL TML_EXPORT TS_GetIntVariable(LPCSTR pszName, short& value);

Arguments:

Name	I/O	Description
pszName	Input	Name of the TML parameter, variable or used defined variable
value		Pointer to the variable where the value is stored
Return	Output	TRUE if no error, FALSE if error

Description: The function reads the value of **pszName** TML data. The TML data (parameter, variable or user defined variable) is of type integer (16-bit). The value read is saved in the variable pointed by **value**.

Remarks:

1. *The TML data available is configuration dependent and it is included in the variables.cfg file from *.t.zip configuration description file.*
2. *The user defined variables are set with EasyMotion Studio prior generating the configuration description file (*.t.zip).*

Related functions: TS_SetIntVariable, TS_SetLongVariable, TS_SetFixedVariable, TS_GetLongVariable, TS_GetFixedVariable

Associated examples: Ex03_ErrorHandling, Ex06_ExternalReference

3.5.11.3. TS_SetLongVariable

Prototype:

BOOL TML_EXPORT TS_SetLongVariable(LPCSTR pszName, long value);

Arguments:

Name	I/O	Description
pszName	Input	Name of the parameter
value		The value to be written
Return	Output	TRUE if no error, FALSE if error

Description: The function writes the **value** in the **pszName** TML data on the active axis. The TML data (parameter, variable or user defined variable) is of type long (32-bit).

Remarks:

1. The TML data available is configuration dependent and is listed in the variables.cfg file from *.t.zip configuration description file.
2. The user defined variables are set with EasyMotion Studio prior generating the configuration description file (*.t.zip).

Related functions: TS_GetIntVariable, TS_SetIntVariable, TS_GetLongVariable, TS_SetFixedVariable, TS_GetFixedVariable

Associated examples: Ex05_Homing

3.5.11.4. TS_GetLongVariable

Prototype:

BOOL TML_EXPORT TS_GetLongVariable(LPCSTR pszName, long& value);

Arguments:

Name	I/O	Description
pszName	Input	Name of the parameter
value		Pointer to the variable where the parameter value is stored
Return	Output	TRUE if no error, FALSE if error

Description: The function reads the value of **pszName** TML data. The TML data (parameter, variable or user defined variable) is of type long (32-bit). The value read is saved in the variable pointed by **value**.

Remarks:

1. The TML data available is configuration dependent and is listed in the variables.cfg file from *.t.zip configuration description file.
2. The user defined variables are set with EasyMotion Studio prior generating the configuration description file (*.t.zip).

Related functions: TS_SetIntVariable, TS_SetLongVariable, TS_SetFixedVariable, TS_GetIntVariable, TS_GetFixedVariable

Associated examples: Ex04_BasicMove, Ex05_Homing, Ex10_EventHandling

3.5.11.5. TS_SetFixedVariable

Prototype:

BOOL TML_EXPORT TS_SetFixedVariable(LPCSTR pszName, DOUBLE value);

Arguments:

Name	I/O	Description
pszName	Input	Name of the parameter
value		The value to be written
Return	Output	TRUE if no error, FALSE if error

Description: The function converts the **value** to type fixed and writes it in the **pszName** TML data on the active axis. The TML data (parameter, variable or user defined variable) is of type fixed (16 bits integer part, 16 bits' fractional part).

Remarks:

1. The TML data available is configuration dependent and is listed in the variables.cfg file from *.t.zip configuration description file.
2. The user defined variables are set with EasyMotion Studio prior generating the configuration description file (*.t.zip).

Related functions: TS_SetIntVariable, TS_GetIntVariable, TS_SetLongVariable, TS_GetLongVariable, TS_GetFixedVariable

Associated examples: Ex04_BasicMove, Ex05_Homing

3.5.11.6. TS_GetFixedVariable

Prototype:

BOOL TML_EXPORT TS_GetFixedVariable(LPCSTR pszName, double& value);

Arguments:

Name	I/O	Description
pszName	Input	Name of the parameter
value		Pointer where the parameter value is stored
Return	Output	TRUE if no error, FALSE if error

Description: The function reads the value of **pszName** TML data from the active axis. The TML data (parameter, variable or user defined variable) is of type fixed (16 bits integer part, 16 bits fractional part). The value read is converted to double and saved in the variable pointed by **value**.

Remarks:

1. The TML data available is configuration dependent and is listed in the variables.cfg file from *.zip configuration description file.
2. The user defined variables are set with EasyMotion Studio prior generating the configuration description file (*.t.zip).

Related functions: TS_SetIntVariable, TS_SetLongVariable, TS_SetFixedVariable, TS_GetIntVariable, TS_GetLongVariable

Associated examples: –

3.5.11.7. TS_GetVariableAddress

Prototype:

BOOL TML_EXPORT TS_GetVariableAddress(LPCSTR pszName, WORD& value);

Arguments:

Name	I/O	Description
pszName	Input	Name of the parameter
value		Pointer where the parameter value is stored
Return	Output	TRUE if no error, FALSE if error

Description: The function returns the address of the **pszName** variable. The variable address is read from the configuration description file (*.t.zip) generated from EasyMotion Studio.

Related functions: TS_SetIntVariable, TS_SetLongVariable, TS_SetFixedVariable, TS_GetIntVariable, TS_GetLongVariable, TS_GetFixedVariable

Associated examples: –

3.5.11.8. TS_SetBuffer

Prototype:

BOOL TML_EXPORT TS_SetBuffer(WORD address, WORD* arrayValues, WORD nSize);

Arguments:

Name	I/O	Description
address	Input	Start address where to download the data buffer
arrayValues		Pointer to the array with data to be downloaded
nSize		The number of words to download
Return	Output	TRUE if no error, FALSE if error

Description: The function downloads a data buffer on the active axis. The parameter **arrayValues** points to the beginning of the array from where the data will be downloaded. The length of the buffer is set with parameter **nSize**. The data is stored on the drive/motor starting with **address**. The **address** can belong to non-volatile memory or TML data memory.

Remark: For details about drive/motor memory structure see the “Memory Map” topic from EasyMotion Studio on line help.

Related functions: TS_GetBuffer

Associated examples: –

3.5.11.9. TS_GetBuffer

Prototype:

BOOL TML_EXPORT TS_GetBuffer(WORD address, WORD* arrayValues, WORD nSize);

Arguments:

Name	I/O	Description
address	Input	Start address from where the data will be uploaded
arrayValues		Pointer to the array where the uploaded data will be stored
nSize		The number of words to upload
Return	Output	TRUE if no error, FALSE if error

Description: The function uploads a data buffer from the active axis. The start address of the buffer is set with parameter **address** and its length is **nSize**. The **address** can belong to drive/motor non-volatile memory or TML data memory. The parameter **arrayValues** points to the beginning of the array where the uploaded data is stored.

Remark: For details about drive/motor memory structure see the “Memory Map” topic from EasyMotion Studio on line help.

Related functions: TS_SetBuffer

Associated examples: -

3.5.12. Miscellaneous

3.5.12.1. TS_Execute

Prototype:

BOOL TML_EXPORT TS_Execute(LPCSTR pszCommands);

Arguments:

Name	I/O	Description
pszCommands	Input	String containing the TML source code to be executed.
Return	Output	TRUE if no error, FALSE if error

Description: The function executes the TML commands entered in TML source code format (as is send from the Command Interpreter, in EasyMotion Studio/EasySetUp), from a string containing that code. Use this function if you want to send a specific motion sequence, directly written in TML language.

Build a string **pszCommands** containing the source TML code and then call the **TS_Execute** function in order to compile the code and to send on-line the associated TML object commands.

If a compile error occurs, the function returns a FALSE, otherwise it returns TRUE.

Related functions: TS_ExecuteScript

Associated examples: Ex02_DriveStatus, Ex06_ExternalReference, Ex08_PVT

3.5.12.2. TS_ExecuteScript

Prototype:

BOOL TML_EXPORT TS_ExecuteScript(LPCSTR pszFileName);

Arguments:

Name	I/O	Description
pszFileName	Input	The name of the file containing the TML source code to be executed.
Return	Output	TRUE if no error, FALSE if error

Description: The function executes TML commands entered in TML source code format (as is sent from the Command Interpreter in EasyMotion Studio/EasySetUp) from a script file. Use this function if you want to send a specific motion sequence, directly written in TML language.

Define a data file **pszFileName** containing the source TML code you want to send to the drive and then call the **TS_ExecuteScript** function in order to compile the code and to send on-line the associated TML object commands.

If a compile error occurs, the function returns a FALSE, otherwise it returns TRUE.

Related functions: TS_Execute

Associated examples: -

3.5.12.3. TS_GetOutputOfExecute

Prototype:

BOOL TML_EXPORT TS_GetOutputOfExecute(LPSTR pszOutput, int nMaxChars);

Arguments:

Name	I/O	Description
pszOutput	Input	String containing the TML source code generated at the last library function call.
Return	Output	TRUE if no error, FALSE if error

Description: The function returns the TML output source code of the last previously executed TML_LIB library function call. Use this function if you want to examine the binary code of the TML commands that are generated when you call one of the functions of the TML_LIB library.

The binary code is returned in the **pszOutput** string. Set the maximum number of characters to be returned as the value of the **nMaxChars** parameter.

Related functions: TS_Execute

Associated examples: –

3.5.13. Data logger

3.5.13.1. TS_SetupLogger

Prototype:

```
BOOL TML_EXPORT TS_SetupLogger(WORD wLogBufferAddr, WORD wLogBufferLen, WORD* arrayAddresses, WORD countAddr, WORD period);
```

Arguments:

Name	I/O	Description
wLogBufferAddr	Input	The address of the logger buffer in drive/motor memory, where data will be stored during logging
wLogBufferLen		The length in words of the logger buffer
arrayAddresses		Pointer to the array containing the drive/motor memory addresses to be logged
countAddr		The number of memory addresses to be logged
period		Time interval between two consecutive data logging expressed in drive/motor time units
Return	Output	TRUE if no error, FALSE if error

Description: The function sets the parameters of the data logger on the active axis. Use this function if you want to perform data logging on the drive/motor during the motion execution and analyze it in the PC application.

Set the **wLogBufferAddress** parameter with the starting address of the drive RAM memory data buffer where a number of **wLogBufferLenlength** data points of logged data will be stored.

The addresses of TML data logged are stored in an array of length **countAddr**. Parameter **arrayAddresses** points to the beginning of the array with.

Remark: The number of data sets which can be stored will be determined as the integer part of the ratio $[\text{length} / \text{countAddr}]$.

The parameter **period** sets how often the TML data is logged. The period can have any value between 1 and 7FFF.

Remark: Be careful when using the data logger functions! Incorrect settings related to data logger buffer location and size may lead to improper operation of the drive, with unpredictable results.

Related functions: TS_StartLogger, TS_UploadLoggerResults, TS_CheckLoggerStatus

Associated examples: Ex09_Logger

3.5.13.2. TS_StartLogger

Prototype:

BOOL TML_EXPORT TS_StartLogger(WORD wLogBufferAddr, BYTE type);

Arguments:

Name	I/O	Description
wLogBufferAddr	Input	The address of the logger buffer in drive/motor memory, where data will be stored during logging
type		Sets the control loop used to trigger the data log
Return	Output	TRUE if no error, FALSE if error

Description: The function starts the data logger on the active axis. The function may be called only after the initialization of the data logger with the TS_SetupLogger function.

Use the parameter **type** to set if the data logging process must be done in the slow control loop (**type = LOGGER_SLOW**), or in the fast control loop (**type = LOGGER_FAST**).

Related functions: TS_SetupLogger, TS_UploadLoggerResults, TS_CheckLoggerStatus

Associated examples: Ex09_Logger

3.5.13.3. TS_CheckLoggerStatus

Prototype:

BOOL TML_EXPORT TS_CheckLoggerStatus(WORD& status);

Arguments:

Name	I/O	Description
wLogBufferAddr	Input	The address of the logger buffer in drive/motor memory, where data will be stored during logging
status		Number of points still remaining to capture; if it is 0, the logging is completed
Return	Output	TRUE if no error, FALSE if error

Description: The function checks the data logger status on the active axis. Use this function in order to check if the data logging process is still running, or if the data logging process was ended. The function returns the **status** parameter; whose value indicates how many points are still to be captured. If **status = 0** the data logging process is finished.

The function may be called only after the start of the logging process with the TS_StartLogger function.

Related functions: TS_SetupLogger, TS_StartLogger, TS_UploadLoggerResults

Associated examples: Ex09_Logger

3.5.13.4. TS_UploadLoggerResults

Prototype:

BOOL TML_EXPORT TS_UploadLoggerResults(WORD wLogBufferAddr, WORD* arrayValues, WORD& countValues);

Arguments:

Name	I/O	Description
wLogBufferAddr	Input	The address of the logger buffer in drive/motor memory, where data will be stored during logging
arrayValues		Pointer to the array where the uploaded data is stored on the PC
countValues		The size of arrayValues, expressed in WORDs
countValues	Output	The number of uploaded data
Return		TRUE if no error, FALSE if error

Description: The function uploads the data logged from the active axis. Use this function to upload the data stored during the data logger execution. Before calling the function, you must declare a data buffer in the PC program, starting at the **arrayValues** address, with a size equal to the **countValues** parameter.

The **TS_UploadLoggerResults** function will fill the **arrayValues** data buffer with the data transferred from the drive, and will also return the actual number of transferred data words, in the **countValues** parameter. Once the data is transferred, you can use it for data analysis, graphical representation.

Remarks:

1. Prior uploading the data logged, call function **TS_CheckLoggerStatus** to test the end of data logging.
2. The number of data sets which were stored will be determined as the integer part of the ratio $[\text{length} / \text{countAddr}]$ where **length** and **countAddr** are setup parameters defined when calling the **TS_SetupLogger** function.

The uploaded data is stored in consecutive data sets, i.e. the first set of **countAddr** words will contain the first logged point for the selected variables, and the second set of **countAddr** words will contain the second logged point for the selected variables, and so on. The following table illustrates this data structure for an example of **2 logged variables**.

Data WORD	Meaning
1	Variable 1, point 1
2	Variable 2, point 1
5	Variable 1, point 2
6	Variable 2, point 2
7	Variable 1, point 3
...	...

Related functions: TS_SetupLogger, TS_StartLogger, TS_CheckLoggerStatus

Associated examples: Ex09_Logger

1. Examples

This chapter presents a collection of applications which use the functions of the **TML_LIB** library to provide you a first, basic insight about using the **TML_LIB** library to implement your motion control applications.

Note that most of these examples contain function calls to TML_LIB functions, and are based on the hypothesis that the setup data is already downloaded into the non-volatile memory of the drive so that you'll directly start sending motion commands from the PC to the drive.

The examples are built for the iPOS family of drives.

Remarks:

1. *Prior running the examples, generate the setup data and modify the examples to accommodate the IO configuration of your drive/motor. Also, the examples are switching between position control and speed control, therefore during the Drive Setup phase enable all 3 control loops, current, speed and position, and tune the controllers.*
2. *The examples for Microsoft Windows platform, require the Working Directory to be set to the **examples** folder of the TML_lib, by default C:\Program Files\Technosoft\TML_LIB\examples\. For details about setting the Working Directory read the development environment online help.*
3. *For projects developed under Delphi and C#, the TML_lib.dll and tmlcomm.dll must be present in the Output Directory of the project.*

Most TML_LIB functions return a Boolean **TRUE** if the function executed correctly, and a **FALSE** if any error occurred (incorrect parameters, failed operation at the PC level). Normally, you must check after each function call if there was an error or not. In case of error use function **TS_GetLastTextError** to obtain a description of the error occurred.

4.1. Start Up

The example details the steps required to build the host application based on TML_lib. Before starting to build the host application you must setup the drive/motor accordingly with your application. The drive/motor setup is done using EasySetUp/EasyMotion Studio. When the setup is finished the host application must include the basic functionality:

4. Open communication channel using the **TS_OpenChannel**. The TML_lib library supports RS232, CAN and Ethernet communication.
5. Load the setup data for each axis controlled from the host with **TS_LoadSetup** function. The setup data must be generated from EasySetUp/EasyMotion Studio. The setup information is included in a *.t.zip file and is used by the library to validate your commands; it doesn't contain the setup data downloaded in the drive non-volatile memory.
6. Associate each axis with the setup information using the **TS_SetupAxis**. An axis is defined by its Axis ID and the setup information. The Axis ID is assigned to a drive/motor in the Drive setup dialog.
7. Select the destination of the commands sent from the host. For single axis applications the selection of the destination must be done once, after the axis setup. In multi-axis applications the **TS_SelectAxis** must be called every time the messages' destination is changed.
8. Call **TS_DriveInitialization** function to check the integrity of the setup data downloaded in the non-volatile memory of the drive. The setup data validation is performed automatically by the drive when it is powered. The **TS_DriveInitialization** function also signals the end of the drive initialization.
9. Enable the power stage of the drive with **TS_Power** function.
10. Send the motion commands required by your application using the functions included in the TML_lib.

11. When the application is finished, disable the power stage of the drive by calling the **TS_Power** function. Close the communication channels using the **TS_CloseChannel** function. To close the current communication channel pass -1 to the TS_CloseChannel.

4.2. Drive status

The drive's/motor's key information is grouped in 2 status registers: Status Register (32-bit) and Motion Error Register (16-bit). The host can monitor the status of the drive/motor by:

- Requesting periodically the values of the status registers (SRL, SRH and MER) using the TS_ReadStatus function.
- Enable the drive to send automatically its status. The message transmission is triggered by conditions which change the status registers or the error register. The host selects the bits from the registers that will trigger a message, via 3 masks one for each register: SRL_MASK, SRH_MASK and MER_MASK.

The host analyze the message content in the user callback function, called automatically by the TML_lib when the host receives a message from the host.

4.3. Error handling

When an error occurs, the drive enters in the fault status. In the fault status the power stage is disabled, the MER register signals the errors occurred and bit 15 from the SRH is set high to signal the fault state.

The normal operation of the drive can be restored by:

- Calling the TS_ResetFault function. The function call must be followed by the TS_Power in order to enable the power stage of the drive. If the error persists then the drive will return to the fault state.
- Resetting the drive using the TS_Reset function when the application depends on special routines to be executed, i.e. homing routines. After a reset command the communication with the drive is disabled until the reset routines end. Hence the host application should add a delay before restoring the communication with the drive/motor.

After the reset the drive communicates using the default baudrate, i.e. 9600bps for serial communication and 500kbps for CAN communication. If the host application was using a different baudrate before the reset, then use MSK_SetBaudRate function to first set baudrate to the default values and then set it to the initial value.

4.4. Basic move

Technosoft drives/motors can execute a broad range of motion profiles. The example covers only the basic motion profiles like


- positioning with trapezoidal speed profile
- positioning with S-curve speed profiles
- velocity profiles

Remark: The example requires all control loops to be enabled. The control scheme is selected in the **Drive Setup** dialog. To enable all control loops first select *Position* in the Control mode, then open the **Advanced** dialog. In the Advanced dialog select the **Close position, speed and current loop** option and press the OK button.

4.5. Homing

The homing procedure is based on the existence of a specific motion sequence containing the TML code needed to implement the homing, on the drive.

The search for the home position can be done in various ways. In order to offer maximum flexibility, Technosoft provides a set of predefined homing methods that can be used as default or can be customized according to the application needs. The predefined homing methods are displayed in the Homing Modes branch from the EasyMotion Studio project tree.



The homing procedure is a TML function that can be triggered using its name or its number. The homing routine can be triggered with its number by using the **TS_Homing(xx)** function, where "xx" = 1...40 and represents the desired homing type. The name of the homing routine can be used only after it is set as **User defined** and it is downloaded with EasyMotion Studio to the non volatile memory of the drive. The homing routine can be triggered by name with the **TS_CancelableCALL_Label("Homexx")**.

The homing routine execution can be aborted at any moment with the **TS_ABORT** function. Hence, if the homing procedure can't find the home signal then you have the option to cancel it. The **TS_Stop** function should be called to stop the motion after canceling the execution of the homing routine.

Bit 8 from **Status Register Low** part is set during the execution of a homing procedure. Hence the status of the homing routine can be easily monitored by checking periodically bit 8 from **SRL**. As long as a homing sequence is in execution, you cannot start another one. If the **TS_CancelableCALL_Label** or **TS_Homing** functions are called to

trigger a homing routine while another one is executing then the new homing routine will not be triggered and a warning is generated by setting bit 7 from **SRL**.

The homing methods embedded in the drive/motor can be customized and used in the TML_LIB environment by performing the following steps:

- Open the EasyMotion Studio project for the respective axis or create a new project for the used configuration.
- Select the **Homing Modes** branch and chose the homing method that will be customized.
- Set the respective homing method as **Used defined** and modify it as required.
- Download the customized homing procedure with the **Application | Motion | Download Program** menu command.
- Generate the configuration setup for TML_LIB with the **Application | Export to TML_LIB** menu command.

Remarks:

1. *The homing parameters must be set before calling the TS_CancelableCALL_Label or TS_Homing functions otherwise the homing behavior will be undefined.*
2. *The homing parameters can be set with: TS_SetFixedVariable, TS_SetLongVariable and TS_SetIntVariable, depending on the type of the parameters.*

Parameter	Type	Address	Description
CACC	Fixed	0x02A2	Acceleration/deceleration rate for the position / speed profiles during homing.
CDEC	Fixed	0x0858	Deceleration rate for quick stop when a limit switch is reached.
CSPD	Fixed	0x02A0	High/normal speed for the position / speed profiles done during homing.
HOMESPD	Fixed	0x0994	Low speed for the final approach towards the home position.
HOMEPOS	Long	0x0992	New home position set at the end of the homing procedure.
HOMECRT	Int	0x08AC	Current threshold for homing routines based on mechanical limit.
HOMETIME	Int	0x08AD	Time window for homing routines based on mechanical limit.

3. *The parameter values must be set in drive internal units. For more information, please check the “**Internal units and Scaling factors**” section.*
4. *The **HOMECRT** and **HOMETIME** parameters are used only by the homing routines based on **mechanical limit** (hardstop).*
5. *The value of **HOMECRT** must be smaller than the current limit set in Drive Setup dialog to ensure correct execution of the homing routine.*
*If **HOMECRT** is greater than the current limit then the homing routine will not be able to detect the mechanical limit and the motor will keep pushing against it. The homing routine will not be completed.*
*If the value of **HOMECRT** is too small, then the homing routine may detect a false mechanical limit condition.*

4.6. External reference

Technosoft drives/motors are capable to use external reference signals provided by other devices. There are 3 types of external references:

- Analogue – read by the drive/motor via a dedicated analogue input (10-bit resolution)

- Digital – computed by the drive/motor from:
 - Pulse & direction signals
 - Quadrature signals like A, B signals of an incremental encoder
- Online – received online via a communication channel from a host and saved in a dedicated TML variable

The example is split in 4 parts, one for each type of external reference and in the fourth the analog reference is used to compute a speed command.

4.7. Multi-axis

In multi-axis mode one of the drives acts as master providing the reference for the other drives. The drives/motors can operate in electronic gearing or electronic camming.

When set as **master**, in electronic gearing, the drive/motor sends its position via a multi-axis communication channel, like the CAN bus. When set as **slave**, the drive/motor follows the master position with a programmable gear ratio.

In electronic camming the drive/motor set as **master**, sends its position via a multi-axis communication channel, and the drive/motor set as **slave** executes a cam profile function of the master position. The cam profile is defined by a cam table – a set of (X, Y) points, where X is cam table input i.e. the master position and Y is the cam table output i.e. the corresponding slave position. Between the points the drive/motor performs a linear interpolation.

The first part of the example presents the steps required to set 2 drives in electronic gearing mode, one as master and the other as slave. The second part of the example illustrates the use of the cam table files and the phases required to set the electronic camming mode.

4.8. PVT - multithreading

In the PVT motion mode the built-in reference generator computes a positioning path using a series of points. Each point specifies the desired **Position**, **Velocity** and **Time**, i.e. contains a **PVT** data. Between the PVT points the reference generator performs a 3rd order interpolation.

The example walks through the steps required to set the PVT mode and use separates threads for each axis. The drives follow a complex path composed from lines and circles. The main thread computes the PVT points, then creates a thread for each axis. In the threads the host sends the PVT points and handles the PVT status received from the drives. When the trajectory is completed each thread closes the communication channel.

4.9. Logger

The **Data Logger** is an advanced graphical analysis tool, allowing you to do data acquisitions on any variable of your drive / motor and plot the results.

Please note that the uploaded data is stored alternatively. Also you have to take in consideration the type of the data received (integer, long, fixed) especially for fixed (16-bit integer part. 16-bit fixed part) variables which must be converted from a 32-bit integer to float.

4.10. Event handling

An event is a programmable condition, which once set, is monitored for occurrence. Only a single event can be programmed at a time. You can do the following actions in relation with an event:

- Change the motion mode and/or the motion parameters, when the event occurs
- Stop the motion when the event occurs
- Wait for the programmed event to occur

The host application can:

- tests continuously the event status, and waits until the event occurs. There is a drawback of this situation, if the event will not occur, due to some unexpected conditions the program hangs-up in an internal loop waiting for the event to occur.
- Check periodically if the event occurred using the `TS_CheckEvent` function. In this way, you can detect if the event does not occur and eventually exit from the test loop after a given time period.

4.11. I/O handling

Each Technosoft drive/motor has a specific number of digital inputs and outputs. Some drives/motors include I/O lines that may be used either as inputs or as outputs. In these cases, before using these lines, you need to specify how you want to use them by calling the **TS_SetupInput** and **TS_SetupOutput** functions.

Remarks:

- *Read carefully the drive/motor user manual to find which I/O lines are available.*
- *You need to set an I/O line as input or output, only once, after power on*

The I/O lines can be controlled individually or simultaneously; the example covers both cases.

4.12. Distributed tasks

The embedded intelligence of the drive/motor allows you to distribute the application between the host and the drives/motors in complex multi-axis applications. Thus, the host, instead of sending commands for each step of an axis movement, it can simply trigger the execution of a TML function, stored on the drive, and monitor the drive status. This approach allows the host to focus on system functionality, leaving the drive to handle the motion tasks.

The steps for building a distributed application are:

1. implement the TML functions using EasyMotion Studio
2. download the TML code on the drive:
 - a. from EasyMotion Studio in the non-volatile memory
 - b. from the host application using the executable file (COFF) resulted after compiling the TML code. The COFF file can be downloaded with `TS_DownloadProgram` function.
 - c. from the host application using the software file (sw) generated from EasyMotion Studio.
3. export the setup data for TML_lib. The setup data generated for TML_lib will contain the name of the TML functions created in EasyMotion Studio.
4. trigger, from the host, the execution of the TML functions by calling the `TS_CancelableCALL_Label` function.
5. monitor the function execution status by requesting periodically the status registers or by enabling the drive to send its status automatically.

The example shows 2 possible ways of executing TML code developed using the EasyMotion Studio.

Appendix A – CAM files format

The cam tables are arrays of X, Y points, where X is the cam input i.e. the master position and Y is the cam output i.e. the slave position. The X points are expressed in the master internal position units, while the Y points are expressed in the slave internal position units. Both X and Y points 32-bit long integer values. The X points must be positive (including 0) and equally spaced at: 1, 2, 4, 8, 16, 32, 64 or 128 i.e. having the interpolation step a power of 2 between 0 and 7. The maximum number of points for one cam table is 8192.

As cam table X points are equally spaced, they are completely defined by two data: The Master start value or the first X point and the Interpolation step providing the distance between the X points. This offers the possibility to minimize the cam size, which is saved in the drive/motor in the following format:

- 1st word (1 word = 16-bit data)
- Bits 15-13 - the power of 2 of the interpolation step. For example, if these bits have the binary value 010 (2), the interpolation step is $2^2 = 4$, hence the master X values are spaced from 4 to 4: 0, 4, 8, 12, etc.
- Bits 12-0 - the length -1 of the table. The length represents the number of points
- 2nd and 3rd words: The Master start value (long), expressed in master position units. 2nd word contains the low part, 3rd word the high part
- 4th and 5th words: Reserved. Must be set to 0
- Next pairs of 2 words: the slave Y positions (long), expressed in position units. The 1st word from the pair contains the low part and the 2nd word from the pair the high part

Last word: the cam table checksum, representing the sum modulo 65536 of all the cam table data except the checksum word itself.

Appendix B – Package contents of TML_LIB for Microsoft Windows

Details the package contents of TML_LIB for Microsoft Windows.

Directory	Files	Description
Root directory Default c:\Program Files (x86)\Technosoft\TML_LIB\	P091.040.UM.PDF	The PDF file of the TML_LIB user manual (this document)
	ChangeLog.txt	Contains the release information
lib	TML_lib.dll	TML_LIB DLL library file
	tmlcomm.dll	TML_lib communication module file
	TML_lib.lib	Import library of TML_LIB
	tmlcomm.lib	Import library of tmlcomm
	TML_lib-borlandc.lib	import library variant of TML_LIB for Borland C++ linker projects
	tmlcomm-borlandc.lib	import library of tmlcomm for Borland C++ projects
lib-multithread	TML_lib.DLL	DLL variant with multithread capabilities
	tmlcomm.DLL	communication module variant with multithread capabilities
	TML_lib.lib	lib file for TML_lib variant with multithread capabilities
	tmlcomm.lib	lib file for tmlcomm.dll with multithread
	TML_lib-borlandc.lib	import library of TML_lib variant with multithread capabilities for Borland C++
	tmlcomm-borlandc.lib	import library of tmlcomm.dll with multithread for Borland C++
include	TML_lib.h	Header file for VC++ applications
	TML_lib.bas	Header file for VB applications
	TML_lib.pas	Header file for Pascal applications
	TML_lib.cs	TML_lib classes for C#
examples	Ex05_Homing.t.zip	Setup data used in example Ex05_Homing
	Ex12_cmd_variable.t.zip	Setup data used in example Ex12_DistributedTasks
	Ex12_cmd_variable.out	Executable file (COFF) used in example Ex12_DistributedTasks
	Ex12_COFF2RAM.t.zip	Setup data used in example Ex12_DistributedTasks
	Ex12_COFF2RAM.out	Executable file (COFF) used in example Ex12_DistributedTasks
	Exx_setup_file_ID1.t.zip	Setup data used in the rest of the examples
	Exx_setup_file_ID2.t.zip	Setup data used in example Ex07_MultiAxes
	ExampleCam.cam	Cam table generated from EasyMotion Studio. The cam table is used in example Ex07_MultiAxes
	ExampleCam.cam	Cam table in text format. Can be imported in EasyMotion Studio to generate the *.cam file
	TML_lib_examples	Archive of TML project used for examples Ex05_Homing and Ex12_DistributedTasks.

examples\Cdemo ²	C projects with all the examples	Complete projects for Visual C++ and Borland C++ Builder implementing the examples from Chapter 4.
examples\C#demo ¹	C# projects with all the examples	Complete projects for C# implementing the examples from Chapter 4.
examples\VBdemo ³	VB project and all examples in Visual Basic	A complete Visual Basic project implementing equivalent examples of the examples presented Chapter 4. The example requires the single thread variant of the TML_lib.
examples\DELPHIdemo ²	Delphi project and all examples in Pascal	A complete Delphi project implementing equivalent examples of those presented in Chapter 4.
examples\VCvirtRS232	Visual C project of the virtual serial driver	A complete Visual C project of a communication driver example for the virtual serial communication

² The examples are available for 32-bit and 64-bit versions of the TML_lib for Microsoft Windows platforms

³ The examples are available only for the 32-bit version of the TML_lib for Microsoft Windows platforms

Appendix C – Package contents of TML_LIB for Linux

Details the package contents for TML_LIB for Linux.

Directory	Files	Description
/usr/include	TML_lib.h	Header file for TML_lib library
	tmlcomm.h	Header file for tmlcomm library
/usr/lib	libTML_lib.so	TML_LIB library file
	libtmlcomm.so	TML communication library file
/usr/share/doc/TML_lib/	Changelog	Contains the release information
	Check-for-updates_linux_x86	Web page which facilitates the update of the library via Internet
	License	License agreement for TML_LIB
	P091.040.UM.xxxx.PDF	The PDF file of the TML_LIB user manual (this document)
/usr/share/doc/TML_lib/examples/src/	C examples	Complete C projects implementing the examples from Chapter 4.
/usr/share/doc/TML_lib/examples/TML_LIB_User/	Ex05_Homing.t.zip	Setup data used in example Ex05_Homing
	Ex12_cmd_variable.t.zip	Setup data used in example Ex12_DistributedTasks
	Ex12_cmd_variable.out	Executable file (COFF) used in example Ex12_DistributedTasks
	Ex12_COFF2RAM.t.zip	Setup data used in example Ex12_DistributedTasks
	Ex12_COFF2RAM.out	Executable file (COFF) used in example Ex12_DistributedTasks
	Exx_setup_file_ID1.t.zip	Setup data used in the rest of the examples
	Exx_setup_file_ID2.t.zip	Setup data used in example Ex07_MultiAxes
	ExampleCam.cam	Cam table generated from EasyMotion Studio. The cam table is used in example Ex07_MultiAxes
	ExampleCam.cam	Cam table in text format. Can be imported in EasyMotion Studio to generate the *.cam file
	TML_lib_examples	Archive of TML project used for examples Ex05_Homing and Ex12_DistributedTasks.
/usr/share/doc/TML_lib/peak-linux-drivers-patches	Patches for Peak System CAN-bus devices drivers versions 3.17 and 4.3	

Appendix D – TML_Lib.h file

The TML_LIB.h file is the header file containing the prototypes of all TML_LIB functions, as well as all the constants needed to call functions of the library.

This file must be included in any C file that refers functions from TML_LIB. Use the TML_LIB.lib and the TML_LIB.dll to build the corresponding executable file.

```
#ifndef __TML_LIB_H__
#define __TML_LIB_H__

#if defined(WINDOWS) || defined(WIN32)
#   ifdef _TMDLL
#       define TML_EXPORT __declspec(dllexport) __stdcall
#   else
#       define TML_EXPORT __declspec(dllimport) __stdcall
#   endif
#else
#   define TML_EXPORT
#endif

#undef BYTE
#undef WORD
#undef DWORD
#undef BOOL

#if defined(WINDOWS) || defined(WIN32)
    typedef unsigned char BYTE;
    typedef unsigned short WORD;
    typedef unsigned long DWORD;
#else
    typedef u_int8_t BYTE;
    typedef u_int16_t WORD;
    typedef u_int32_t DWORD;
#endif

typedef int BOOL;
#ifndef FALSE
#define FALSE 0
#endif
#ifndef TRUE
#define TRUE 1
#endif

typedef const char* LPCSTR;
typedef char* LPSTR;
```

```

//supported CAN protocols
#define PROTOCOL_TMLCAN          0x00 /*use TMLCAN protocol (default, 29-bit
identifiers)*/
#define PROTOCOL_TECHNOCAN      0x80 /* use TechnoCAN protocol
(11-bit identifiers)*/
#define PROTOCOL_MASK           0x80 /*this bits are used for
specifying CAN protocol through nChannelType param of MSK_OpenComm function*/

/***** supported CAN devices *****/
CHANNEL_IXXAT_CAN - see http://www.ixxat.com
CHANNEL_SYS_TEC_USBCAN - see www.systec-electronic.com
CHANNEL_ESD_CAN - see http://www.esd-electronics.com
CHANNEL_PEAK_SYS_PCAN_* - see http://www.peak-system.com
CHANNEL_LAWICEL_USBCAN - see http://www.canusb.com
*****/

/*Constants used as values for 'OpenChannel' parameters*/
#define CHANNEL_RS232            0
#define CHANNEL_IXXAT_CAN        2
#define CHANNEL_SYS_TEC_USBCAN   3
#define CHANNEL_PEAK_SYS_PCAN_PCI 4
#define CHANNEL_ESD_CAN          5
#define CHANNEL_PEAK_SYS_PCAN_ISA 6
#define CHANNEL_PEAK_SYS_PCAN_PC104 CHANNEL_PEAK_SYS_PCAN_ISA /* Same with
PCAN_ISA*/
#define CHANNEL_PEAK_SYS_PCAN_USB 7
#define CHANNEL_PEAK_SYS_PCAN_DONGLE 8
#define CHANNEL_LAWICEL_USBCAN    9
#define CHANNEL_KVASER_USBCAN     10
#define CHANNEL_SOCKET_CAN        11
#define CHANNEL_VIRTUAL_SERIAL    15
#define CHANNEL_XPORT_IP          16
#define CHANNEL_ETHERNET_CAN      17

/*Constant used for host ID*/
#define HOST_ID                  1

/*Constants used as values for 'Logger' parameters*/
#define LOGGER_SLOW               1
#define LOGGER_FAST               2

/*Constants used as values for 'MoveMoment' parameters*/
#define UPDATE_NONE               -1
#define UPDATE_ON_EVENT           0
#define UPDATE_IMMEDIATE          1

```

```

/*Constants used for 'ReferenceType' parameters*/
#define REFERENCE_POSITION          0
#define REFERENCE_SPEED              1
#define REFERENCE_TORQUE             2
#define REFERENCE_VOLTAGE           3

/*Constants used for EnableSuperposition*/
#define SUPERPOS_DISABLE            -1
#define SUPERPOS_NONE               0
#define SUPERPOS_ENABLE             1

/*Constants used for PositionType*/
#define ABSOLUTE_POSITION           0
#define RELATIVE_POSITION           1

/*Constants used for EnableSlave*/
#define SLAVE_NONE                  0
#define SLAVE_COMMUNICATION_CHANNEL 1
#define SLAVE_2ND_ENCODER           2

/*Constants used for ReferenceBase*/
#define FROM_MEASURE                0
#define FROM_REFERENCE              1

/*Constants used for DecelerationType*/
#define S_CURVE_SPEED_PROFILE        0
#define TRAPEZOIDAL_SPEED_PROFILE    1

/*Constants used for IOState*/
#define IO_HIGH                      1
#define IO_LOW                       0

/*Constants used for TransitionType*/
#define TRANSITION_HIGH_TO_LOW       -1
#define TRANSITION_DISABLE           0
#define TRANSITION_LOW_TO_HIGH       1

/*Constants used for IndexType*/
#define INDEX_1                      1
#define INDEX_2                      2

/*Constants used for LSWType*/
#define LSW_NEGATIVE                 -1

```



```

#define LSW_POSITIVE          1

/*Constants used for TS_Power; to activate/deactivate the PWM commands*/
#define POWER_ON              1
#define POWER_OFF             0

/*Constants used as inputs parameters of the I/O functions*/
#define INPUT_0               0
#define INPUT_1               1
#define INPUT_2               2
#define INPUT_3               3
#define INPUT_4               4
#define INPUT_5               5
#define INPUT_6               6
#define INPUT_7               7
#define INPUT_8               8
#define INPUT_9               9
#define INPUT_10              10
#define INPUT_11              11
#define INPUT_12              12
#define INPUT_13              13
#define INPUT_14              14
#define INPUT_15              15
#define INPUT_16              16
#define INPUT_17              17
#define INPUT_18              18
#define INPUT_19              19
#define INPUT_20              20
#define INPUT_21              21
#define INPUT_22              22
#define INPUT_23              23
#define INPUT_24              24
#define INPUT_25              25
#define INPUT_26              26
#define INPUT_27              27
#define INPUT_28              28
#define INPUT_29              29
#define INPUT_30              30
#define INPUT_31              31
#define INPUT_32              32
#define INPUT_33              33
#define INPUT_34              34
#define INPUT_35              35
#define INPUT_36              36
#define INPUT_37              37

```

```

#define INPUT_38      38
#define INPUT_39      39

#define OUTPUT_0       0
#define OUTPUT_1       1
#define OUTPUT_2       2
#define OUTPUT_3       3
#define OUTPUT_4       4
#define OUTPUT_5       5
#define OUTPUT_6       6
#define OUTPUT_7       7
#define OUTPUT_8       8
#define OUTPUT_9       9
#define OUTPUT_10      10
#define OUTPUT_11      11
#define OUTPUT_12      12
#define OUTPUT_13      13
#define OUTPUT_14      14
#define OUTPUT_15      15
#define OUTPUT_16      16
#define OUTPUT_17      17
#define OUTPUT_18      18
#define OUTPUT_19      19
#define OUTPUT_20      20
#define OUTPUT_21      21
#define OUTPUT_22      22
#define OUTPUT_23      23
#define OUTPUT_24      24
#define OUTPUT_25      25
#define OUTPUT_26      26
#define OUTPUT_27      27
#define OUTPUT_28      28
#define OUTPUT_29      29
#define OUTPUT_30      30
#define OUTPUT_31      31
#define OUTPUT_32      32
#define OUTPUT_33      33
#define OUTPUT_34      34
#define OUTPUT_35      35
#define OUTPUT_36      36
#define OUTPUT_37      37
#define OUTPUT_38      38
#define OUTPUT_39      39

```

```

/*Constants used for the register for function TS_ReadStatus*/

```

```

#define REG_MCR          0
#define REG_MSR          1
#define REG_ISR          2
#define REG_SRL          3
#define REG_SRH          4
#define REG_MER          5
#define REG_DER          6
#define REG_DER2         7

/*Constants used to select or set the group*/
#define GROUP_0          0
#define GROUP_1          1
#define GROUP_2          2
#define GROUP_3          3
#define GROUP_4          4
#define GROUP_5          5
#define GROUP_6          6
#define GROUP_7          7
#define GROUP_8          8

/*Special parameter values*/
#define FULL_RANGE        0
#define NO_VARIATION      0

/*****
Callback function used by client application for handling unsolicited
messages which this driver receives in unexpected places
*****/
#ifdef (WINDOWS) || defined(WIN32)
    typedef void (__stdcall *pfnCallbackRecvDriveMsg)(WORD wAxisID, WORD wAddress,
long Value);
#else
    typedef void (*pfnCallbackRecvDriveMsg)(WORD wAxisID, WORD wAddress, long
Value);
#endif

#ifdef __cplusplus
extern "C" {
#endif

LPCSTR TML_EXPORT TS_GetLastErrorText(void);
/*****
Function: Returns a text related to the last occurred error when one of the
library functions
was called.
*****/

```

Input arguments:

-

Output arguments:

return: A text related to the last occurred error

*****/

/*****/

/*****Parametrization*****/

/*****/

int TML_EXPORT TS_LoadSetup(LPCSTR setupPath);

Function: Load setup information from a zip archive or a directory containing setup.cfg and variables.cfg files.

Input arguments:

setupPath: path to the zip archive or directory that contains setup.cfg and variables.cfg of the given setup

Output arguments:

return: >=0 index of the loaded setup; -1 if error

*****/

/*****/

/***** Communication channels *****/

/*****/

int TML_EXPORT TS_OpenChannel(LPCSTR pszDevName, BYTE btType, BYTE nHostID, DWORD baudrate);

Function: Open a communication channel.

Input arguments:

pszDevName: communication device name

name ("1","2","3"... -> "COM1", "COM2", "COM3"...)

CHANNEL_IXXAT_CAN: "1" .. "4"

CHANNEL_SYS_TEC_USBCAN and CHANNEL_ESD_CAN: "0" .. "10"

CHANNEL_PEAK_SYS_PCAN_PCI: "1" or "2"

CHANNEL_LAWICEL_USBCAN: "" for the first device found or the serial number of the device

CHANNEL_XPORT_IP: "IP" or "hostname"

btType: channel type (CHANNEL_) with an optional protocol (PROTOCOL_*, default is PROTOCOL_TMLCAN)*

nHostID: Is the address of your PC computer. A value between 1 and 255

For RS232: axis ID of the drive connected to the PC serial port (usually 255)

For XPORT: "IP:port"

```

        BaudRate:      Baud rate
                        serial ports: 9600, 19200, 38400, 56000 or 115200
                        CAN devices: 125000, 250000, 500000, 1000000

Output arguments:
        return:        channel's file descriptor or -1 if error
*****/

BOOL TML_EXPORT TS_SelectChannel(int fd);
/*****
Function: Select active communication channel. If you use only one channel there
is no need to call this function.

Input arguments:
        fd: channel file descriptor (-1 means selected communication channel)

Output arguments:
        return:        TRUE if no error; FALSE if error
*****/

#ifdef __cplusplus
void TML_EXPORT TS_CloseChannel(int fd = -1);
#else
void TML_EXPORT TS_CloseChannel(int fd);
#endif
/*****
Function: Close the communication channel.

Input arguments:
        fd: channel file descriptor (-1 means selected communication channel)
*****/

/*****/
/*****/Drive Administration *****/
/*****/

BOOL TML_EXPORT TS_SetupAxis(BYTE axisID, int idxSetup);
/*****
Function: Select setup configuration for the drive with axis ID.

Input arguments:
        axisID:        axis ID. It must be a value between 1 and 255;
        idxSetup:      Index of previously loaded setup,

Output arguments:
        return:        TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_SelectAxis(BYTE axisID);
/*****
Function: Selects the active axis.

```

```

    Input arguments:
        axisID:          The ID of the axis to become the active one. It must be a
value between 1 and 255;
                                defined at TS_OpenChannel function call.

    Output arguments:
        return:          TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_SetupGroup(BYTE groupID, int idxSetup);
/*****
    Function: Select setup configuration for the drives within group.
    Input arguments:
        groupID:          group ID. It must be a value between 1 and 8;
        idxSetup:         Index of previously loaded setup,
    Output arguments:
        return:          TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_SelectGroup(BYTE groupID);
/*****
    Function: Selects the active group.
    Input arguments:
        groupID:          The ID of the group of axes to become the active
ones. It must be a value
                                between 1 and 8.
    Output arguments:
        return:          TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_SetupBroadcast(int idxSetup);
/*****
    Function: Select setup configuration for all drives on the active channel.
    Input arguments:
        idxSetup:         Index of previously loaded setup,
    Output arguments:
        return:          TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_SelectBroadcast(void);
/*****
    Function: Selects all axis on the active channel.
        return:          TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_Reset(void);

```

```

/***** Function:
Resets selected drives.
    return:      TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_ResetFault(void);
/*****
    Function: This function clears most of the errors bits from Motion Error Register
(MER).
    return:      TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_Power(BOOL Enable);
/*****
    Function: Controls the power stage (ON/OFF).
    Input arguments:
        Enable:      TRUE -> Power ON the drive; FALSE -> Power OFF the drive
    Output arguments:
        return:      TRUE if no error; FALSE if error
*****/

#ifdef __cplusplus
BOOL TML_EXPORT TS_ReadStatus(short SelIndex, WORD& Status);
#else
BOOL TML_EXPORT TS_ReadStatus(short SelIndex, WORD* Status);
#endif
/***** Function:
Returns drive status information.
    Input arguments:
        SelIndex:
            REG_MCR -> read Motion Control Register
            REG_MSR -> read Motion Status Register
            REG_ISR -> read Interrupt Status Register
            REG_SRL -> read Status Register Low
            REG_SRH -> read Status Register High
            REG_MER -> read Motion Error Register
            REG_DER -> read Detailed Error Register
    Output arguments:
        Status: drive status information (value of the selected register)
        return:      TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_Save(void);
/*****
    Function: Saves actual values of all the parameters from the drive/motor working
memory into

```

the EEPROM setup table.

Output arguments:

return: TRUE if no error; FALSE if error

*****/

BOOL TML_EXPORT **TS_UpdateImmediate**(void);

Function: Update the motion mode immediately.

Output arguments:

return: TRUE if no error; FALSE if error

*****/

BOOL TML_EXPORT **TS_UpdateOnEvent**(void);

Function: Update the motion mode on next event occurrence.

Output arguments:

return: TRUE if no error; FALSE if error

*****/

BOOL TML_EXPORT **TS_SetPosition**(long PosValue);

Function: Set actual position value.

Input arguments:

PosValue: Value at which the position is set

Output arguments:

return: TRUE if no error; FALSE if error

*****/

BOOL TML_EXPORT **TS_SetCurrent**(short CrtValue);

Function: Set actual current value.

Input arguments:

CrtValue: Value at which the motor current is set

REMARK: this command can be used only for

step motor drives

Output arguments:

return: TRUE if no error; FALSE if error

*****/

BOOL TML_EXPORT **TS_SetTargetPositionToActual**(void);

Function: Set the target position value equal to the actual position value.

Output arguments:

return: TRUE if no error; FALSE if error

*****/


```

BOOL TML_EXPORT TS_SetIntVariable(LPCSTR pszName, short value);
/***** Function:
Writes an integer type variable to the drive.
Input arguments:
    pszName:      Name of the variable
    value: Variable value
Output arguments:
    return:      TRUE if no error; FALSE if error
*****/

#ifdef __cplusplus
BOOL TML_EXPORT TS_GetIntVariable(LPCSTR pszName, short& value);
#else
BOOL TML_EXPORT TS_GetIntVariable(LPCSTR pszName, short* value);
#endif
/***** Function: Reads an integer type variable from the drive.
Input arguments:
    pszName:      Name of the variable
Output arguments:
    value: Variable value
    return:      TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_SetLongVariable(LPCSTR pszName, long value);
/***** Function:
Writes a long integer type variable to the drive.
Input arguments:
    pszName:      Name of the variable
    value: Variable value
Output arguments:
    return:      TRUE if no error; FALSE if error
*****/

#ifdef __cplusplus
BOOL TML_EXPORT TS_GetLongVariable(LPCSTR pszName, long& value);
#else
BOOL TML_EXPORT TS_GetLongVariable(LPCSTR pszName, long* value);
#endif
/***** Function: Reads a long integer type variable from the drive.
Input arguments:
    pszName:      Name of the variable
Output arguments:

```

```

        value: Variable value
        return:      TRUE if no error; FALSE if error
    *****/

BOOL TML_EXPORT TS_SetFixedVariable(LPCSTR pszName, double value);
/*****
    Function: Writes a fixed point type variable to the drive.
    Input arguments:
        pszName:      Name of the variable
        value: Variable value
    Output arguments:
        return:      TRUE if no error; FALSE if error
    *****/

#ifdef __cplusplus
BOOL TML_EXPORT TS_GetFixedVariable(LPCSTR pszName, double& value);
#else
BOOL TML_EXPORT TS_GetFixedVariable(LPCSTR pszName, double* value);
#endif
/*****
    Function: Reads a fixed point type variable from the drive.
    Input arguments:
        pszName:      Name of the variable
    Output arguments:
        value: Variable value
        return:      TRUE if no error; FALSE if error
    *****/

BOOL TML_EXPORT TS_SetBuffer(WORD address, WORD* arrayValues, WORD nSize);
/*****
    Function: Download a data buffer to the drive's memory.
    Input arguments:
        address:      Start address where to download the data buffer
        arrayValues:   Buffer containing the data to be downloaded
        nSize: the number of words to download
    Output arguments:
        return:      TRUE if no error; FALSE if error
    *****/

BOOL TML_EXPORT TS_GetBuffer(WORD address, WORD* arrayValues, WORD nSize);
/*****
    Function: Upload a data buffer from the drive (get it from motion chip's memory).
    Input arguments:
        address:      Start address where from to upload the data buffer
        arrayValues:   Buffer address where the uploaded data will be stored

```

```

        nSize: the number of words to upload
Output arguments:
    arrayValues: the uploaded data
    return:      TRUE if no error; FALSE if error
*****/

/*****/
/*****MOTION functions*****/
/*****/

BOOL TML_EXPORT TS_MoveAbsolute(long AbsPosition, double Speed, double
Acceleration, short MoveMoment, short ReferenceBase);
/*****
    Function: Move Absolute with trapezoidal speed profile. This function allows you
to program a position profile
        with a trapezoidal shape of the speed.
Input arguments:
    AbsPosition: Absolute position reference value
    Speed:       Slew speed; if 0, use previously defined value
    Acceleration: Acceleration deceleration; if 0, use previously defined value
    MoveMoment:
        UPDATE_NONE -> setup motion parameters, movement will start latter
(on an Update command)
        UPDATE_IMMEDIATE -> start moving immediate
        UPDATE_ON_EVENT -> start moving on event
    ReferenceBase:
        FROM_MEASURE -> the position reference starts from the actual
measured position value
        FROM_REFERENCE -> the position reference starts from the actual
reference position value
Output arguments:
    return:      TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_MoveRelative(long RelPosition, double Speed, double
Acceleration, BOOL IsAdditive, short MoveMoment, short ReferenceBase);
/*****
    Function: Move Relative with trapezoidal speed profile. This function allows you
to program a position profile
        with a trapezoidal shape of the speed.
Input arguments:
    RelPosition: Relative position reference value
    Speed:       Slew speed; if 0, use previously defined value
    Acceleration: Acceleration deceleration; if 0, use previously defined value
    MoveMoment:

```

```

        UPDATE_NONE -> setup motion parameters, movement will start latter
(on an Update command)
        UPDATE_IMMEDIATE -> start moving immediate
        UPDATE_ON_EVENT -> start moving on event
    IsAdditive:
        TRUE -> Add the position increment to the position to reach set by
the previous motion command
        FALSE -> No position increment is added to the target position
    ReferenceBase:
        FROM_MEASURE -> the position reference starts from the actual
measured position value
        FROM_REFERENCE -> the position reference starts from the actual
reference position value
    Output arguments:
        return:      TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_MoveVelocity(double Speed, double Acceleration, short
MoveMoment, short ReferenceBase);
/*****
    Function: Move at a given speed, with acceleration profile.
    Input arguments:
        Speed:      Jogging speed
        Acceleration: Acceleration deceleration; if 0, use previously defined value
        MoveMoment:
            UPDATE_NONE -> setup motion parameters, movement will start latter
(on an Update command)
            UPDATE_IMMEDIATE -> start moving immediate
            UPDATE_ON_EVENT -> start moving on event
        ReferenceBase:
            FROM_MEASURE -> the position reference starts from the actual
measured position value
            FROM_REFERENCE -> the position reference starts from the actual
reference position value
        Output arguments:
            return:      TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_SetAnalogueMoveExternal (short ReferenceType, BOOL UpdateFast,
double LimitVariation, short MoveMoment);
/*****
    Function: Set Motion type as using an analogue external reference.
    Input arguments:
        ReferenceType:
            REFERENCE_POSITION -> external position reference
            REFERENCE_SPEED -> external speed reference
            REFERENCE_TORQUE -> external torque reference

```

```

        REFERENCE_VOLTAGE -> external voltage reference
    UpdateFast:
        TRUE -> generate the torque reference in the fast control loop
        FALSE -> generate the torque reference in the slow control loop
    LimitVariation:
        NO_VARIATION (0) -> the external reference is limited at the value
set in the Drive Setup
        A value which can be an acceleration or speed in function of the
reference type.
    MoveMoment:
        UPDATE_NONE -> setup motion parameters, movement will start latter
(on an Update command)
        UPDATE_IMMEDIATE -> start moving immediate
        UPDATE_ON_EVENT -> start moving on event
    Output arguments:
        return:         TRUE if no error; FALSE if error
*****

#ifdef __cplusplus
BOOL TML_EXPORT TS_SetDigitalMoveExternal (BOOL SetGearRatio = FALSE, short
Denominator = 1, short Numerator = 1, double LimitVariation = 0, short MoveMoment =
1);
#else
BOOL TML_EXPORT TS_SetDigitalMoveExternal (BOOL SetGearRatio, short Denominator,
short Numerator, double LimitVariation, short MoveMoment);
#endif
/*****
    Function: Set Motion type as using a digital external reference. This function is
used only for Positioning.
    Input arguments:
        MoveMoment:
            UPDATE_NONE -> setup motion parameters, movement will start latter
(on an Update command)
            UPDATE_IMMEDIATE -> start moving immediate
            UPDATE_ON_EVENT -> start moving on event
        LimitVariation:
            NO_VARIATION (0) -> the external reference is limited at the value
set in the Drive Setup
            A value which can be an acceleration or speed in function of the
reference type.
        SetGearRatio: Set the gear parameters; if TRUE, following parameters are
needed
        Denominator: Gear master ratio
        Numerator: Gear slave ratio
    Output arguments:
        return:         TRUE if no error; FALSE if error
*****

```

```

#ifdef __cplusplus
BOOL TML_EXPORT TS_SetOnlineMoveExternal (short ReferenceType, double
LimitVariation = 0, double InitialValue = 0., short MoveMoment = 1);
#else
BOOL TML_EXPORT TS_SetOnlineMoveExternal (short ReferenceType, double
LimitVariation, double InitialValue, short MoveMoment);
#endif
/***** Function:
Set Motion type as using an analogue external reference.
Input arguments:
    ReferenceType:
        REFERENCE_POSITION -> external position reference
        REFERENCE_SPEED -> external speed reference
        REFERENCE_TORQUE -> external torque reference
        REFERENCE_VOLTAGE -> external voltage reference
    LimitVariation:
        NO_VARIATION (0) -> the external reference is limited at the value
set in the Drive Setup
        A value which can be an acceleration or speed in function of the
reference type.
    MoveMoment:
        UPDATE_NONE -> setup motion parameters, movement will start latter
(on an Update command)
        UPDATE_IMMEDIATE -> start moving immediate
        UPDATE_ON_EVENT -> start moving on event
    InitialValue: If non zero, set initial value of EREF
Output arguments:
    return: TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_VoltageTestMode(short MaxVoltage, short IncrVoltage, short
Theta0, short Dtheta, short MoveMoment);
/*****
Function: Use voltage test mode.
Input arguments:
    MaxVoltage: Maximum test voltage value
    IncrVoltage: Voltage increment on each slow sampling period
    Theta0: Initial value of electrical angle value
        Remark: used only for AC motors; set to 0 otherwise
    Dtheta: Electric angle increment on each slow sampling period
    MoveMoment:
        UPDATE_NONE -> setup motion parameters, movement will start latter
(on an Update command)
        UPDATE_IMMEDIATE -> start moving immediate
        UPDATE_ON_EVENT -> start moving on event
*****/

```

Output arguments:

return: TRUE if no error; FALSE if error

*****/

```
BOOL TML_EXPORT TS_TorqueTestMode(short MaxTorque, short IncrTorque, short Theta0,
short Dtheta, short MoveMoment);
```

/*****/

Function: Use torque test mode.

Input arguments:

MaxTorque: Maximum test torque value

IncrTorque: Torque increment on each slow sampling period

Theta0: Initial value of electrical angle value

Remark: used only for AC motors; set to 0 otherwise

Dtheta: Electric angle increment on each slow sampling period

MoveMoment:

UPDATE_NONE -> setup motion parameters, movement will start latter
(on an Update command)

UPDATE_IMMEDIATE -> start moving immediate

UPDATE_ON_EVENT -> start moving on event

Output arguments:

return: TRUE if no error; FALSE if error

*****/

```
BOOL TML_EXPORT TS_SetGearingMaster(BOOL Group, BYTE SlaveID, short ReferenceBase,
BOOL Enable,
```

```
BOOL SetSlavePos, short MoveMoment);
```

/*****/

Function: Setup master parameters in gearing mode.

Input arguments:

Group

TRUE -> set slave group ID with value;

FALSE-> set slave axis ID with SlaveID value;

SlaveID: Axis ID in the case that Group is FALSE or a Group ID when
Group is TRUE

ReferenceBase:

FROM_MEASURE -> send position feedback

FROM_REFERENCE -> send position reference

Enable: TRUE -> enable gearing operation; FALSE -> disable gearing
operation

SetSlavePos: TRUE -> initialize slave(s) with master position

MoveMoment:

UPDATE_NONE -> setup motion parameters, movement will start latter
(on an Update command)

UPDATE_IMMEDIATE -> start moving immediate

UPDATE_ON_EVENT -> start moving on event

Output arguments:

```

        return:          TRUE if no error; FALSE if error
    *****/

BOOL TML_EXPORT TS_SetGearingSlave(short Denominator, short Numerator, short
ReferenceBase,
                                short
EnableSlave, double LimitVariation, short MoveMoment);
/*****
    Function: Setup slave parameters in gearing mode.
    Input arguments:
        Denominator:    Master gear ratio value
        Numerator:      Slave gear ratio value
        ReferenceBase:
            FROM_MEASURE -> the position reference starts from the actual
measured position value
            FROM_REFERENCE -> the position reference starts from the actual
reference position value
        EnableSlave:
            SLAVE_NONE -> do not enable slave operation
            SLAVE_COMMUNICATION_CHANNEL -> enable operation got via a
communication channel
            SLAVE_2ND_ENCODER -> enable operation read from 2nd encoder or P&D
inputs
        LimitVariation:
            NO_VARIATION (0) -> the external reference is limited at the value
set in the Drive Setup
            A value which can be an acceleration or speed in function of the
reference type.
        MoveMoment:
            UPDATE_NONE -> setup motion parameters, movement will start latter
(on an Update command)
            UPDATE_IMMEDIATE -> start moving immediate
            UPDATE_ON_EVENT -> start moving on event
    Output arguments:
        return:          TRUE if no error; FALSE if error
    *****/

BOOL TML_EXPORT TS_MotionSuperposition(short Enable, short Update);
/***** Function:
enable or disable the superposition of the electronic gearing mode with a second
motion mode
    Input arguments:
        Enable: if 0, disable the Superposition mode
                if 1, enable the Superposition mode
        Update: if 0, doesn't send UPD command to the drive, in order to take into
account the
                Superposition mode

```


if 1, sends UPD command to the drive, in order to take into account the

Superposition mode

Output arguments:

return: TRUE if no error; FALSE if error

*****/

BOOL TML_EXPORT **TS_SetCammingMaster**(BOOL Group, BYTE SlaveID, **short** ReferenceBase, BOOL Enable, **short** MoveMoment);

/*****/

Function: Setup master parameters in camming mode.

Input arguments:

Group

TRUE -> set slave group ID with (SlaveID + 256) value;

FALSE-> set slave axis ID with SlaveID value;

SlaveID: Axis ID in case Group is FALSE, or group mask otherwise (0 means broadcast)

ReferenceBase:

FROM_MEASURE -> send position feedback

FROM_REFERENCE -> send position reference

Enable: TRUE -> enable camming operation; FALSE -> disable camming operation

MoveMoment:

UPDATE_NONE -> setup motion parameters, movement will start latter (on an Update command)

UPDATE_IMMEDIATE -> start moving immediate

UPDATE_ON_EVENT -> start moving on event

Output arguments:

return: TRUE if no error; FALSE if error

*****/

#ifdef __cplusplus

BOOL TML_EXPORT **TS_CamDownload**(LPCSTR pszCamFile, WORD wLoadAddress, WORD wRunAddress, WORD& wNextLoadAddr, WORD& wNexRunAddr);

#else

BOOL TML_EXPORT **TS_CamDownload**(LPCSTR pszCamFile, WORD wLoadAddress, WORD wRunAddress, WORD* wNextLoadAddr, WORD* wNexRunAddr);

#endif

/***** Function:
Download a CAM file to the drive, at a specified address.

Input arguments:

pszCamFile: the name of the file containing the CAM information

wLoadAddress: memory address where the CAM is loaded

wRunAddress: memory where the actual CAM table is transferred and executed at run time

Output arguments:

wNextLoadAddr: memory address available for the next CAM file; if 0 there is no memory left

wNextRunAddress: memory where the next CAM table is transferred and executed at run time;

return: TRUE if no error; FALSE if error

*****/

BOOL TML_EXPORT **TS_CamInitialization**(WORD LoadAddress, WORD RunAddress);

/*****

Function: Copies a CAM file from E2ROM to RAM memory. You should not use this if you download CAMs directly to RAM memory

(load address == run address)

Input arguments:

LoadAddress: memory address in E2ROM where the CAM is already loaded

RunAddress: memory address in RAM where the CAM is copied.

Output arguments:

return: TRUE if no error; FALSE if error

*****/

#ifdef __cplusplus

BOOL TML_EXPORT **TS_SetCammingSlaveRelative**(WORD RunAddress, **short** ReferenceBase, **short** EnableSlave, **short** MoveMoment,

long OffsetFromMaster = 0, **double** MultInputFactor = 0, **double** MultOutputFactor = 0);

#else

BOOL TML_EXPORT **TS_SetCammingSlaveRelative**(WORD RunAddress, **short** ReferenceBase, **short** EnableSlave, **short** MoveMoment,

long OffsetFromMaster, **double** MultInputFactor, **double** MultOutputFactor);

#endif

/*****

Function: Setup slave parameters in relative camming mode.

Input arguments:

RunAddress: memory addresses where the CAM is executed at run time. If any of them is 0 it means that no start address is set

ReferenceBase:

FROM_MEASURE -> the position reference starts from the actual measured position value

FROM_REFERENCE -> the position reference starts from the actual reference position value

EnableSlave:

SLAVE_NONE -> do not enable slave operation

SLAVE_COMMUNICATION_CHANNEL -> enable operation got via a communication channel

SLAVE_2ND_ENCODER -> enable operation read from 2nd encoder or P&D inputs

```

        MoveMoment:
            UPDATE_NONE -> setup motion parameters, movement will start latter
(on an Update command)
            UPDATE_IMMEDIATE -> start moving immediate
            UPDATE_ON_EVENT -> start moving on event
            nOffsetFromMaster, nMultInputFactor, nMultOutputFactor: if non-zero, set
the correspondent parameter
        Output arguments:
            return:          TRUE if no error; FALSE if error
    *****/

#ifdef __cplusplus
    BOOL TML_EXPORT TS_SetCammingSlaveAbsolute(WORD RunAddress, double LimitVariation,
short ReferenceBase, short EnableSlave, short MoveMoment,

        long OffsetFromMaster = 0, double MultInputFactor = 0, double
MultOutputFactor = 0);
#else
    BOOL TML_EXPORT TS_SetCammingSlaveAbsolute(WORD RunAddress, double LimitVariation,
short ReferenceBase, short EnableSlave, short MoveMoment,

        long OffsetFromMaster, double MultInputFactor, double MultOutputFactor);
#endif
/*****
    Function: Setup slave parameters in absolute camming mode.
    Input arguments:
        RunAddress: memory addresses where the CAM is executed at run time. If any
of them is 0 it means that no start address is set
        LimitVariation:
            NO_VARIATION (0) -> no limitation on speed value at the value set
in the Drive Setup
            A value which can be an acceleration or speed in function of the
reference type.
        ReferenceBase:
            FROM_MEASURE -> the position reference starts from the actual
measured position value
            FROM_REFERENCE -> the position reference starts from the actual
reference position value
        EnableSlave:
            SLAVE_NONE -> do not enable slave operation
            SLAVE_COMMUNICATION_CHANNEL -> enable operation got via a
communication channel
            SLAVE_2ND_ENCODER -> enable operation read from 2nd encoder or P&D
inputs
        MoveMoment:
            UPDATE_NONE -> setup motion parameters, movement will start latter
(on an Update command)
            UPDATE_IMMEDIATE -> start moving immediate

```

```

        UPDATE_ON_EVENT -> start moving on event
        nOffsetFromMaster, nMultInputFactor, nMultOutputFactor: if non-zero, set
the correspondent parameter
    Output arguments:
        return:         TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_SetMasterResolution(long MasterResolution);
/*****
    Function: Setup the resolution for the master encoder connected on the second
encoder input of the drive.
    Input arguments:
        MasterResolution:
            FULL_RANGE (0) -> select this option if the master position is not
cyclic. (e.g. the resolution is equal with the whole
                                     32-bit range of
position)
            Value that represents the number of lines of the 2nd master encoder
    Output arguments:
        return:         TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_SendSynchronization (long Period);
/*****
    Function: Setup drives to send synchronization messages.
    Input arguments:
        Period: the time period between 2 sends
    Output arguments:
        return:         TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_Stop(void);
/*****
    Function: Stop the motion.
    Output arguments:
        return:         TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_QuickStopDecelerationRate(double Deceleration);
/*****
    Function: Set the deceleration rate used for QuickStop or SCurve positioning
profile.
    Input Arguments:
        Deceleration: the value of the deceleration rate
    Output arguments:
        return:         TRUE if no error; FALSE if error

```

```

*****/

BOOL TML_EXPORT TS_SendPVTPoint(long Position, double Velocity, unsigned int Time,
short PVTCounter);
/*****
Function: Sends a PVT point to the drive.
Input arguments:
    Position:    drive position for the desired point
    Velocity:    desired velocity of the drive at the point
    Time:        amount of time for the segment
    PVTCounter: integrity counter for current PVT point
Output arguments:
    return:      TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_SendPVTFirstPoint(long Position, double Velocity, unsigned int
Time, short PVTCounter,
short
PositionType, long InitialPosition, short MoveMoment, short ReferenceBase);
/*****
Function: Sends the first point from a series of PVT points and sets the PVT
motion mode.
Input arguments:
    Position:    drive position for the desired point
    Velocity:    desired velocity of the drive at the point
    Time:        amount of time for the segment
    PVTCounter: integrity counter for current PVT point
    PositionType: ABSOLUTE_POSITION or RELATIVE_POSITION
    InitialPosition: drive initial position at the start of an absolute PVT
movement.
It is taken into
consideration only if an absolute movement is requested
    MoveMoment:
        UPDATE_NONE -> setup motion parameters, movement will start latter
(on an Update command)
        UPDATE_IMMEDIATE -> start moving immediate
        UPDATE_ON_EVENT -> start moving on event
    ReferenceBase:
        FROM_MEASURE -> the position reference starts from the actual
measured position value
        FROM_REFERENCE -> the position reference starts from the actual
reference position value
Output arguments:
    return:      TRUE if no error; FALSE if error
*****/

```

```

BOOL TML_EXPORT TS_PVTSetup(short ClearBuffer, short IntegrityChecking, short
ChangePVTCounter,
                                short AbsolutePositionSource, short
ChangeLowLevel, short PVTCounterValue, short LowLevelValue);
/***** Function:
For PVT motion mode parametrization and setup.
Input arguments:
    ClearBuffer: 0 -> nothing
                  1 -> clears the PVT buffer
    IntegrityChecking: 0 -> PVT integrity counter checking is active (default)
                      1 -> PVT integrity counter checking is inactive
    ChangePVTCounter: 0 -> nothing
                      1 -> drive internal PVT integrity counter is changed with
the value specified PVTCounterValue
    AbsolutePositionSource: specifies the source for the initial position in case
the PVT motion mode will be absolute
                          0 -> initial position read from PVTPOS0
                          1 -> initial position read from current value of
target position (TPOS)
    ChangeLowLevel:      0 -> nothing
                          1 -> the parameter for BufferLow signaling is changed
with the value specified LowLevelValue
    PVTCounterValue:     New value for the drive internal PVT integrity counter
    LowLevelValue:       New value for the level of the BufferLow signal
Output arguments:
    return:              TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_SendPTPoint(long Position, unsigned int Time, short PTCounter);
/***** Function: Sends a PT point to the drive.
Input arguments:
    Position: drive position for the desired point
    Time:     amount of time for the segment
    PTCounter: integrity counter for current PT point
Output arguments:
    return:    TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_SendPTFirstPoint(long Position, unsigned int Time, short
PTCounter,
                                short
PositionType, long InitialPosition, short MoveMoment, short ReferenceBase);
/***** Function: Sends the first point from a series of PT points and sets the PT motion
mode.
Input arguments:

```

```

    Position:      drive position for the desired point
    Time:          amount of time for the segment
    PTCOUNTER:     integrity counter for current PT point
    PositionType:  ABSOLUTE_POSITION or RELATIVE_POSITION
    InitialPosition: drive initial position at the start of an absolute PT
movement. It is taken into consideration only if an absolute movement is requested
    MoveMoment:
        UPDATE_NONE -> setup motion parameters, movement will start latter
(on an Update command)
        UPDATE_IMMEDIATE -> start moving immediate
        UPDATE_ON_EVENT -> start moving on event
    ReferenceBase:
        FROM_MEASURE -> the position reference starts from the actual
measured position value
        FROM_REFERENCE -> the position reference starts from the actual
reference position value
    Output arguments:
        return:      TRUE if no error; FALSE if error
*****/
BOOL TML_EXPORT TS_PTSetup(short ClearBuffer, short IntegrityChecking, short
ChangePTCounter,
                                short AbsolutePositionSource, short
ChangeLowLevel, short PTCOUNTERValue, short LowLevelValue);
/*****
    Function: For PT motion mode parametrization and setup.
    Input arguments:
        ClearBuffer: 0 -> nothing
                    1 -> clears the PT buffer
        IntegrityChecking: 0 -> PT integrity counter checking is active (default)
                           1 -> PT integrity counter checking is inactive
        ChangePVTCounter: 0 -> nothing
                           1 -> drive internal PT integrity counter is changed with the
value specified PTCOUNTERValue
        AbsolutePositionSource: specifies the source for the initial position in case
the PT motion mode will be absolute
                                0 -> initial position read from PVTPOS0
                                1 -> initial position read from current value of target
position (TPOS)
        ChangeLowLevel: 0 -> nothing
                        1 -> the parameter for BufferLow signaling is changed with
the value specified LowLevelValue
        PTCOUNTERValue: New value for the drive internal PT integrity counter
        LowLevelValue:  New value for the level of the BufferLow signal
    Output arguments:
        return:      TRUE if no error; FALSE if error
*****/

```

```

BOOL TML_EXPORT TS_MoveSCurveRelative(long RelPosition, double Speed, double
Acceleration, long JerkTime, short MoveMoment, short DecelerationType);
/*****
Function: For relative S-Curve motion mode.
Input arguments:
    RelPosition:    Relative position reference value
    Speed:          Slew speed
    Acceleration:    Acceleration deceleration
    JerkTime:       The time after the acceleration reaches the desired value.
    MoveMoment:
        UPDATE_NONE -> setup motion parameters, movement will start latter
(on an Update command)
        UPDATE_IMMEDIATE -> start moving immediate
        UPDATE_ON_EVENT -> start moving on event
    DecelerationType:
        S_CURVE_SPEED_PROFILE -> s-curve speed profile
        TRAPEZOIDAL_SPEED_PROFILE -> trapezoidal speed profile
Output arguments:
    return:         TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_MoveSCurveAbsolute(long AbsPosition, double Speed, double
Acceleration, long JerkTime, short MoveMoment, short DecelerationType);
/*****
Function: For absolute S-Curve motion mode.
Input arguments:
    AbsPosition:    Absolute position reference value
    Speed:          Slew speed
    Acceleration:    Acceleration deceleration
    JerkTime:       The time after which the acceleration reaches the desired
value.
    MoveMoment:
        UPDATE_NONE -> setup motion parameters, movement will start latter
(on an Update command)
        UPDATE_IMMEDIATE -> start moving immediate
        UPDATE_ON_EVENT -> start moving on event
    DecelerationType:
        S_CURVE_SPEED_PROFILE -> s-curve speed profile
        TRAPEZOIDAL_SPEED_PROFILE -> trapezoidal speed profile
Output arguments:
    return:         TRUE if no error; FALSE if error
*****/

/*****/
/*****/EVENT-RELATED functions*****/
/*****/

```



```

#ifdef __cplusplus
BOOL TML_EXPORT TS_CheckEvent(BOOL& event);
#else
BOOL TML_EXPORT TS_CheckEvent(BOOL* event);
#endif
/*****
Function: Check if the actually active event occurred.
Output arguments:
event: TRUE on event detected
return: TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_SetEventOnMotionComplete(BOOL WaitEvent, BOOL EnableStop);
/*****
Function: Setup event when the motion is complete.
Input arguments:
WaitEvent: TRUE -> Wait until event occurs; FALSE -> Continue
EnableStop: TRUE -> On motion complete, stop the motion, FALSE -> Don't
stop the motion
Output arguments:
return: TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_SetEventOnMotorPosition(short PositionType, long Position, BOOL
Over, BOOL WaitEvent, BOOL EnableStop);
/*****
Function: Setup event when motor position is over/under imposed value.
Input arguments:
PositionType: ABSOLUTE_POSITION or RELATIVE_POSITION
Position: Position value to be reached
Over: TRUE -> Look for position over; FALSE -> Look for position
below
WaitEvent: TRUE -> Wait until event occurs; FALSE -> Continue
EnableStop: TRUE -> On event, stop the motion, FALSE -> Don't stop the
motion
Output arguments:
return: TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_SetEventOnLoadPosition(short PositionType, long Position, BOOL
Over, BOOL WaitEvent, BOOL EnableStop);
/*****
Function: Setup event when load position is over/under imposed value.
Input arguments:
PositionType: ABSOLUTE_POSITION or RELATIVE_POSITION

```

```

        Position:      Position value to be reached
        Over:          TRUE -> Look for position over; FALSE -> Look for position
below
        WaitEvent:     TRUE -> Wait until event occurs; FALSE -> Continue
        EnableStop:    TRUE -> On event, stop the motion, FALSE -> Don't stop the
motion
        Output arguments:
        return:        TRUE if no error; FALSE if error
*****/

```

```

BOOL TML_EXPORT TS_SetEventOnMotorSpeed(double Speed, BOOL Over, BOOL WaitEvent,
BOOL EnableStop);

```

```

/*****
Function: Setup event when motor speed is over/under imposed value.
Input arguments:
        Speed:          Speed value to be reached
        Over:          TRUE -> Look for speed over; FALSE -> Look for speed below
        WaitEvent:     TRUE -> Wait until event occurs; FALSE -> Continue
        EnableStop:    TRUE -> On event, stop the motion, FALSE -> Don't stop the
motion
        Output arguments:
        return:        TRUE if no error; FALSE if error
*****/

```

```

BOOL TML_EXPORT TS_SetEventOnLoadSpeed(double Speed, BOOL Over, BOOL WaitEvent,
BOOL EnableStop);

```

```

/*****
Function: Setup event when load speed is over/under imposed value.
Input arguments:
        Speed:          Speed value to be reached
        Over:          TRUE -> Look for speed over; FALSE -> Look for speed below
        WaitEvent:     TRUE -> Wait until event occurs; FALSE -> Continue
        EnableStop:    TRUE -> On event, stop the motion, FALSE -> Don't stop the
motion
        Output arguments:
        return:        TRUE if no error; FALSE if error
*****/

```

```

BOOL TML_EXPORT TS_SetEventOnTime(WORD Time, BOOL WaitEvent, BOOL EnableStop);
/*****

```

```

Function: Setup event after a time interval.
Input arguments:
        Time:          Time after which the event will be set
        WaitEvent:     TRUE -> Wait until event occurs; FALSE -> Continue
        EnableStop:    TRUE -> On event, stop the motion, FALSE -> Don't stop the
motion

```

Output arguments:

return: TRUE if no error; FALSE if error

*****/

BOOL TML_EXPORT **TS_SetEventOnPositionRef**(long Position, BOOL Over, BOOL WaitEvent, BOOL EnableStop);

/*****

Function: Setup event when position reference is over/under imposed value.

Input arguments:

Position: Position value to be reached

Over: TRUE -> Look for speed over; FALSE -> Look for speed below

WaitEvent: TRUE -> Wait until event occurs; FALSE -> Continue

EnableStop: TRUE -> On event, stop the motion, FALSE -> Don't stop the motion

Output arguments:

return: TRUE if no error; FALSE if error

*****/

BOOL TML_EXPORT **TS_SetEventOnSpeedRef**(double Speed, BOOL Over, BOOL WaitEvent, BOOL EnableStop);

/*****

Function: Setup event when speed reference is over/under imposed value.

Input arguments:

Speed: Speed value to be reached

Over: TRUE -> Look for speed over; FALSE -> Look for speed below

WaitEvent: TRUE -> Wait until event occurs; FALSE -> Continue

EnableStop: TRUE -> On event, stop the motion, FALSE -> Don't stop the motion

Output arguments:

return: TRUE if no error; FALSE if error

*****/

BOOL TML_EXPORT **TS_SetEventOnTorqueRef**(int Torque, BOOL Over, BOOL WaitEvent, BOOL EnableStop);

/*****

Function: Setup event when torque reference is over/under imposed value.

Input arguments:

Torque: Torque value to be reached

Over: TRUE -> Look for speed over; FALSE -> Look for speed below

WaitEvent: TRUE -> Wait until event occurs; FALSE -> Continue

EnableStop: TRUE -> On event, stop the motion, FALSE -> Don't stop the motion

Output arguments:

return: TRUE if no error; FALSE if error

*****/

```

BOOL TML_EXPORT TS_SetEventOnEncoderIndex(short IndexType, short TransitionType,
BOOL WaitEvent, BOOL EnableStop);

```

```

/*****

```

Function: Setup event when encoder index is triggered.

Input arguments:

IndexType: INDEX_1 or INDEX_2

TransitionType: TRANSITION_HIGH_TO_LOW or TRANSITION_LOW_TO_HIGH

WaitEvent: TRUE -> Wait until event occurs; FALSE -> Continue

EnableStop: TRUE -> On event, stop the motion, FALSE -> Don't stop the motion

Output arguments:

return: TRUE if no error; FALSE if error

```

*****/

```

```

BOOL TML_EXPORT TS_SetEventOnLimitSwitch(short LSWType, short TransitionType, BOOL
WaitEvent, BOOL EnableStop);

```

```

/*****

```

Function: Setup event when selected limit switch is triggered.

Input arguments:

LSWType: LSW_NEGATIVE or LSW_POSITIVE

TransitionType: TRANSITION_HIGH_TO_LOW or TRANSITION_LOW_TO_HIGH

WaitEvent: TRUE -> Wait until event occurs; FALSE -> Continue

EnableStop: TRUE -> On event, stop the motion, FALSE -> Don't stop the motion

Output arguments:

return: TRUE if no error; FALSE if error

```

*****/

```

```

BOOL TML_EXPORT TS_SetEventOnDigitalInput(BYTE InputPort, short IOState, BOOL
WaitEvent, BOOL EnableStop);

```

```

/*****

```

Function: Setup event when selected input port status is IOState.

Input arguments:

InputPort: Input port number

IOState: IO_LOW or IO_HIGH

WaitEvent: TRUE -> Wait until event occurs; FALSE -> Continue

EnableStop: TRUE -> On event, stop the motion, FALSE -> Don't stop the motion

Output arguments:

return: TRUE if no error; FALSE if error

```

*****/

```

```

BOOL TML_EXPORT TS_SetEventOnHomeInput(short IOState, BOOL WaitEvent, BOOL
EnableStop);

```

```

/***** Function:
Setup event when selected input port status is IOState.

```

```

Input arguments:
    IOState:      IO_LOW or IO_HIGH
    WaitEvent:    TRUE -> Wait until event occurs; FALSE -> Continue
    EnableStop:   TRUE -> On event, stop the motion, FALSE -> Don't
stop the motion
Output arguments:
    return:       TRUE if no error; FALSE if error
*****/

/*****/
/*****INPUT / OUTPUT functions*****/
/*****/

BOOL TML_EXPORT TS_SetupInput(BYTE nIO);
/*****
Function: Setup IO port as input.
Input arguments:
    nIO:    Port number to be set as input
Output arguments:
    return:  TRUE if no error; FALSE if error
*****/

#ifdef __cplusplus
BOOL TML_EXPORT TS_GetInput(BYTE nIO, BYTE& InValue);
#else
BOOL TML_EXPORT TS_GetInput(BYTE nIO, BYTE* InValue);
#endif
/*****
Function: Get input port status.
Input arguments:
    nIO:    Input port number to be read
Output arguments:
    InValue: the input port status value (0 or 1)
    return:  TRUE if no error; FALSE if error
*****/

#ifdef __cplusplus
BOOL TML_EXPORT TS_GetHomeInput(BYTE& InValue);
#else
BOOL TML_EXPORT TS_GetHomeInput(BYTE* InValue);
#endif
/*****
Function: Get home input port status.

Output arguments:

```

```

        InValue:      the input port status value (0 or 1)
        return:       TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_SetupOutput(BYTE nIO);
/***** Function:
Setup IO port as output.
Input arguments:
        nIO:   Port number to be set as output
Output arguments:
        return:   TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_SetOutput(BYTE nIO, BYTE OutValue);
/***** Function: Set output port status.
Input arguments:
        nIO:   Output port number to be written
        OutValue:   Output port status value to be set (0 or 1)
Output arguments:
        return:   TRUE if no error; FALSE if error
*****/

#ifdef __cplusplus
BOOL TML_EXPORT TS_GetMultipleInputs(LPCSTR pszVarName, short& Status);
#else
BOOL TML_EXPORT TS_GetMultipleInputs(LPCSTR pszVarName, short* Status);
#endif
/***** Function: Read multiple inputs.
Input arguments:
        pszVarName: temporary variable name used to read input status
Output arguments:
        Status: value of multiple input status.
        return:   TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_SetMultipleOutputs(LPCSTR pszVarName, short Status);
/***** Function: Set multiple outputs (for firmware versions FAxX).
        pszVarName: temporary variable name used to set output status
        Status: value to be set
Output arguments:
        return:   TRUE if no error; FALSE if error
*****/

```

```

BOOL TML_EXPORT TS_SetMultipleOutputs2(short SelectedPorts, short Status);
/*****
Function:      Set multiple outputs (for firmware versions FBxx).
SelectedPorts: port mask. Set bit n to 1 if you want to update the status
of port n.
Status: value to be set
Output arguments:
return:      TRUE if no error; FALSE if error
*****/

/*****/
/*****/General use*****/
/*****/

BOOL TML_EXPORT TS_SendDataToHost(BYTE HostAddress, DWORD StatusRegMask, WORD
ErrorRegMask);
/*****
Function: Send status and error registers to host.
Input arguments:
HostAddress:  axis ID of host
StatusRegMask: bit mask for status register
ErrorRegMask: bit mask for error register
Output arguments:
return:      TRUE if no error; FALSE if error
*****/

#ifdef __cplusplus
BOOL TML_EXPORT TS_OnlineChecksum(WORD startAddress, WORD endAddress, WORD&
checksum);
#else
BOOL TML_EXPORT TS_OnlineChecksum(WORD startAddress, WORD endAddress, WORD*
checksum);
#endif
/*****
Function: Get checksum of a memory range.
startAddress: start memory address
endAddress: end memory address
Output arguments:
checksum: checksum (sum modulo 0xFFFF) of a memory range returned
by the active drive/motor
return:      TRUE if no error; FALSE if error
*****/

#ifdef __cplusplus
BOOL TML_EXPORT TS_DownloadProgram(LPCSTR pszOutFile, WORD& wEntryPoint);

```

```

#else
BOOL TML_EXPORT TS_DownloadProgram(LPCSTR pszOutFile, WORD* wEntryPoint);
#endif
/*****
  Function: Download a COFF formatted file to the drive, and return the entry point
  of that file.
  Input arguments:
      pszOutFile:    Name of the output TML object file
  Output arguments:
      wEntryPoint:   the entry point (start address) of the downloaded file
      return:        TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_GOTO(WORD address);
/*****
  Function: Execute a GOTO instruction on the drive.
  Input arguments:
      address:       program memory address of the instruction
  Output arguments:
      return:        TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_GOTO_Label(LPCSTR pszLabel);
/*****
  Function: Execute a GOTO instruction on the drive.
  Input arguments:
      pszLabel:      label of the instruction
  Output arguments:
      return:        TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_CALL(WORD address);
/*****
  Function: Execute a CALL instruction on the drive.
  Input arguments:
      address:       address of the procedure
  Output arguments:
      return:        TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_CALL_Label(LPCSTR pszFunctionName);
/*****
  Function: Execute a CALL instruction on the drive.
  Input arguments:
      pszFunctionName: name of the procedure to be executed
*****/

```


Output arguments:

return: TRUE if no error; FALSE if error

*****/

BOOL TML_EXPORT **TS_CancelableCALL**(WORD address);

/*****

Function: Execute a cancelable call (CALLS) instruction on the drive.

Input arguments:

address: address of the procedure

Output arguments:

return: TRUE if no error; FALSE if error

*****/

BOOL TML_EXPORT **TS_CancelableCALL_Label**(LPCSTR pszFunctionName);

/*****

Function: Execute a cancelable call (CALLS) instruction on the drive.

Input arguments:

pszFunctionName: name of the procedure to be executed

Output arguments:

return: TRUE if no error; FALSE if error

*****/

BOOL TML_EXPORT **TS_Homing**(BYTE homingNumber);

/*****

Function: Execute predefined homing routine (HOMING instruction).

Input arguments:

homingNumber: the number of the homing routine to be executed (1 to 40). The number of the homing routines available are product dependent.

Output arguments:

return: TRUE if no error; FALSE if error

*****/

BOOL TML_EXPORT **TS_ABORT**(void);

/*****

Function: Execute ABORT instruction on the drive (aborts execution of a procedure called

with cancelable call instruction).

Output arguments:

return: TRUE if no error; FALSE if error

*****/

BOOL TML_EXPORT **TS_Execute**(LPCSTR pszCommands);

/*****

Function: Execute TML commands entered in TML source code format (as is entered in Command Interpreter).

Input arguments:

pszCommands: String containing the TML source code to be executed. Multiple lines are allowed.

Output arguments:

return: TRUE if no error; FALSE if error

*****/

BOOL TML_EXPORT TS_ExecuteScript(LPCSTR pszFileName);

/*****

Function: Execute TML commands in TML source code, from a script file (as is entered in Command Interpreter).

Input arguments:

pszFileName: The name of the file containing the TML source code to be executed.

Output arguments:

return: TRUE if no error; FALSE if error

*****/

BOOL TML_EXPORT TS_GetOutputOfExecute(LPSTR pszOutput, **int** nMaxChars);

/*****

Function: Return the TML output code of the last previously executed library function call.

Input arguments:

pszOutput: String containing the TML source code generated at the last library function call.

nMaxChars: maximum number of characters to return in the string

Output arguments:

return: TRUE if no error; FALSE if error

*****/

BOOL TML_EXPORT TS_SetupLogger(WORD wLogBufferAddr, WORD wLogBufferLen, WORD* arrayAddresses, WORD countAddr, WORD period);

/*****

Function: Setup logger parameters (could be set up on a group/broadcast destination).

Input arguments:

wLogBufferAddr: The address of logger buffer in drive memory, where data will be stored during logging

wLogBufferLen: The length in WORDs of the logger buffer

arrayAddresses: An array containing the drive memory addresses to be logged

countAddr: The number of memory addresses to be logged

period: How often to log the data: a value between 1 and 7FFF (useful only for new generation drives).

If it is different than 1, one set of data will be stored at every "period" samplings.

Output arguments:

return: TRUE if no error; FALSE if error

*****/

BOOL TML_EXPORT **TS_StartLogger**(WORD wLogBufferAddr, BYTE LogType);

/*****

Function: Start the logger on a drive (could be started on a group/broadcast destination).

Input arguments:

wLogBufferAddr: address of logger buffer (previously set by TS_SetupLogger)

LogType:

LOGGER_FAST: logging occurs in fast sampling control loop

(current loop)

LOGGER_SLOW: logging occurs in slow sampling control loop

(position/speed loop)

Output arguments:

return: TRUE if no error; FALSE if error

*****/

#ifdef __cplusplus

BOOL TML_EXPORT **TS_CheckLoggerStatus**(WORD wLogBufferAddr, WORD& status);

#else

BOOL TML_EXPORT **TS_CheckLoggerStatus**(WORD wLogBufferAddr, WORD* status);

#endif

/*****

Function: Check logger status. (destination must be a single axis).

Input arguments:

wLogBufferAddr: address of logger buffer (previously set by TS_SetupLogger)

Output arguments:

status: Number of points still remaining to capture; if it is 0, the logging is completed

return: TRUE if no error; FALSE if error

*****/

#ifdef __cplusplus

BOOL TML_EXPORT **TS_UploadLoggerResults**(WORD wLogBufferAddr, WORD* arrayValues, WORD& countValues);

#else

BOOL TML_EXPORT **TS_UploadLoggerResults**(WORD wLogBufferAddr, WORD* arrayValues, WORD* countValues);

#endif

/*****

Function: Upload logged data from the drive (destination must be a single axis).

Input arguments:

wLogBufferAddr: address of logger buffer (previously set by TS_SetupLogger)

```

        arrayValues:   Pointer to the array where the uploaded data is stored on the
PC
        countValues:   The size of arrayValues
Output arguments:
        arrayValues:   uploaded logger data
        countValues:   The size of actualized data (lower or equal with countValues
input value)
        return:        TRUE if no error; FALSE if error
*****/

void TML_EXPORT
TS_RegisterHandlerForUnrequestedDriveMessages (pfnCallbackRecvDriveMsg handler);
/*****
Function: Register application's handler for unrequested drive messages.
Input arguments:
pfnCallbackRecvDriveMsg:           pointer to handler
Output arguments:
*****/

BOOL TML_EXPORT TS_CheckForUnrequestedDriveMessages (void);
/*****
Function: Check if there are new unrequested drive messages and call handler for
every message received.
Input arguments:
Output arguments:
        return:        TRUE if no error; FALSE if error
*****/

BOOL TML_EXPORT TS_DriveInitialisation (void);
/*****
Function: Execute ENDINIT command and verify if the setup table is valid. This
function
must be called only after TS_LoadSetup & TS_SetupAxis &
TS_SelectAxis are called.
Input arguments:
Output arguments:
        return:        TRUE if no error; FALSE if error
*****/
#ifdef __cplusplus
}
#endif

#endif // __TML_LIB_H__

```




T E C H N O S O F T