



\* FOR ALL AVAILABLE OPTIONS CHECK THE USER MANUAL OF THE DRIVE  
 \*\* ALL DIGITAL INPUTS AND OUTPUTS CAN BE SET AS PNP/NPN BY SOFTWARE

<b>iGVD71 BX-CAT</b>		<b>P/N:P025.027.E221</b>	
Copyright © Technosoft 2023. All rights reserved.			
<b>iGVD71 BX-CAT - Electrical Connection Diagram</b>			
Size <b>A4</b>	Document Number: P091.025.iGVD71.CAT.CDG.0523	Author: ALN	Rev <b>B</b>
Date: 0523	Sheet 1 of 1		