



*To select the CANopen protocol, connect pin 1 of J2 to GND; for TMLCAN protocol connect to +V_{LOG} or leave unconnected.

** The PNP/NPN connection is software selectable.

iMOT17xS XM - CAN		P/N:P036.121.E120	
Copyright © Technosoft 2021. All rights reserved.			
		Electrical Connection Diagram	
Title		iMOT172S XM-CAN	
Size A4	Document Number: P091.026.iMOT17xS XM.CDG.0321	Author: ALN	Rev C
Date: 0321	Sheet		1 of 1